

ENERCALC 3D

USER MANUAL

© 2020 ENERCALC, Inc.
ENERCALC, Inc.

This page is intentionally left blank.
Remove this text from the manual
template if you want it completely blank.

1.	ENERCALC 3D	15
1.1	License Agreement	17
1.2	Terms and Conventions	17
1.3	Introduction	18
1.3.1	Graphical User Interface (GUI)	20
1.3.2	Spreadsheet Navigation	20
2.	Menus	25
2.1	Model	26
2.1.1	Save Only	26
2.1.2	Save & Close	26
2.1.3	Close without Saving	26
2.1.4	Print Text Report	26
2.1.5	Envelope Report	26
2.1.6	Print Current View	27
2.1.7	Print Options	28
2.1.8	General Information	28
2.1.9	Frame Item Counts	29
2.1.10	View Log File	30
2.2	Edit	31
2.2.1	Undo	31
2.2.2	Redo	31
2.2.3	Lock Model	31
2.2.4	Duplicate	31
2.2.5	Array	32
2.2.6	Mirror	33
2.2.7	Move	34
2.2.8	Rotate	35
2.2.9	Scale	36
2.2.10	Delete	37
2.2.11	Extrude	38
2.2.11.1	Extrude > Extrude Nodes to Members	38
2.2.11.2	Extrude > Extrude Members to Shells	39
2.2.11.3	Extrude > Extrude Shells to Bricks	41
2.2.12	Revolve	43
2.2.12.1	Revolve > Revolve Members to Shells	43
2.2.12.2	Revolve > Revolve Shells to Bricks	45
2.2.13	Split Members	46
2.2.14	Sub-Mesh Shells	48
2.2.15	Insert Nodes at Intersections of Selected Members	49

2.2.16	Explode Selected Members at Nodes	49
2.2.17	Renumber	51
2.2.17.1	Renumber > Auto Number All Nodes	51
2.2.17.2	Renumber > Renumber Selected Nodes	51
2.2.17.3	Renumber > Renumber Selected Members/Shells/Bricks	52
2.2.18	Switch Coordinates	52
2.2.19	Reverse Node Order for Selected Elements	53
2.2.20	Merge All Nodes & Elements	53
2.2.21	Remove All Orphaned Nodes	53
2.2.22	Element Local Angle	53
2.2.23	Match Local x-Axes for Shells	53
2.2.24	3-Point Member Orientation	53
2.2.25	Tension/Compression Only	54
2.2.26	Convert Selected Members to Rigid Links	54
2.2.27	Self Weight Exclusion	54
2.2.28	Element Activation	54
2.2.29	Clear	54
2.2.29.1	Clear > Clear Undo & Redo	54
2.2.29.2	Clear > Clear Results	54
2.2.29.3	Clear > Clear Everything	55
2.3	View	55
2.3.1	Redraw	55
2.3.2	Restore Model	55
2.3.3	Preset Views	55
2.3.4	Named Views	56
2.3.5	Named Selections	56
2.3.6	Zoom	57
2.3.6.1	Zoom > Zoom Extent	57
2.3.6.2	Zoom > Zoom Window	57
2.3.6.3	Zoom > Zoom Object	57
2.3.6.4	Zoom > Zoom Previous	57
2.3.6.5	Zoom > Zoom In	57
2.3.6.6	Zoom > Zoom Out	57
2.3.7	Pan	57
2.3.7.1	Pan > Pan Screen	58
2.3.7.2	Pan > Right	58
2.3.7.3	Pan > Left	58
2.3.7.4	Pan > Up	58
2.3.7.5	Pan > Down	58
2.3.8	Rotate	58
2.3.8.1	Rotate > +X	58
2.3.8.2	Rotate > -X	58
2.3.8.3	Rotate > +Y	59
2.3.8.4	Rotate > -Y	59

2.3.8.5	Rotate > +Z	59
2.3.8.6	Rotate > -Z	59
2.3.9	Real-Time Motion	59
2.3.9.1	Real-Time Motion > Real-Time Pan	59
2.3.9.2	Real-Time Motion > Real-Time Zoom	59
2.3.9.3	Real-Time Motion > Real-Time Rotate	60
2.3.10	Window/Point Select	60
2.3.11	Line Select	61
2.3.12	Select by IDs	61
2.3.12.1	Select by IDs > Nodes	61
2.3.12.2	Select by IDs > Members	62
2.3.12.3	Select by IDs > Shells	62
2.3.12.4	Select by IDs > Bricks	62
2.3.12.5	Select by IDs > Select All	62
2.3.12.6	Select by IDs > Unselect All	62
2.3.13	Select by Properties	62
2.3.13.1	Select by Properties > Materials	63
2.3.13.2	Select by Properties > Member Sections	63
2.3.13.3	Select by Properties > Member Orientations	64
2.3.13.4	Select by Properties > Tension/Compression Only Members	65
2.3.13.5	Select by Properties > Shell Thicknesses	65
2.3.13.6	Select by Properties > Orphaned Nodes	66
2.3.13.7	Select by Properties > Coordinates	66
2.3.13.8	Select by Properties > Selection Names	67
2.3.13.9	Select by Properties > Concrete Beam/Column/Plate Criteria	68
2.3.13.10	Select by Properties > Steel Design Criteria	68
2.3.13.11	Select by Properties > Select/Unselect All	68
2.3.14	Flip Selection	68
2.3.15	Freeze Selected	68
2.3.16	Freeze All Except Level	68
2.3.17	Freeze All Except Plane	69
2.3.18	Thaw	69
2.3.19	Load Diagram	69
2.3.20	Annotate	70
2.3.21	Query	71
2.3.22	Distance	72
2.3.23	Render	72
2.3.23.1	Render > Render Options	73
2.3.23.2	Render > Quick Render	73
2.3.24	Result Diagrams	74
2.3.24.1	Result Diagrams > Shear and Moment Diagram	74
2.3.24.2	Result Diagrams > Deflection Diagram	75
2.3.24.3	Result Diagrams > Contour Diagram	76
2.3.24.4	Result Diagrams > Unity Check	78
2.3.24.5	Result Diagrams > Response Animation	78

2.3.25	Options	79
2.3.25.1	Options > Drawing Grid	79
2.3.25.2	Options > Global Axes	79
2.3.25.3	Options > Contour Legend	79
2.3.25.4	Options > Comment	79
2.4	Geometry	80
2.4.1	Materials	80
2.4.2	Member Sections	81
2.4.3	Shell Thicknesses	84
2.4.4	Levels	86
2.4.5	Drawing Grid	86
2.4.6	Object Snap	88
2.4.7	Draw Node	89
2.4.8	Draw Member	89
2.4.9	Draw Shell	90
2.4.10	Draw Brick	91
2.4.11	Generate	92
2.4.11.1	Generate > Nodes from Grid	92
2.4.11.2	Generate > Members by Nodes	92
2.4.11.3	Generate > Shells by Nodes	94
2.4.11.4	Generate > Bricks by Nodes	95
2.4.11.5	Generate > Non-Prismatic Members	95
2.4.11.6	Generate > Arc Members	96
2.4.11.7	Generate > Circular Shells	98
2.4.11.8	Generate > Rectangular Shells	99
2.4.11.9	Generate > Cylindrical Frames	101
2.4.11.10	Generate > Rectangular Frames	103
2.4.12	Element Local Angle	108
2.4.13	3-Point Member Orientation	109
2.4.14	Moment Releases	109
2.4.15	Rigid Offset	110
2.4.16	Tension/Compression Only	110
2.4.17	Convert Members to Rigid Links	111
2.4.18	Element Activation	111
2.4.19	Supports	111
2.4.19.1	Support	111
2.4.19.2	Inclined Roller	112
2.4.20	Springs	114
2.4.21	Diaphragms	115
2.4.22	Master-Slave	116
2.4.22.1	Master-Slave	116
2.4.22.2	Generic Displacement Constraint	116
2.4.23	Story Drift Nodes	117

2.5	Loads	118
2.5.1	Load Cases	118
2.5.2	Load Combinations	119
2.5.3	Nodal Loads	122
2.5.4	Point Loads	122
2.5.5	Line Loads	123
2.5.6	Area Loads	124
2.5.7	Surface Loads	125
2.5.8	Thermal Loads	126
2.5.9	Self Weights	127
2.5.10	Self Weight Exclusion	127
2.5.11	Generate Loads	127
2.5.11.1	Generate Loads > Fluid Loads	127
2.5.11.2	Generate Loads > Pattern Loads	128
2.5.11.3	Generate Loads > Moving Loads	129
2.5.12	Case-Copy Loads	130
2.5.13	Convert Area Loads to Line Loads	131
2.5.14	Convert Local Loads to Global Loads	131
2.5.15	Additional Masses	131
2.5.16	Response Spectra Library	132
2.6	Assign	134
2.6.1	Supports	134
2.6.2	Springs	135
2.6.3	Member Properties	137
2.6.4	Shell Properties	138
2.6.5	Nodal Loads	139
2.6.6	Point Loads	140
2.6.7	Line Loads	141
2.6.8	Surface Loads	141
2.6.9	Additional Masses	142
2.6.10	Deletion	143
2.7	Input Data	144
2.7.1	Materials	145
2.7.2	Sections	145
2.7.3	Shell Thicknesses	145
2.7.4	Nodes	145
2.7.5	Members	146
2.7.6	Shells	147
2.7.7	Bricks	148
2.7.8	Supports	149
2.7.9	Springs	150

2.7.9.1	Springs > Nodal Springs	150
2.7.9.2	Springs > Line Springs	151
2.7.9.3	Springs > Surface Springs	152
2.7.10	Member Releases	152
2.7.11	Diaphragms	153
2.7.12	Load Cases	154
2.7.13	Load Combinations	154
2.7.14	Nodal Loads	154
2.7.15	Point Loads	155
2.7.16	Line Loads	156
2.7.17	Area Loads	157
2.7.18	Surface Loads	158
2.7.19	Self Weights	159
2.7.20	Thermal Loads	160
2.7.20.1	Member Thermal Loads	160
2.7.20.2	Shell Thermal Loads	160
2.7.20.3	Brick Thermal Loads	161
2.7.21	Calculated Masses	162
2.7.22	Additional Masses	163
2.7.23	Response Spectra Library	164
2.7.24	Story Drift Nodes	166
2.7.25	Comments	167
2.8	Analysis	168
2.8.1	Analysis Options	168
2.8.2	Static Analysis	172
2.8.3	Frequency Analysis	173
2.8.4	Response Spectrum Analysis	174
2.9	Analysis Result	176
2.9.1	Nodal Displacements	176
2.9.2	Story Drifts	177
2.9.3	Support Reactions	177
2.9.4	Spring Reactions	178
2.9.4.1	Spring Reactions > Nodal	178
2.9.4.2	Spring Reactions > Line	178
2.9.4.3	Spring Reactions > Surface	179
2.9.5	Multi-DOF Constraint Forces & Moments	179
2.9.6	Member End Forces & Moments	180
2.9.7	Member Segmental Results	180
2.9.8	Shell Forces & Moments	181
2.9.9	Shell Principal Forces & Moments	181
2.9.10	Shell Stresses [Top & Bottom]	182
2.9.11	Shell Principal Stresses	183

2.9.12	Shell Nodal Resultants	183
2.9.13	Brick Stresses	184
2.9.14	Brick Principal Stresses	184
2.9.15	Eigenvalues	185
2.9.16	Eigenvectors	185
2.9.17	Mode Participation Factors	186
2.9.18	Modal Displacements SX, SY and SZ	186
2.9.19	Inertial Forces SX, SY and SZ	187
2.9.20	Modal Combinations	187
2.9.20.1	Nodal Displacements	187
2.9.20.2	Support Reactions	188
2.9.20.3	Nodal, Line and Surface Spring Reactions	188
2.9.20.4	Multi-DOF Constraint Forces & Moments	188
2.9.20.5	Member End Forces & Moments	189
2.9.20.6	Member Segmental Results	189
2.9.20.7	Shell Forces & Moments	190
2.9.20.8	Brick Stresses	190
2.9.20.9	Base Shears	190
2.10	Concrete Design	191
2.10.1	RC Materials	191
2.10.2	Design Criteria	192
2.10.2.1	Design Criteria > Model Design Criteria	192
2.10.2.2	Design Criteria > Beam Design Criteria	194
2.10.2.3	Design Criteria > Column Design Criteria	195
2.10.2.4	Design Criteria > Plate Design Criteria	197
2.10.2.5	Design Criteria > Exclude Elements	198
2.10.2.6	Design Criteria > Cracking Factors	198
2.10.3	Assign	199
2.10.3.1	Assign > Beam Design Properties	199
2.10.3.2	Assign > Column Design Properties	200
2.10.3.3	Assign > Plate Design Properties	200
2.10.4	Design Input	201
2.10.4.1	Design Input > RC Member Input	201
2.10.4.2	Design Input > RC Plate Input	202
2.10.5	Perform Design	203
2.10.6	Design Output	203
2.10.6.1	Design Output > RC Analysis Envelope	203
2.10.6.2	Design Output > RC Beam Results	204
2.10.6.3	Design Output > RC Column Results	204
2.10.6.4	Design Output > Flexural/Axial Interaction > Sections	205
2.10.6.5	Design Output > Flexural/Axial Interaction > P-Mx (+)	206
2.10.6.6	Design Output > Flexural/Axial Interaction > P-Mx (-)	206
2.10.6.7	Design Output > Flexural/Axial Interaction > P-My (+)	206
2.10.6.8	Design Output > Flexural/Axial Interaction > P-My (-)	207
2.10.6.9	Design Output > Flexural/Axial Interaction > P-Mx-My	207

2.10.6.10	Design Output > Flexural/Axial Interaction > Print Diagrams	207
2.10.6.11	Design Output > Member Shear Design Results	209
2.10.6.12	Design Output > Wood-Armer Moments	209
2.10.6.13	Design Output > RC Plate Results	210
2.10.7	Diagrams	210
2.10.7.1	Diagrams > RC Member Envelope Diagram	210
2.10.7.2	Diagrams > RC Plate Envelope Contour	211
2.10.8	RC Report	212
2.10.9	RC Tools	214
2.10.9.1	RC Tools > Rebar Database	214
2.10.9.2	RC Tools > K Calculator	214
2.10.9.3	RC Tools > Quick Rectangular Beam Flexural Design	215
2.10.9.4	RC Tools > Quick Tee Beam Flexural Design	216
2.11	Steel Design	217
2.11.1	Steel Materials	217
2.11.2	Design Criteria	218
2.11.2.1	Model Design Criteria	218
2.11.2.2	Member Design Criteria	219
2.11.2.3	Section Pool	221
2.11.2.4	Exclude Elements	221
2.11.3	Assign Member Design Properties	222
2.11.4	Steel Member Input	222
2.11.5	Perform Design	223
2.11.6	Design Results	223
2.11.7	Steel Tools	224
2.11.7.1	K Calculator	224
2.11.7.2	Section Check	224
2.11.7.3	Section Design	239
2.12	Settings	240
2.12.1	Units & Precisions	240
2.12.2	Data Options	241
2.12.3	New Origin	243
2.12.4	Graphic Scales	244
2.12.5	Colors	244
2.12.6	Preferences	245
2.12.7	Tools	246
2.12.7.1	Tools > Unit Conversion	246
2.12.7.2	Tools > Calculator	247
2.12.7.3	Tools > Text Editor	247
2.12.7.4	Tools > Copy Command History	247
2.12.7.5	Tools > Clear Command History	247
2.12.8	Toolbars	247
2.13	Window	248
2.13.1	New Window	248

2.13.2	Close	248
2.13.3	Close All	248
2.13.4	Tile Horizontal	248
2.13.5	Tile Vertical	248
2.13.6	Tile Cascade	248
3.	Toolbars	251
3.1	Main Toolbar	252
3.2	View Toolbar	252
3.3	Edit/Run Toolbar	254
3.4	Input Toolbar	255
3.5	Output Toolbar	255
3.6	Status Bar	256
4.	Coordinate Systems	257
4.1	Global Coordinate System	258
4.2	Local Coordinate Systems - General	258
4.3	Member Local Coordinate System	259
4.4	Four-Node Shell Local Coordinate System	261
4.5	Eight-Node Brick Local Coordinate System	262
5.	Nodes	263
5.1	Nodal Coordinates	264
5.2	Degrees of Freedom (DOFs)	264
5.3	Node Numbers	265
5.4	Loads	266
5.5	Supports	266
5.6	Springs	267
6.	Members	269
6.1	Member Sections	270
6.2	Local Coordinate System	270
6.3	Member Numbers	271
6.4	Beams Vs. Trusses	271
6.5	Elastic Stiffness Matrix	271
6.6	Geometric Stiffness Matrix	272
6.7	Moment Releases	273

6.8	Tension/Compression-Only	273
6.9	Rigid Links	274
6.10	Rigid Diaphragms	274
6.11	Loads	274
6.12	Line Springs	279
6.13	Internal Forces and Moments	280
7.	Shells	283
7.1	Shell Thicknesses	285
7.2	Local Coordinate System	285
7.3	Shell Numbers	285
7.4	Element In-Plane Stiffness Matrix	286
7.5	Element Out-of-Plane Stiffness Matrix	286
7.6	Combining Element In-Plane and Out-of-Plane Stiffness Matrices	286
7.7	Loads	286
7.8	Surface Springs	287
7.9	Internal Forces or Moments	287
7.10	Membrane Nodal Resultants	289
8.	Bricks	291
8.1	Local Coordinate System	292
8.2	Brick Numbers	292
8.3	Element Stiffness Matrix	292
8.4	Loads	293
8.5	Internal Stresses	293
9.	Static Analysis	295
9.1	Load Cases and Load Combinations	296
9.2	Linear, Non-linear Static Analyses	296
9.3	P-Delta (P- Δ) vs. P-delta (P- δ)	297
9.4	Solution Algorithm	299
9.5	Solution Accuracy and Stability	300
10.	Frequency Analysis	303
10.1	Solution Algorithm	304
10.2	Mass and Stiffness	305
10.3	Solution Convergence	305

11. Concrete Design – ACI 318-02/05/08/11/14	307
11.1 Concrete Column Design	308
11.2 Concrete Beam Design	318
11.3 Concrete Slab/Wall Design	322
12. Steel Design	325
12.1 Section Orientation	326
12.2 Member Internal Forces and Moments	326
12.3 Solution Algorithms	327
13. References	329
14. Appendix	333
14.1 Unit Conversions	334
14.2 Designations, diameters and areas of standard bars	334
Index	0


This page is intentionally left blank.
Remove this text from the manual
template if you want it completely blank.

ENERCALC 3D

1 ENERCALC 3D

ENERCALC 3D

A Structural Analysis and Design Program



Accuracy, Reliability, Ease of Use

ENERCALC, INC.

Last Edited: 3 February 2020

1.1 License Agreement

OpenGL® is a registered trademark of Silicon Graphics, Inc. (SGI).
Windows® is a registered trademark of Microsoft Corporation.
ENERCALC 3D is a trademark of ENERCALC, Inc.

Copyright 2010-2019 by ENERCALC. All rights reserved.

1.2 Terms and Conventions

The convention for commands in this documentation is Main Menu > Sub-Menu. For example, Model Editing > Undo means the Undo command from the Model Editing item in the main menu.

Model View: A window in the program that contains the graphical display of the model.

Report View: A window in the program that contains the text or graphical report.

Structural Command: A command in the program that affects the results for a model.

Member: A beam or frame element. It also refers to a truss when the element has full moment releases at two ends. The term “beam element”, “frame element” and “member” are used interchangeably in this program.

Shell: a four-node shell finite element. It includes membrane action and plate bending action. It is sometimes called a plate.

Brick: an eight-node solid finite element.

Entity: A node, member, shell or brick.

Element: A member or finite element (shell or brick).

Object: A node or finite element (shell or brick) or its dependent.

Dependent: A structural entity whose existence depends upon the existence of another structural entity. For example, a support is a dependent of a node; a moment release is a dependent of a member (beam element). All loads are dependents of nodes or members or finite elements.

Parent: A structural entity which may have dependents. Nodes and elements may be parents. For example, a node may be a parent of a support or a member. A member may be a parent of a moment release.

Distance List: A comma separated list that specifies multiple distances. For example, a distance list of "12,2@14,3@10" will generate distances of 12, 14, 14, 10, 10, and 10 in length units.

Orphaned Node: A node that is not connected to any elements.

DOFs: Degrees of freedom.

64-bit floating point (double precision): The solver that uses 64-bit (8 bytes) floating-point arithmetic. The 64-bit floating point (double precision) is the standard solver in almost all structural analysis programs.

128-bit floating point (quad precision): The solver that uses 128-bit (16 bytes) floating-point arithmetic. The 128-bit floating point (quad precision) is extremely accurate and is uniquely available in ENERCALC 3D.

1.3 Introduction

Built from the ground up, ENERCALC 3D is a powerful structural design / finite element analysis software tool designed for structural engineers of all skill levels. ENERCALC 3D is reliable, easy to use, and affordable. The software is designed for accuracy and simplicity, allowing engineers to get the job done without being overwhelmed by useless features.

The program includes the following frame and finite elements:

- 2D and 3D beam and truss element (also called member). The element can be linear, tension-only or compression-only.
- 3D four-node shell element, with thick (MITC4) plate and thin (Kirchhoff) plate bending and plane membrane stress (compatible and incompatible) formulations.
- 3D eight-node solid element (brick) with compatible and incompatible formulations.
- Linear and nonlinear nodal, line, and surface spring elements.
- Rigid diaphragm.

The program includes the following analysis and design options:

- Static linear analysis.
- Geometric nonlinear (P-Delta) analysis.
- Standard 64-bit floating point (double precision) and extremely accurate 128-bit floating point (quad precision) skyline solvers.
- Lightning fast sparse solver based on Intel PARDISO solver.
- Nodal, point, line, and surface forces; point moments; self-weight.
- Forced displacements on supports.
- Member moment releases.
- Concrete beam, column and slab/wall designs according to ACI 318-02/05/08/11/14.
- Steel beam and column design according to AISC 14th Edition LRFD.

The program provides the following main user interface features:

- Multiple views with different display settings.
- Graphically drawing nodes, members and finite elements, area loads and rigid diaphragms via mouse-click.
- Versatile spreadsheets for input data and results.
- Powerful automatic model generations for continuous beams; 2D and 3D frames; 2D and 3D shells; arc beams and non-prismatic beams.
- Quality 3D graphical rendering with hidden line or surface removal based on OpenGL®
- Loading diagram; moment and shear diagram for members; contours for shells and solids; deflection diagram.
- Flexible editing features such as undo/redo, duplicate, move, scale, delete, revolve, extrude, splitting members, sub-mesh shells, node and element merging.
- Real time panning, zooming and rotating.
- Many different selection methods such as point/window/cross select, select by IDs, select by properties, with options to freeze or thaw parts of a model.
- Flexible annotations for input and results.
- Text and graphical reports in html format. Graphical report may contain multiple images. Text report may be saved in plain text format.
- Print previews for graphical and text reports

1.3.1 Graphical User Interface (GUI)

ENERCALC 3D has a modern graphical user interface (Figure 0.1). It includes menus, multiple toolbars, multiple views and a status bar.




Figure 0.1

1.3.2 Spreadsheet Navigation

The program uses spreadsheets (grid control, see Figure 0.2) extensively for data input and output. It offers multiple ways to navigate within a spreadsheet as specified in the following table.




Figure 0.2

Key	Action
up arrow	Moves active cell up one row
down	Moves active cell down one row
right	Moves active cell right one column

Key	Action
left arrow	Moves active cell left one column
Shift+arrow	Extends selection in direction of arrow key
Page Up	Moves active cell one page up
Page	Moves active cell one page down
Ctrl+Page	Moves active cell one page left
Ctrl+Page	Moves active cell one page right
Home	Moves active cell to first cell in row
End	Moves active cell to last cell in row that contains data
Ctrl+Home	Moves active cell to first row, first column
Ctrl+End	Moves active cell to last row and column that contain data
Tab	Moves active cell to next cell to the right (or at end of row moves to beginning of next row)
Shift+Tab	Moves active cell to next cell to the left (or at beginning of row moves up to end of row above)

Key	Action
Shift+spac	Selects current row
Ctrl+space	Selects current column
Shift+Ctrl+	Selects entire sheet
Ctrl+X or	Cuts current selection or active cell's data to Clipboard
Ctrl+V or	Pastes Clipboard contents into active cell
Ctrl+C or	Copies current selection or active cell's data to Clipboard

Key	Action
Enter	Active cell moves down
Esc	If sheet is in edit mode, previous cell value replaces new value and edit mode is turned off
F2	If edit mode is on, cell value is cleared

Menus

2 Menu

2.1 Model

The Model menu provides commands that are related to files. It also provides commands related to text and graphical reports.

The program generates text reports for input and output, or graphical reports for captured images in PDF file format. Report files may be viewed as separate windows within the program.

The Model menu changes its layout depending upon the view type of the current window. For example, when the current window is a report view, commands related to printing are provided.

2.1.1 Save Only

When the current window is a model view, Model > Save Only saves the model. If the model has not been saved before, the Save As dialog box will be displayed prompting you to enter a file name.

2.1.2 Save & Close

Saves the current model data, closes the model and redisplay the Model Manager window.

2.1.3 Close without Saving

Model > Close without Saving provides a way to close the current model and return to the Model Manager without saving the current model.

2.1.4 Print Text Report

Model > Print Text Report allows you to preview and print a report for the model using the current report configuration options.

2.1.5 Envelope Report

Analysis Result > Envelope Report allows you to print enveloped diagrams of multiple load combinations on members (Figure 1.1). You may give a name to the type of envelope. You have the option to print an envelope report on selected members only. Two charts are printed on each page. You have the option to select the diagram

type for each chart. For example, you may select the major moment Mz diagram for chart one and the major shear Vy diagram for the second chart.




Figure 1.1

2.1.6 Print Current View

Model > Print Current View allows you to preview and print the current model view.

2.1.7 Print Options

Model > Print Options prompts you with the following dialog box (Figure 1.2). It allows you to generate a report for input and/or output data in html file format.

The command provides different options to control the contents of the report. For example, you may generate a report for selected nodes or elements only. After clicking the OK button, the graphical report will be displayed in a report view within the web browser. You may then print the report to a PDF file.





Figure 1.2

2.1.8 General Information

Model > General Information prompts you with the following dialog box (Figure 1.3). It allows you to



A dialog box titled "General Information" with a close button (X) in the top right corner. It contains three text input fields: "Project Name:" with the value "Examples", "Model Name:" with the value "Example-10", and "Engineer(s):" with the value "Chris Conrad". Below these fields is a large text area with the placeholder text "Write your notes here" and a vertical scrollbar. At the bottom right of the dialog are two buttons: "OK" and "Cancel".

Figure 1.3

2.1.9 Frame Item Counts

Model > Frame Item Counts displays the key statistics about the model (Figure 1.4).

The screenshot shows a window titled "Model Statistics" with a standard Windows interface (minimize, maximize, close buttons). Below the title bar are three buttons: "Print...", "Save...", and "Close". The main area contains a table with two columns: "Item" and "Value". The table lists 25 items, with the first row "Materials" highlighted in orange. The rest of the rows have a light blue background. A vertical scrollbar is on the right side of the table.

	Item	Value
1	Materials	1
2	Member Sections	1
3	Shell Thicknesses	1
4	Beam RC Design Criteria	1
5	column RC design criteria	1
6	Plate RC design criteria	1
7	Steel design criteria	1
8		
9	Nodes	0
10	Members	0
11	Shells	0
12	Bricks	0
13		
14	Supports	0
15	Nodal Springs	0
16	Line Springs	0
17	Surface Springs	0
18	Beam Releases	0
19		
20	Load Cases	1
21	Load Combinations	1
22		
23	Loads in case - Default	
24	Nodal Loads	0
25	Point Loads	0

Figure 1.4

2.1.10 View Log File

Model > View Log File allows you to view the log file generated during the solution process

2.2 Edit

The Edit main menu provides commands to edit or modify the model.

2.2.1 Undo

Edit > Undo undoes the previous structural command. By default, you may undo up to 10 levels. You may set a different number of undo levels by running Settings > Data Options. Non-structural commands such as zooming or panning may not be undone. More undo levels requires more computer memory.

2.2.2 Redo

Edit > Redo reverses the previous undo command.

2.2.3 Lock Model

Edit > Lock Model locks the model so that you cannot modify it. You may still access non-structural commands such as zooming and panning while the model is locked. The model may be automatically locked after an analysis is performed successfully. To do that, just click Settings > Preferences.

2.2.4 Duplicate

Edit > Duplicate prompts you with the following dialog box (Figure 2.1). It allows you make one copy of the selected parts of a model to a different location. You may specify copydistances along the X, Y or Z directions. Nodal or element dependents (except loads) are copied together with their parents automatically. For example, when a member is copied, moment releases on that member are copied also. You have the option to copy the loads attached to the selected nodes or elements. You have the option to automatically merge nodes and elements after copying. You should check this option unless duplicate nodes are explicitly permitted.




Figure 2.1

2.2.5 Array

Edit > Array prompts you with the following dialog box (Figure 2.2). It allows you make one or more copy of the selected parts of a model to a different location. You may specify the step size along the X, Y or Z directions. Nodal or element dependents (except loads) are copied together with their parents automatically. For example, when a member is copied, moment releases on that member are copied also. You have the option to copy the loads attached to the selected nodes or elements. You have the option to automatically merge nodes and elements after copying. You should check this option unless duplicate nodes are explicitly permitted.




Figure 2.2

2.2.6 Mirror

Edit > Mirror prompts you with the following dialog box (Figure 2.3). It allows you to mirror the selected parts of a model to a different location by defining a mirror plane. Nodal or element dependents (except loads) are mirrored together with their parents automatically. For example, when a member is mirrored, moment releases on that member are mirrored also. You have the option to copy the loads attached to the selected nodes or elements. You have the option to automatically merge nodes and elements after copying. You should check this option unless duplicate nodes are explicitly permitted.




Figure 2.3

2.2.7 Move

Edit > Move prompts you with the above dialog box (Figure 2.4). It lets you move selected parts of a model to a different location. You may specify move distances along the X, Y or Z directions. Nodal or element dependents such as loads are moved together with selected nodes or elements automatically. You have the option to automatically merge nodes and elements after moving. You should check this option unless duplicate nodes are explicitly permitted.




Figure 2.4

Note: When using this command, be sure to select the intended entities AND THEIR NODES, before executing the command. If the entities are selected without their nodes, the command will not work.

2.2.8 Rotate

Edit > Rotate prompts you with the following dialog box (Figure 2.5). It lets you rotate selected parts of a model by an angle about one of the global axes. Nodal or element dependents such as loads are moved together with the elements. You have the option to automatically merge nodes and elements after rotating. You should check this option unless duplicate nodes are explicitly permitted.




Figure 2.5

Note: When using this command, be sure to select the intended entities AND THEIR NODES, before executing the command. If the entities are selected without their nodes, the command will not work.

2.2.9 Scale

Edit > Scale prompts you with the above dialog box (Figure 2.6). It lets you scale selected parts of a model in the X, Y or Z directions. You may specify the coordinates of a base point and scales for the three global directions.

The following formula is used to perform the scaling in the program.

$$X_{new} = X_{base} + (X_{old} - X_{base}) * scale$$

Where X_{new} represents the nodal coordinates after scaling, X_{old} represents the nodal coordinates before scaling and X_{base} represents coordinates of the base point.




Figure 2.6

Note: When using this command, be sure to select the intended entities AND THEIR NODES, before executing the command. If the entities are selected without their nodes, the command will not work.

2.2.10 Delete

Edit > Delete prompts you with the following dialog box (Figure 2.7). It allows you to delete selected nodes or elements or their dependents. Loads are deleted based on their visibilities in the model view. Dependents such as loads will be deleted if their parent nodes or elements are deleted.




Figure 2.7

2.2.11 Extrude

Edit > Extrude provides various methods of creating entities by starting with a selected set and extruding them by specified distances.

2.2.11.1 Extrude > Extrude Nodes to Members

Edit > Extrude > Extrude Nodes to Members prompts you with the following dialog box (Figure 2.8). It generates a series of members by extruding selected nodes along a global direction.

You may specify a distance list and an extrusion direction for the generation of beams. The distance list is a comma separated list that specifies multiple distances. For example, a distance list of “12,2@14,3@10” will generate distances of 12, 14, 14, 10, 10 and 10 in length units. You have the option to automatically merge nodes and elements after extrusion. You should check this option unless duplicate nodes are explicitly permitted.




Figure 2.8

The following members in Figure 4.30 are generated by extruding one node (the first node) using the input from Figure 4.29.



Figure 2.9

2.2.11.2 Extrude > Extrude Members to Shells

Edit > Extrude > Extrude Members to Shells prompts you with the following dialog box (Figure 2.10). It generates a series of shells by extruding selected members along a global direction. You may specify a distance list and an extrusion direction for the generation of shells. The extrusion direction must not be parallel to the selected members. You have the option to automatically merge nodes and elements after extrusion. You should check this option unless duplicate nodes are explicitly permitted. You also have the option to automatically delete selected members after the extrusion.




Figure 2.10

The input in Figure 2.10 is applied to the members in Figure 2.11 to generate the shells in Figure 2.12 by extruding.




Figure 2.11




Figure 2.12

2.2.11.3 Extrude > Extrude Shells to Bricks

Edit > Extrude > Extrude Shells to Bricks prompts you with the following dialog box (Figure 2.13). It generates a series of bricks by extruding selected shells along a global direction. You may specify a distance list and an extrusion direction for the generation of shells. The extrusion direction must not be parallel to the selected shells. You have the option to automatically merge nodes and elements after extrusion. You should check this option unless duplicate nodes are explicitly permitted. You also have the option to automatically delete selected shells after the extrusion.






Figure 2.13

The input in Figure 2.13 is applied to the shells in Figure 2.14 to generate the bricks in Figure 2.15 by extruding.



shells used for extruding

Figure 2.14



bricks generated


Figure 2.15

2.2.12 Revolve

Edit > Revolve provides various methods of creating entities by starting with a selected set and revolving them through specified angles.

2.2.12.1 Revolve > Revolve Members to Shells

Edit > Revolve > Revolve Members to Shells prompts you with the following dialog box (Figure 2.16). It generates a series of shells by revolving selected members about the global Y axis. You may specify the number of segments, start and end angles for revolving. The program will merge nodes automatically. You have the option to automatically delete the selected members after revolving.



Revolve Selected Members to Shells

Revolve about Global Y

Segments: 16

Start angle: 0 deg

End angle: 360 deg


Delete selected members after revolving

Nodes will be merged automatically.

OK Cancel


Figure 2.16

The input in Figure 2.16 is applied to the members in Figure 2.17 to generate the shells in Figure 2.18 by revolving.



members used for revolving

Figure 2.17



shells generated

Figure 2.18

2.2.12.2 Revolve > Revolve Shells to Bricks

Edit > Revolve > Revolve Shells to Bricks prompts you with the following dialog box (Figure 2.19). It generates a series of bricks by revolving selected shells about the global Y axis. You may specify the number of segments, start and end angles for revolving. The program will merge nodes automatically. You have the option to automatically delete the selected shells after revolving.




Figure 2.19

The input in Figure 2.19 is applied to the shells in Figure 2.20 to generate the bricks in Figure 2.21 by revolving. Bricks are rendered in the figure.




Figure 2.20




Figure 2.21

2.2.13 Split Members

Edit > Split Members prompts you with the following dialog box (Figure 2.22). It allows you to divide selected members by specifying 2 or more segments of equal length or by providing a distance list. Loads on the original members are assigned

automatically to the generated members after splitting. You have the option to automatically merge nodes and elements after splitting.





Figure 2.22

The input in Figure 2.22 is applied to the members in Figure 2.23 to generate the members in Figure 2.24 by splitting.



members before splitting

Figure 2.23




Figure 2.24

2.2.14 Sub-Mesh Shells

Edit > Sub-Mesh Shells prompts you with the following dialog box (Figure 2.25). It allows you to sub-mesh selected shells by specifying 2 or more segments along sides 1-2 & 4-3 and sides 2-3 & 1-4. Loads on the original shells are assigned automatically to the generated shells after sub-meshing. You have the option to merge nodes and elements after sub-meshing. You should check this option unless duplicate nodes are explicitly permitted.






Figure 2.25

The input in Figure 2.25 is applied to the shells in Figure 2.26 to generate the shells in Figure 2.27 by meshing.



shells before sub-meshing

Figure 2.26



shells after sub-meshing

Figure 2.27

2.2.15 Insert Nodes at Intersections of Selected Members

Edit > Insert Nodes at Intersections of Selected Members allows you to insert nodes at all intersections of the selected members. The newly created nodes are likely isolated (orphaned) nodes, meaning they are not attached to intersecting members. Generally speaking, you should explode the members at these nodes. The program prompts you to do so at the end of this command.

2.2.16 Explode Selected Members at Nodes

Edit > Explode Selected Members at Nodes allows you to split selected members at nodes which are located on but are not connected to these members.

Consider the following three figures: Figure 2.28 shows a shell with edge members on four sides:




Figure 2.28

Figure 2.29 shows shells generated by sub-meshing (2x2) the shell from Figure 4.49:




Figure 2.29

Figure 2.30 shows members generated by exploding members at nodes.




Figure 2.30

Notice in Figure 2.30, the middle nodes on the edge are on but not connected to the members. The figures are rendered using the command View > Render, with the rendering ratio of 80% for both members and shells.

2.2.17 Renumber

Edit > Renumber offers options to renumber entities in the model.

2.2.17.1 Renumber > Auto Number All Nodes

Edit > Renumber > Auto Number All Nodes prompts you with the following dialog box (Figure 2.31). It allows you to renumber all nodes sequentially based on nodal coordinates.




Figure 2.31

2.2.17.2 Renumber > Renumber Selected Nodes

Edit > Renumber > Renumber Selected Nodes prompts you with the following dialog box (Figure 2.32). It allows you to Renumber selected nodes based on the following two modes:

- a). Increment each selected node number by a delta (may be positive or negative). For example, if we have selected node numbers 2, 5, 8 and a delta of 2, the new node numbers will be 4, 7, and 10.
- b). Renumber each selected node from a new start number (must be positive) and a step (may be positive or negative). For example, if we have selected node numbers 2, 5, 8, a new start number of 1000 and a step of 2, the new node numbers will be 1000, 1002, 1004.

If renumbering is successful, nodal dependents such as loads, masses and springs will be renumbered automatically. The renumbering will be undone automatically if any errors are encountered.




Figure 2.32

2.2.17.3 Renumber > Renumber Selected Members/Shells/Bricks

Edit > Renumber > Renumber Members, Shells and Bricks commands are similar to Renumber Nodes and are not repeated here.

2.2.18 Switch Coordinates

Edit > Switch Coordinates prompts you with the following dialog box (Figure 2.33). It allows you to switch the X and Z, or the Y and Z coordinates of the selected nodes. For example, you may generate a floor system on the XY (vertical) plane and then switch coordinates to place the floor on the XZ (horizontal) plane.




Figure 2.33

2.2.19 Reverse Node Order for Selected Elements

Edit > Reverse Node Order for Selected Elements allows you to reverse the nodes' order for selected elements. For members and shells, this command in effect changes their local coordinate systems. For bricks, this command may be used to rectify a wrong nodal ordering which results in negative diagonals in element stiffness.

It is important to point out that dependents on the elements are not reversed or changed accordingly. After running this command, you should check on these dependents such as loads and moment releases on members, loads on shells, etc.

2.2.20 Merge All Nodes & Elements

Edit > Merge All Nodes & Elements merges all nodes that are located within a distance tolerance between two or more nodes, and merges all elements that share the same nodes. You may set the distance tolerance using the command Settings > Data Options.

2.2.21 Remove All Orphaned Nodes

Edit > Remove All Orphaned Nodes removes all nodes that are not connected to any elements. Orphaned nodes make the model unstable. They must be removed prior to the solution.

2.2.22 Element Local Angle

Edit > Element Local Angle prompts you with a dialog box to assign local angles to the selected members and/or shells. The element local angle is used to change the element local coordinate system.

2.2.23 Match Local x-Axes for Shells

Edit > Match Local x-Axes for Shells prompts you with a dialog box to specify a source shell. The orientation of the local x-axes of the selected shells will be changed to match the orientation of the local x-axis of the source shell.

2.2.24 3-Point Member Orientation

Edit > 3-Point Member Orientation prompts you with a dialog box to specify an X, Y, and Z coordinate. The orientation of selected members will be changed so the local z-axis of all selected members is perpendicular to the plane formed by the two member end coordinates and the specified X, Y, Z coordinate.

2.2.25 Tension/Compression Only

Edit > Tension/Compression Only prompts you with a dialog box to assign nonlinearity (linear, tension only or compression only) to the selected members. The member stiffness will be ignored if a tension only member is subjected to compressive forces or if a compression only member is subjected to tensile forces. The presence of tension only or compression only members makes the model nonlinear and requires iterative solution for each load combination.

2.2.26 Convert Selected Members to Rigid Links

Edit > Convert Members to Rigid Links will convert selected members to rigid links.

2.2.27 Self Weight Exclusion

Edit > Self Weight Exclusion allows self weight to be considered or ignored for selected members, shells, and bricks.

2.2.28 Element Activation

Edit > Element Activation allows members, shells, and/or bricks to be selectively activated or deactivated.

This allows these modeling entities to remain in the model while studying the effects of ignoring their structural contributions to the model.

2.2.29 Clear

Edit > Clear offers some options for clearing some data that could be using memory.

2.2.29.1 Clear > Clear Undo & Redo

Edit > Clear > Clear Undo & Redo clears the undo/redo buffer, thus frees up computer memory. It is a good idea to use this command before the solution so that more memory may be committed to the solver.

2.2.29.2 Clear > Clear Results

Edit > Clear > Clear Results clears all results from computer memory. You need to re-solve the model to obtain new results.

2.2.29.3 Clear > Clear Everything

Edit > Clear > Clear Everything clears all input and output (results) data from computer memory. You should think twice before running this command.

2.3 View

The View menu provides commands to graphically view inputs such as geometry and loading; perform selections by various methods; and display outputs such as shear and moment diagrams for members, and contours for shells and bricks.

2.3.1 Redraw

View > Redraw regenerates and redraws all graphics in the model view.

2.3.2 Restore Model

View > Restore restores original settings for the model view. These settings include zooming = 1.0, panning = 0, rotation = 0.

2.3.3 Preset Views

You may place the model view in a preset orientation by selecting one of these commands (Figure 3.1).

Front	Back	Left	Right
Top	Bottom	Isometric	

Figure 3.1

2.3.4 Named Views

View > Named Views allows you to save the current view settings such as zooming factor, panning distance or rotation angles so that you may recall the same view settings later on.

2.3.5 Named Selections

View > Named Selections prompts you with the following dialog box (Figure 3.2). It allows you to save the currently selected items to a name. You may use the command View > Select by Properties > Selection Names to recall the previously saved named selections. This command is very useful to group related items.




Figure 3.2

2.3.6 Zoom

The Zoom controls allow the model to be displayed at various scales.

2.3.6.1 Zoom > Zoom Extent

View > Zoom > Zoom Extent displays the entire model in the view.

2.3.6.2 Zoom > Zoom Window

View > Zoom > Zoom Window zooms in on a specific part of the model by clicking and dragging the left mouse button. The command remains in effect until another command is selected, the right mouse button is clicked, or ESC is pressed.

2.3.6.3 Zoom > Zoom Object

View > Zoom > Zoom Object zooms in on a specific node, member, shell or brick. The command remains in effect until another command is selected, the right mouse button is clicked, or ESC is pressed.

2.3.6.4 Zoom > Zoom Previous

View > Zoom > Zoom Previous lets you zoom back to the previous view. You may use this command after you zoom in or pan to view a portion of your model in greater detail.

2.3.6.5 Zoom > Zoom In

View > Zoom > Zoom In zooms in on the model by a preset factor (1.25). You may use this command by pressing CTRL+UP arrow or CTRL+RIGHT arrow.

2.3.6.6 Zoom > Zoom Out

View > Zoom > Zoom Out zooms out on the model by a preset factor (1.25). You may use this command by pressing CTRL+DOWN arrow or CTRL+LEFT.

2.3.7 Pan

The Pan controls allow the view of the model to be moved.

2.3.7.1 Pan > Pan Screen

View > Pan > Pan Screen pans (moves) the model by clicking and dragging the left mouse button. The command remains in effect until another command is selected, the right mouse button is clicked, or ESC is pressed.

2.3.7.2 Pan > Right

View > Pan > Right pans the model to the right by a preset screen distance. You may use this command by pressing CTRL+RIGHT arrow.

2.3.7.3 Pan > Left

View > Pan > Left pans the model to the left by a preset screen distance. You may use this command by pressing CTRL+LEFT arrow.

2.3.7.4 Pan > Up

View > Pan > Up pans the model to the top by a preset screen distance. You may use this command by pressing CTRL+UP arrow.

2.3.7.5 Pan > Down

View > Pan > Down pans the model to the bottom by a preset screen distance. You may use this command by pressing CTRL+DOWN arrow.

2.3.8 Rotate

The Rotate commands allow the view of the model to be spun around various axes.

2.3.8.1 Rotate > +X

View > Rotate > +X rotates the model view about X by a preset positive angle (5 degrees). You may use this command by pressing SHIFT+DOWN arrow.

2.3.8.2 Rotate > -X

View > Rotate > -X rotates the model view about X by a preset negative angle (5 degrees). You may use this command by pressing SHIFT+UP arrow.

2.3.8.3 Rotate > +Y

View > Rotate > +Y rotates the model view about Y by a preset positive angle (5 degrees). You may use this command by pressing SHIFT+RIGHT arrow.

2.3.8.4 Rotate > -Y

View > Rotate > -Y rotates the model view about Y by a preset negative angle (5 degrees). You may use this command by pressing SHIFT+LEFT arrow.

2.3.8.5 Rotate > +Z

View > Rotate > +Z rotates the model view about Z by a preset positive angle (5 degrees). You may use this command by pressing CTRL+SHIFT+UP arrow or CTRL+SHIFT+RIGHT arrow

2.3.8.6 Rotate > -Z

View > Rotate > -Z rotates the model view about Z by a preset negative angle (5 degrees). You may use this command by pressing CTRL+SHIFT+DOWN arrow or CTRL+SHIFT+LEFT arrow

2.3.9 Real-Time Motion

The Real-Time Motion commands allow the model view to be grabbed and moved or spun.

2.3.9.1 Real-Time Motion > Real-Time Pan

View > Real-Time Motion > Real-Time Pan allows you to pan the model view in real time by clicking and dragging the left mouse button. The command remains in effect until another command is selected, the right mouse button is clicked, or ESC is pressed.

2.3.9.2 Real-Time Motion > Real-Time Zoom

View > Real-Time Motion > Real-Time Zoom allows you to zoom in or out on the model view in real time by clicking and dragging the left mouse button up or down. The command remains in effect until another command is selected, the right mouse button is clicked, or ESC is pressed.

2.3.9.3 Real-Time Motion > Real-Time Rotate

View > Real-Time Motion > Real-Time Rotate allows you to rotate the model view in real time by clicking and dragging the left mouse button. The command remains in effect until another command is selected, the right mouse button is clicked, or ESC is pressed.

2.3.10 Window/Point Select

View > Window/Point Select allows you to window-select or point-select nodes and elements by clicking or clicking-dragging the left mouse button. The Window/ Point Select command is the default selection command in the program.

Point versus Window

The point-selection selects or unselects at most one node or element. The window-selection selects or unselects a group of nodes or elements within a rectangular selection window.

Window Drawn Right-to-Left versus Left-to-Right

If the selection window is drawn from left to right, then only entities that are entirely within the selection rectangle will be selected/unselected.

If the selection window is drawn from right to left, then all entities that are crossed by the selection rectangle will also be selected or unselected.

Select versus Reverse Select

By default, the selection mode is REVERSE SELECT, that is, entities picked will be selected if they are currently unselected and will be unselected if they are currently selected. However, the selection mode will be SELECT if CTRL is pressed while selecting, that is, entities picked will always be selected.

The selection of nodes and elements is an important activity in the program. Most of the commands apply only to selected nodes or elements. For this reason, many selection methods are provided in the program and are explained in the following sections.

2.3.11 Line Select

View > Line Select allows you to line-select elements by clicking-dragging the left mouse button. The line-selection selects or unselects a group of entities that the drawn line intersects.

2.3.12 Select by IDs

The Select by IDs tools offer many easy ways to quickly select multiple entities.

2.3.12.1 Select by IDs > Nodes

View > Select by IDs > Nodes prompts you with the following dialog box (Figure 3.3). It allows you to select nodes by specifying a range of node IDs.

Three selection modes are provided: “Select”, “Unselect”, “Reverse Select”. The “Select” mode will select nodes. The “Unselect” mode will unselect nodes. The “Reverse Select” mode will select the unselected nodes and unselect the selected nodes.




Figure 3.3

2.3.12.2 Select by IDs > Members

View > Select by IDs > Members prompts you with a dialog box to select members by specifying a range of member IDs.

Three selection modes are provided: “Select”, “Unselect”, “Reverse Select”. The “Select” mode will select members. The “Unselect” mode will unselect members. The “Reverse Select” mode will select the unselected members and unselect the selected members.

2.3.12.3 Select by IDs > Shells

View > Select by IDs > Shells prompts you with a dialog box to select shells by specifying a range of shell IDs.

Three selection modes are provided: “Select”, “Unselect”, “Reverse Select”. The “Select” mode will select shells. The “Unselect” mode will unselect shells. The “Reverse Select” mode will select the unselected shells and unselect the selected shells.

2.3.12.4 Select by IDs > Bricks

View > Select by IDs > Bricks prompts you with a dialog box to select bricks by specifying a range of brick IDs.

Three selection modes are provided: “Select”, “Unselect”, “Reverse Select”. The “Select” mode will select bricks. The “Unselect” mode will unselect bricks. The “Reverse Select” mode will select the unselected bricks and unselect the selected bricks.

2.3.12.5 Select by IDs > Select All

View > Select by IDs > Select All selects all nodes and elements. You may use this command by pressing CTRL+A.

2.3.12.6 Select by IDs > Unselect All

View > Select by IDs > Unselect All unselects all nodes and elements. You may use this command by pressing ESC. If you are in the middle of another command such as zooming, press ESC twice to unselect all.

2.3.13 Select by Properties

The Select by Properties tools offer more ways to quickly select multiple entities.

2.3.13.1 Select by Properties > Materials

View > Select by Properties > Materials prompts you with the following dialog boxes (Figure 3.4). It allows you to select/unselect elements that use the specified materials.

Three selection modes are provided: “Select”, “Unselect”, “Reverse Select”. The “Select” mode will select elements. The “Unselect” mode will unselect elements. The “Reverse Select” mode will select the unselected elements and unselect the selected elements.




Figure 3.4

2.3.13.2 Select by Properties > Member Sections

View > Select by Properties > Member Sections prompts you with the following dialog box (Figure 3.5). It allows you to select/unselect members that use the specified sections.

Three selection modes are provided: “Select”, “Unselect”, “Reverse Select”. The “Select” mode will select elements. The “Unselect” mode will unselect elements. The “Reverse Select” mode will select the unselected elements and unselect the selected elements.




Figure 3.5

2.3.13.3 Select by Properties > Member Orientations

View > Select by Properties > Orientations prompts you with the following dialog box (Figure 3.6). It allows you to select/unselect members based on their orientations to the three global axes. For example, you may select/unselect all vertical columns by checking the global Y direction. The selection modes are similar to the ones used in previous sections and are not repeated here.




Figure 3.6

2.3.13.4 Select by Properties > Tension/Compression Only Members

View > Select by Properties > Tension/Compression Only Members allow you to select all tension-only or compression-only members.

2.3.13.5 Select by Properties > Shell Thicknesses

View > Select by Properties > Shell Thicknesses prompt you with the following dialog boxes (Figure 3.7). It is similar to the one used in View > Select by Properties > Member Sections. The Select by Properties > Shell Thicknesses applies to shells only. Three selection modes are similar to the ones used in the previous section and are not repeated here.




Figure 3.7

2.3.13.6 Select by Properties > Orphaned Nodes

View > Select by Properties > Orphaned Nodes selects all orphaned nodes.

2.3.13.7 Select by Properties > Coordinates

View > Select by Properties > Coordinates prompts you with the following dialog box (Figure 3.8). It allows you to select/unselect nodes and elements based on nodal coordinates. Nodes are selected/unselected if their coordinates are within the boundary of the minimum and maximum coordinates. Elements are selected/unselected if coordinates of their nodes are within the boundary of minimum and maximum coordinates. The selection modes are similar to the ones used in previous sections and are not repeated here.




Figure 3.8

2.3.13.8 Select by Properties > Selection Names

View > Select by Properties > Selection Names allows you to select/unselect nodes and elements based on saved named selections. You may assign (or save) named selections from the Geometry menu.




Figure 3.9

2.3.13.9 Select by Properties > Concrete Beam/Column/Plate Criteria

View > Select by Properties > Concrete Beam Criteria, Concrete Column Criteria and Concrete Plate Criteria allows you to select member or plate elements based on their design criteria.

2.3.13.10 Select by Properties > Steel Design Criteria

View > Select by Properties > Steel Design Criteria allows you to select members based on a steel design criteria.

2.3.13.11 Select by Properties > Select/Unselect All

View > Select by Properties > Select All and Unselect All are the same as in View > Select by IDs. They are provided here for convenience.

2.3.14 Flip Selection

View > Flip Selection inverts the selection statuses of all entities in the entire model. The nodes and elements currently selected will be unselected and vice versa.

2.3.15 Freeze Selected

View > Freeze Selected freezes or hides the selected nodes, elements and their dependents. The frozen nodes or elements are not displayed and are not modifiable unless the model integrity is at stake. This command allows you to focus on some particular parts of the model. For example, if you want to work on a particular floor of a three dimensional building, you may select the floor, flip the selection and freeze the selected elements.

2.3.16 Freeze All Except Level

View > Freeze All Except Level freezes or hides the all nodes, elements and their dependents except those on the specified level (Figure 3.10). This command provides a shortcut to the previous command when you would like to focus on elements of the model in a horizontal plan view. You must have levels defined (through menu Assign Properties > Levels) before running this command.



Figure 3.10

2.3.17 Freeze All Except Plane

View > Freeze All Except Plane freezes or hides all nodes, elements and their dependents except those on the specified plane (Figure 3.11). This command provides a shortcut to the previous command when you would like to focus on elements of the model in a plan view.



Figure 3.11

2.3.18 Thaw

View > Thaw allows you to thaw all frozen (hidden) nodes, elements and their dependents.

2.3.19 Load Diagram

View > Load Diagram prompts you with the following dialog box (Figure 3.12). It allows you to view loads of selected types in selected load cases. You may have the options to show load magnitudes or units. The line load intervals may vary between 1

and 16. An interval between 2 to 6 is recommended. Transparency may be set for non-area loads and area loads so you can see objects underneath the loads. The displayed loads may be deleted. The loads not displayed cannot be deleted unless their parent nodes or elements are deleted.




Figure 3.12

2.3.20 Annotate

View > Annotate prompts you with the above dialog box (Figure 3.13). It allows you to view annotations for nodes and elements and their properties. The element local axes may also be displayed using this command. Three annotation modes are available. You may annotate all entities, annotate selected entities, and erase existing annotations. For performance reasons, it is recommended that the annotations be applied only for objects of interest.




Figure 3.13

2.3.21 Query

View > Query lets you query extensive input and output information for a single node, member or finite element (Figure 3.14). For example, a node query will list node id, nodal coordinates and nodal loads. It will also list relevant support or nodal spring information. If there are analysis results, it will list nodal displacements, support or spring reactions as well.




Figure 3.14

2.3.22 Distance

View > Distance lets you click two locations and obtain the distance between the two coordinates.

2.3.23 Render

View > Render offers rendering controls.

2.3.23.1 Render > Render Options

View > Render > Render Options prompts you with the following dialog box (Figure 3.15). It allows you to turn on or off the shading of the surfaces of members, shells and bricks as though they were illuminated from multiple light sources. It provides a way for you to realistically visualize the image of the model. For shells, you have the option to render thickness as well as surface.

You have the option to apply different rendering percentages to different elements. Enter 100% for full rendering, 0% for no rendering, and anything in-between for partial rendering. The partial rendering (e.g. 50-80%) may be useful in identifying connectivity of elements to nodes.




Figure 3.15

Note: Rendering a model can be expensive in terms of memory and time usage by the program. You should turn off the rendering when it is not necessary.

2.3.23.2 Render > Quick Render

View > Render > Quick Render turns rendering on or off. You may use this command by pressing F8.

2.3.24 Result Diagrams

2.3.24.1 Result Diagrams > Shear and Moment Diagram

Analysis Results > Result Diagrams > Shear and Moment Diagram prompts you with the following dialog box (Figure 3.16).




Figure 3.16

It allows you to view the member shear (including axial force) diagram or moment (including torsion) diagram for the selected load combination. Only one shear or moment diagram for the selected load combination may be displayed per window. However, you may display different shear or moment diagrams in multiple windows. To open a new window, click Window > New Window.

You have the option to show values and units for the diagram. You may show diagrams on all members or on selected members only. You may also erase existing diagrams. By default, no diagram is displayed even if an analysis has been performed successfully.




Figure 3.17

2.3.24.2 Result Diagrams > Deflection Diagram

Analysis Results > Result Diagrams > Deflection Diagram prompts you with the following dialog box (Figure 3.18).




Figure 3.18

It allows you to view the deflected shape of the model for the selected load combination. The deflected shape is constructed by adding nodal displacements to nodal coordinates. For members, you have the option to show the local y and/or z

deflection as well. You need to adjust the displacement magnification to view the deflection properly. The deflection displayed is for the selected load combination only. However, you may display deflections for different load combinations in multiple windows. To open a new window, click Window > New Window. The deflection values and units may be shown for the member local deflections. You may choose to have shadows of the undeformed shape and deformed shape hidden. *You cannot perform mouse selection while the deflected shape is shown. However, you may open another window with the undeformed shape and perform mouse selection as usual.*




Figure 3.19

2.3.24.3 Result Diagrams > Contour Diagram

Analysis Results > Result Diagrams > Contour Diagram prompts you with the following dialog box (Figure 3.20). It allows you to view a result contour for shells and/or bricks for the selected load combination.

Four display modes are available. They are Iso-Surface and Value, Iso-Surface only, Value only, None or Erase. The Iso-Surface provides color bands for the contour component in different ranges. The number of ranges (or colors) may be either 16 or 8. Either top or bottom stresses may be specified for plate/shell elements. The Value (the absolute maximum) of the contour component may be shown for each element. The contour may be displayed in colors or gray scale. The latter is useful for people with color-impaired visions.

The contour components include:

- nodal displacements (D_x , D_y , D_z , D_{ox} , D_{oy} , and D_{oz})
- shell bending moments (M_{xx} , M_{yy} , M_{xy}) and shears (V_{xx} , V_{yy})

- shell membrane normal forces (F_{xx} , F_{yy}) and in-plane shears (F_{xy})
- shell and brick stresses (S_{xx} , S_{yy} , S_{zz} , S_{xy} , S_{xz} , S_{yz})
- surface spring reactions (SR_x , SR_y , SR_z)
- shell principal moments (M_{max} , M_{min}) and shear (V_{max})
- shell principal membrane forces (F_{max} , F_{min})
- principal stresses (S_1 , S_2 , S_3) for shells and bricks
- Von Mises stresses for shells and bricks




Figure 3.20

Only one contour component for the selected load combination may be displayed per window. However, you may display different contour components in multiple windows. To open a new window, click Window > New Window.

Four different modulations may be applied to values of the contour component. They are “Positive and Negative”, “Absolute”, “Positive Only”, “Negative Only”. For example, you may choose the contour component “Mxx” and the modulation “Negative Only” to view only the negative moments Mxx of the plates.

The following figure (Figure 9.6) shows a displacement (D_z) contour for a plate, with display mode “Iso-Surface and Values” and value modulation of “Positive and Negative”.




Figure 3.21

2.3.24.4 Result Diagrams > Unity Check

Analysis Results > Result Diagrams > Unity Check toggles on and off the colored codes for concrete and steel beam-column unity check results. The colors are coded according to the following:

- Blue if design is safe
- Red if design is not safe.

2.3.24.5 Result Diagrams > Response Animation

Analysis Results > Result Diagrams > Response Animation toggles on or off structural responses (such as deflection, moment shear diagrams or stress contours) animation. Animation parameters may be set in Settings > Preferences.

2.3.25 Options

2.3.25.1 Options > Drawing Grid

View > Options > Drawing Grid shows or hides the drawing grid. You may set up the grid by using the command Geometry > Drawing Grid. The grid coordinates are shown in the status bar while the mouse is moving in the model view. You may use this command by pressing F7.

2.3.25.2 Options > Global Axes

View > Options > Global Axes shows or hides the legend of the global axes in the bottom-left corner of the window. You may use this command by pressing F5.

2.3.25.3 Options > Contour Legend

View > Options > Contour Legend shows or hides the contour legend. The results must exist for the contour legend to be displayed.

2.3.25.4 Options > Comment

View > Options > Comment allows you to insert a comment at a specified location (Figure 3.23). The comment must be less than 256 characters in length. To remove an existing comment, go to Tables > Comments and delete the comment entry.




Figure 3.23

2.4 Geometry

The Geometry menu provides commands to draw individual nodes and elements based on a drawing grid or existing nodes and parametrically generate models of regular shape.

2.4.1 Materials

Geometry > Materials prompts you with the following dialog box (Figure 4.1). It allows you to define and/or assign materials to selected elements in the model. An Id is assigned automatically to each material by the program and may not be changed. You may assign a label with 127 maximum characters to each material for easy identification. The material properties include:

- Young's modulus (E),
- Poisson ratio ($0 \leq \nu < 0.5$),
- Weight density,
- Temperature coefficients.

The shear modulus (G) is calculated automatically.

These material properties are used in the structural analysis of the model. Material properties related to design may be set from design menus. For example, concrete strength f'_c and reinforcement strengths f_y and f_{ys} may be defined from RC Design > Design Criteria > RC Materials.

You may add standard steel and concrete materials by clicking the "Std Materials" button. A standard material label starts with "Steel" or "Concrete".

You may add one or more materials by clicking the "New Rows" button. You may also print all materials in the list by clicking the "Print" button. The "Assign active material to currently selected elements" checkbox may be used to assign the active material to selected elements. The active material refers to the one that currently has focus in the list in the dialog box. In order for material assignments to take place, members, shells or bricks must be selected beforehand.

*A more flexible way to assign material and other properties to entities is to use **Assign > Member Properties** or **Assign > Shell Properties** command, which allows you to continuously assign one or more properties to entities.*

The program always has a default material labeled "Default". You may not delete this material or change its label. You may, however, change its properties.




Figure 4.1

2.4.2 Member Sections

Geometry > Member Sections prompts you with the following dialog box (Figure 4.2). It allows you to define and/or assign sections to selected members in the model. An Id is assigned automatically to each section by the program and may not be changed. You may assign a label with 127 maximum characters to each section for easy identification. The section properties include:

- moment of inertia about major axis (I_z)
- moment of inertia about minor axis (I_y)
- torsional moment of inertia (J)
- section area (A)
- shear area in the local y direction (A_y)
- shear area in the local z direction (A_z).

These properties are used in the analysis. Other properties (B , H , T_f and T_w) are dimensions for regular sections such as rectangular, circular, wide flange sections. These dimensional properties are used for graphic rendering only (not used in analysis).

You may add one or more sections by clicking the “New Rows” button. You may also print all sections in the list by clicking the “Print” button. The “Assign active section to currently selected members” checkbox may be used to assign the active section to selected members. The active section refers to the one that currently has focus in the list in the dialog box. In order for section assignments to take place, members must be selected beforehand.

*A more flexible way to assign member properties is to use **Assign > Member Properties** command, which allows you to continuously assign one or more properties to members.*

Note: The section property input does not include I_{xy} – the product of inertia. For a section where I_{xy} is not zero such as an angle, the principal axes of a cross section are different from its geometric axes. In such situations, you should enter section properties in its principal axes and adjust the member element local angle accordingly.

Section Id	Label	I_z [in ⁴]	I_y [in ⁴]	J [in ⁴]	A [in ²]	A_y [in ²]	A_z [in ²]	b [in]	d [in]	I_f [in]	t_w [in]
1	Default	1	1	1	1	1	1	0	0	0	0
2	W27x84	2850	106	2.81	24.8	12.282	12.7488	9.96	26.7	0.64	0.46
3	W10x45	248	53.4	1.51	13.3	3.535	9.9448	8.02	10.1	0.62	0.35

Buttons: New Rows, Regular Section..., AISC Table..., NDS Table..., Rigid Link, Print..., Save..., Assign active section to currently selected members, Apply, Cancel

Figure 4.2

You may add a regular section by clicking the “Regular Section” button. The program displays the following dialog box (Figure 4.3). Three regular sections are currently

provided by the program, namely rectangular, circular, wide flange and Tee sections. The properties of these sections are calculated automatically.




Figure 4.3

AISC (14th Edition) Steel Shapes

Shape: W Print... Save... OK Cancel

	Shape	A [in ²]	d [in]	tw [in]	bf [in]	tf [in]	Ix [in ⁴]	Sx [in ³]	rx [in]	Zx [in ⁴]	Iy [in ⁴]	Sy [in ³]	ry [in]	Zy [in ⁴]	J [in ⁴]
1	W44x335	98.5	44	1.03	15.9	1.77	31100	1410	17.8	1620	1200	150	3.49	236	74.7
2	W44x290	85.4	43.6	0.865	15.8	1.58	27000	1240	17.8	1410	1040	132	3.49	205	50.9
3	W44x262	77.2	43.3	0.785	15.8	1.42	24100	1110	17.7	1270	923	117	3.47	182	37.3
4	W44x230	67.8	42.9	0.71	15.8	1.22	20800	971	17.5	1100	796	101	3.43	157	24.9
5	W40x593	174	43	1.79	16.7	3.23	50400	2340	17	2760	2520	302	3.8	481	445
6	W40x503	148	42.1	1.54	16.4	2.76	41600	1980	16.8	2320	2040	249	3.72	394	277
7	W40x431	127	41.3	1.34	16.2	2.36	34800	1690	16.6	1960	1690	208	3.65	328	177
8	W40x397	117	41	1.22	16.1	2.2	32000	1560	16.6	1800	1540	191	3.64	300	142
9	W40x372	110	40.6	1.16	16.1	2.05	29600	1460	16.5	1680	1420	177	3.6	277	116
10	W40x362	106	40.6	1.12	16	2.01	28900	1420	16.5	1640	1380	173	3.6	270	109
11	W40x324	95.3	40.2	1	15.9	1.81	25600	1280	16.4	1460	1220	153	3.58	239	79.4
12	W40x297	87.3	39.8	0.93	15.8	1.65	23200	1170	16.3	1330	1090	138	3.54	215	61.2
13	W40x277	81.5	39.7	0.83	15.8	1.58	21900	1100	16.4	1250	1040	132	3.58	204	51.5
14	W40x249	73.5	39.4	0.75	15.8	1.42	19600	993	16.3	1120	926	118	3.55	182	38.1
15	W40x215	63.5	39	0.65	15.8	1.22	16700	859	16.2	964	803	101	3.54	156	24.8
16	W40x199	58.8	38.7	0.65	15.8	1.07	14900	770	16	869	695	88.2	3.45	137	18.3
17	W40x192	116	41.6	1.42	12.4	2.52	29900	1440	16.1	1710	803	130	2.64	212	172
18	W40x182	97.7	40.8	1.22	12.2	2.13	24700	1210	15.9	1430	644	106	2.57	172	105
19	W40x177	95.9	40.8	1.18	12.1	2.13	24500	1200	16	1410	640	105	2.58	170	103
20	W40x169	86.2	40.4	1.06	12	1.93	21900	1080	15.9	1270	562	93.5	2.55	150	76.6
21	W40x162	82.3	40.2	1.03	12	1.81	20500	1020	15.8	1190	521	87.1	2.52	140	65

Figure 4.4

You may also add sections from the AISC steel shape table (Figure 4.4) or NDS wood shape table. *You should not modify an AISC or NDS shape label or its properties.*

You may create one and only one rigid link section for use in the model by simply click “Rigid Link” button. A rigid link is a member that has very large sectional properties (A, A_y , A_z , I_z , I_y and J). There can only be one rigid link section defined in the model and it must be named as “RIGID_LINK”. The properties for the RIGID_LINK section must be set to 0’s on the member section dialog box. The program will appropriately calculate A, A_y , A_z , I_z , I_y and J during the solution process. **Self weight for rigid links will be ignored by the program.**

The program always has a default section labeled “Default”. You may not delete this section or change its label. You may, however, change its properties.

2.4.3 Shell Thicknesses

Geometry > Shell Thicknesses prompts you with the following dialog box (Figure 4.5). It allows you to define and/or assign thicknesses to selected shells in the model. An Id is assigned automatically to each thickness by the program and may not be changed. You may assign a label with 127 maximum characters to each thickness for easy identification. The thickness properties include thickness only.




Figure 4.5

You may add one or more thicknesses by clicking the “New Rows” button. You may also print all thicknesses in the list by clicking the “Print” button. The “Assign active thickness to currently selected shells” checkbox may be used to assign the active thickness to selected shells. The active thickness refers to the one that currently has focus in the list in the dialog box. In order for thickness assignments to take place, shells must be selected beforehand.

*A more flexible way to assign shell properties is to use **Assign > Shell Properties** command, which allows you to continuously assign one or more properties to shells.*

The program always has a default thickness labeled “Default”. You may not delete this thickness or change its label. You may, however, change its properties.

2.4.4 Levels

Geometry > Levels prompts you with the following dialog box (Figure 4.6). It allows you to define physical levels in the model. Once levels are defined, you are able to view a level plan by using the command View > Freeze All Except Level. To unfreeze the frozen parts of the model, click View > Thaw.




Figure 4.6

2.4.5 Drawing Grid

Geometry > Drawing Grid prompts you with the following dialog box (Figure 4.7). It allows you to generate a 1D, 2D or 3D rectangular grid for drawing or guidance. The distance list is a comma separated list that specifies multiple distances. For example, a distance list of “12, 2@14, 3@10” will generate distances of 12, 14, 14, 10, 10 and 10 in length units. You may specify a distance list for the X, Y, or Z direction or any combination of them.




Figure 4.7

You may specify an insertion point to translate and rotation parameters to rotate the grid. The drawing grid may be turned on or off by running the command View > Options > Drawing Grid or by simply pressing F7. You may regard the grid as a user defined coordinate system that can be changed at any time. The coordinates of the grid intersection under the mouse are displayed in the status bar. It helps you to identify correct points when drawing nodes or elements. The following example (Figure 4.8) shows the use of this command.




Figure 4.8

2.4.6 Object Snap

The Geometry > Object Snap pop-up menu provides options to snap node locations at $1/2$, $1/3$, ... $1/9^{\text{th}}$ points on a member under the mouse cursor. If you are drawing elements, you also have the option to snap to the perpendicular point on a member from the last point. It is a good idea to turn off the drawing grid (by pressing F7) to avoid snapping to grid points while any of the snap options is on.




Figure 4.9

2.4.7 Draw Node

Geometry > Draw Node allows you to draw new nodes in the model. To draw a node, simply move the mouse, point to an intersection of the grid and click the left mouse button. You may also draw a node by entering nodal X, Y, and Z (optional) coordinates in the command window via the keyboard. This is very useful if you need to draw nodes outside the grid interactions. The command remains in effect until another command is selected, the right mouse button is clicked, or ESC is pressed.

2.4.8 Draw Member

Geometry > Draw Member allows you to draw new members in the model. To draw a member, simply move the mouse and click the left mouse button from point to point (Figure 4.10). The clicked points must be intersections on the grid or existing nodes. These points become the element nodes. New nodes are created if necessary. Members are drawn continuously. Right clicking the mouse once lets you start drawing members from a new location. *Remember, the start and end nodes determine the default local coordinate system.* The members drawn have the current section and material properties. You may use the commands in the Geometry menu to assign appropriate properties to them.




Figure 4.10

You may also specify a node by entering nodal X, Y and Z (optional) coordinates in the command window via the keyboard. This is very useful if you need to specify nodes outside the grid intersections. In addition, you may specify a node by entering an existing node number directly. You can combine the use of keyboard and mouse to draw members.

You may turn on annotations for nodes and members while drawing. To do that, click View > Annotate. The command remains in effect until another command is selected, the right mouse button is clicked twice, or ESC is pressed.




Figure 4.11

2.4.9 Draw Shell

Geometry > Draw Shell allows you to draw new shells in the model. To draw a shell, simply move the mouse and click the left mouse button from point to point (Figure 4.10). The clicked points must be intersections on the grid or existing nodes. These points become the element nodes. New nodes are created if necessary. *Remember, the order of clicked points determines the default local coordinate system.* The shells drawn have the current thickness and material properties. You may use the commands in the Geometry menu to assign appropriate properties to them.

You may also specify a node by entering nodal X, Y, and Z (optional) coordinates in the command window via the keyboard. This is very useful if you need to specify nodes outside the grid interactions. In addition, you may specify a node by entering an existing node number directly. You can combine the use of keyboard and mouse to draw shells.

You may turn on annotations for nodes and shells while drawing. To do that, click View > Annotate. The command remains in effect until another command is selected, the right mouse button is clicked, or ESC is pressed.

2.4.10 Draw Brick

Geometry > Draw Brick allows you to draw new bricks in the model. To draw a brick, simply move the mouse and click the left mouse button from point to point (Figure 4.11). The grid must be set up in 3 dimensions. The clicked points must be intersections on the grid or existing nodes. These points become the element nodes. New nodes are created if necessary. Remember, the order of clicked points must be such that the vector of the surface 1-2-3-4 points to the surface 5-6-7-8. The bricks drawn have the current material properties. You may use the commands in the Geometry menu to assign appropriate properties to them.

You may also specify a node by entering nodal X, Y, and Z coordinates in the command window via the keyboard. This is very useful if you need to specify nodes outside the grid interactions. In addition, you may specify a node by entering an existing node number directly. You can combine the use of keyboard and mouse to draw bricks.

You may turn on annotations for nodes and bricks while drawing. To do that, click View > Annotate. The command remains in effect until another command is selected, the right mouse button is clicked, or ESC is pressed.




Figure 4.11

It is generally not easy to draw bricks in 3 dimensions due to visualization difficulty. You may generate bricks based on shells using the commands such as Edit > Extrude or Revolve. You may also use spreadsheets to input nodes and bricks by running Input Data > Nodes or Bricks.

2.4.11 Generate

The Geometry > Generate pop-up menu provides commands to quickly generate commonly used structural components in a model. These commands may be used multiple times to generate different parts in the model.

2.4.11.1 Generate > Nodes from Grid

Geometry > Generate > Nodes from Grid will convert all grid points to nodes in one sweep. You may use this command as many times as you like. You must merge nodes manually if necessary. The generated nodes may then be used to generate members, shells, or bricks using the following three commands.

2.4.11.2 Generate > Members by Nodes

Geometry > Generate > Members by Nodes allows you to quickly generate new members based on selected base members and existing nodes. New members are skipped if no valid nodes exist. The following five figures (Figure 4.12 - 4.16) show how this command may be used.




Figure 4.12

Given one selected member and existing nodes in Figure 4.12 and using the input in Figure 4.13, 10 new members in Figure 4.14 are generated.




Figure 4.13




Figure 4.14

By selecting all 11 members in Figure 4.14 and using the input in Figure 4.15, 33 more members are generated in Figure 4.16.




Figure 4.15




Figure 4.16

2.4.11.3 Generate > Shells by Nodes

Geometry > Generate > Shells by Nodes allows you to quickly generate new shells based on selected base shells and existing nodes. New shells are skipped if no valid nodes exist. The concept in this command is similar to Generate > Members by Nodes.

2.4.11.4 Generate > Bricks by Nodes

Geometry > Generate > Bricks by Nodes allows you to quickly generate new bricks based on selected base bricks and existing nodes. New bricks are skipped if no valid nodes exist. The concept in this command is similar to Generate > Members by Nodes.

2.4.11.5 Generate > Non-Prismatic Members

Geometry > Generate > Non-Prismatic Members prompts you with the following dialog box (Figure 4.17). It allows you to quickly convert each of the selected prismatic members into multiple prismatic members to approximate a non-prismatic member. The distance list is a comma separated list that specifies multiple distances. For example, a distance list of “12, 2@14, 3@10” will generate distances of 12, 14, 14, 10, 10 and 10 in length units. The lengths of the selected prismatic members must be consistent with the distance list.




Figure 4.18

The left and right haunches of the non-prismatic members may be of type linear, parabolic or straight. You must define the geometry (Figure 4.7) including middle depth (DM), left depth (DL), right depth (DR), width, left length ratio (LL / L), right length ratio (LR / L). Each of the selected prismatic members will be exploded into multiple prismatic members to approximate the non-prismatic member’s behavior.

Appropriate member sections will be automatically added and assigned in the model. Existing loads on the selected prismatic members will be assigned to the new members appropriately.




Figure 4.19

2.4.11.6 Generate > Arc Members

Geometry > Generate > Arc Members prompts you with the following dialog box (Figure 4.20). It allows you to quickly generate members along an arc. You may specify an arc radius, the start and end angles, and the number of segments. You may specify an insertion point to translate and rotation parameters to rotate the generate shells. The generated members have the default section and material properties. You may assign them appropriate properties using commands in the Assign Properties menu.




Figure 4.20

The following example (Figure 4.21) shows members generated along an arc using the input from Figure 4.20.





Figure 4.21

2.4.11.7 Generate > Circular Shells

Geometry > Generate > Circular Shells prompts you with the following dialog box (Figure 4.22). It allows you to quickly generate shells in a circle. You may specify the number of segments to control the fineness of the mesh. Generally speaking, a relatively fine mesh is recommended to minimize the discretization error along the curved edge. The generated shells are mostly rectangular in shape, with some general quadrilaterals along the edge. You should not use rectangular thin plate formulation in the analysis. You may specify an insertion point to translate and rotation parameters to rotate the generated shells. The generated shells have the default thickness and material properties. You may assign them appropriate properties using commands in the Assign Properties menu.



The dialog box is titled "Generate Shell Elements in a Circle" and features a close button (X) in the top right corner. It contains the following fields and options:

- Radius: 10 in
- Segments: 10
- Insertion Point Coordinates:
 - X: 0 in
 - Y: 0 in
 - Z: 0 in
- Rotation:
 - About: Global Z (dropdown)
 - Angle: 0 deg
- Supports along the edge: Pinned (dropdown)
- Buttons: OK and Cancel

Figure 4.22

The following example (Figure 4.23) shows shells generated in a circle using the input from Figure 4.22.




Figure 4.23

2.4.11.8 Generate > Rectangular Shells

Geometry > Generate > Rectangular Shells prompts you with the following dialog box (Figure 4.24). It allows you to quickly generate shells in a rectangle. The distance list is a comma separated list that specifies multiple distances. For example, a distance list of "12,2@14,3@10" will generate distances of 12, 14, 14, 10, 10 and 10 in length units. You may specify an insertion point to translate and rotation parameters to rotate the generated shells. The generated shells have the default thickness and material properties. You may assign them appropriate properties using commands in the Assign Properties menu.

Generate Shell Elements in a Rectangle

Enter distance lists for each direction (e.g. 12, 3@20, 2@15).

X Direction: 10@0.2 in

Y Direction: 10@0.2 in

Insertion Point Coordinates

X: 0 in

Y: 0 in

Z: 0 in

Rotation

About: Global Z

Angle: 0 deg

OK Cancel

Figure 4.24

This command can only generate shells in a rectangle. To generate shells in a general quadrilateral, you may first define one quadrilateral shell and then use the command Edit > Sub-Mesh Shells to sub-divide it.

The following example (Figure 4.25) shows a 10x10 rectangular mesh of shells generated using the input from Figure 4.24.




Figure 4.25

2.4.11.9 Generate > Cylindrical Frames

Geometry > Generate > Cylindrical Frames prompts you with the following dialog box (Figure 4.26). It allows you to quickly generate 2D or 3D cylindrical frames. The distance list is a comma separated list that specifies multiple distances. For example, a distance list of "12, 2@14, 3@10" will generate distances of 12, 14, 14, 10, 10 and 10 in length unit. You may leave the Y direction distance list empty, in which case, a plane cylindrical frame will be generated. You may specify pinned or fixed supports at the bottom. The generated members have the default section and material properties. You may assign them appropriate properties using commands in the Assign menu.




Figure 4.26

You have the option not to generate members. In this way, you can generate nodes on cylindrical system first. Then you may use the command `Generate > Shells (Bricks) by Nodes` to generate a system of shell (brick) elements.

Using the input in Figure 4.26, a 3D cylindrical frame in Figure 4.27 is generated. You may need to set the element local angles for columns for correct orientation.




Figure 4.27

2.4.11.10 Generate > Rectangular Frames

Geometry > Generate > Rectangular Frames prompts you with the following dialog box (Figure 4.28). It allows you to quickly generate 1D frames (continuous beams), 2D frames (plane frame or grillage) or 3D frames (space frames). The distance list is a comma separated list that specifies multiple distances. For example, a distance list of “12, 2@14, 3@10” will generate distances of 12, 14, 14, 10, 10 and 10 in length unit. You may leave appropriate distance list(s) blank to generate on a plane or along a line. You may specify pinned or fixed supports at the bottom. The generated members have the default section and material properties. You may assign them appropriate properties using commands in the Assign Properties menu.

Generate Rectangular Frame X

Enter distance lists for each direction (e.g. 12, 3@20, 2@15). Leave appropriate box(s) blank to generate on a plane or along a line.

X Direction: in

Y Direction: in

Z Direction: in

Insertion Point Coordinates	Rotation
X: <input style="width: 50px;" type="text" value="0"/> in	About: <input style="width: 100px;" type="text" value="Global Z"/> ▼
Y: <input style="width: 50px;" type="text" value="0"/> in	Angle: <input style="width: 50px;" type="text" value="0"/> deg
Z: <input style="width: 50px;" type="text" value="0"/> in	

Supports at bottom: ▼

Figure 4.28

The following three examples show the uses of this command. The first example (Figure 4.29) is a continuous beam in the X direction generated using the input from the dialog box above. The first two spans are of 10 ft and the last three spans are of 15 ft. The pinned supports are also generated automatically.



Figure 4.29

The second example (Figure 4.30) is a 2D frame on the XY plane with horizontal spans 10, 10, 18, 10, 10 ft and vertical spans 15, 8, 8, 8 ft as shown in the following.



Figure 4.30

A rectangular frame is first generated using the input from the following dialog box (Figure 4.31).

Generate Rectangular Frame ×

Enter distance lists for each direction (e.g. 12, 3@20, 2@15). Leave appropriate box(s) blank to generate on a plane or along a line.

X Direction: in

Y Direction: in

Z Direction: in

Insertion Point Coordinates	Rotation
X: <input type="text" value="0"/> in	About: <input type="text" value="Global Z"/> ▾
Y: <input type="text" value="0"/> in	Angle: <input type="text" value="0"/> deg
Z: <input type="text" value="0"/> in	

Supports at bottom: ▾

Figure 4.31

The frame is then modified by selecting and deleting nodes 19, 24, 25, 26, 29, 30 and horizontal members at the bottom (Figure 4.32). Notice when a node is deleted, elements (and their dependents such as loads) connected to that node are automatically deleted also.




Figure 4.32

The third example (Figure 4.33) is a 3D frame with 6 spans in the X direction, 4 spans in the Z direction, and 10 spans in the Y direction. All spans are 10 ft. The frame is fixed at the bottom.




Figure 4.33

It is generated using the input from Figure 4.34.




Figure 4.34

2.4.12 Element Local Angle

Geometry > Element Local Angle prompts you with a dialog box (Figure 4.35) to assign local angles to the selected members and/or shells. The element local angle is used to change the element local coordinate system.




Figure 4.35

2.4.13 3-Point Member Orientation

Geometry > 3-Point Member Orientation prompts you with a dialog box to specify an X, Y, and Z coordinate. The orientation of selected members will be changed so the local z-axis of all selected members is perpendicular to the plane formed by the two member end coordinates and the specified X, Y, Z coordinate.

2.4.14 Moment Releases

Geometry > Moment Releases prompts you with the following dialog box (Figure 4.36). It allows you to assign moment releases to selected members in the model. Major or minor moment releases may be applied to the start and/or end ends of the members. Trusses are members with moments fully released at both ends. The program assigns appropriate moment releases automatically if the model type is of “2D Truss” or “3D Truss”. However, if the model contains both trusses and beams, you should use the model type “2D Frame” or “3D Frame”, and assign appropriate moment releases to members. In order for moment release assignments to take place, members must be selected beforehand.




Figure 4.36

2.4.15 Rigid Offset

Geometry > Rigid Offset prompts you with the above dialog box (Figure 4.37). It allows you to assign rigid offsets to the selected members. This command will effectively break each selected member into two or three members, with either or both ends being rigid links.




Figure 4.37

2.4.16 Tension/Compression Only

Geometry > Tension/Compression Only prompts you with the above dialog box (Figure 4.38). It allows you to assign nonlinearity (linear, tension only or compression only) to the selected members. The member stiffness will be ignored if a tension only member is subjected to compressive forces or if a compression only member is subjected to tensile forces. The presence of tension only or compression only members makes the model nonlinear and requires iterative solution for each load combination.




Figure 4.38

2.4.17 Convert Members to Rigid Links

Geometry > Convert Members to Rigid Links will convert selected members to rigid links.

2.4.18 Element Activation

Geometry > Element Activation allows members, shells, and/or bricks to be selectively activated or deactivated.

This allows these modeling entities to remain in the model while studying the effects of ignoring their structural contributions to the model.

2.4.19 Supports

2.4.19.1 Support

Geometry > Supports > Support prompts you with the following dialog (Figure 4.39).

It allows you to assign supports (rigid boundary conditions) to selected nodes in the model. One or more of the six global degrees of freedom (DOFs) may be restrained. In addition, you may specify enforced displacements in the restrained DOFs. The enforced displacements may be used to model support settlements. You may regard them as special loads. For normal supports, enforced displacements in the restrained DOFs are zero. The program provides three commonly used supports, namely, pinned, fixed and roller. In order for support assignments to take place, nodes must be selected beforehand.

After clicking “Assign”, you can start to *continuously* assign supports by window-selecting nodes until you right click the mouse or press the ESC key.




Figure 4.39

2.4.19.2 Inclined Roller

Geometry > Multi-DOF Constraints > Inclined Rollers prompts you with the following dialog box (Figure 4.40). It allows you to define an inclined roller support on XY, YZ or XZ plane. An inclined roller can only move along the line between the reference point (defined in the dialog) and the support location. For example in Figure 4.44, the roller is located at coordinate (8.0, 5.0, 0) and is inclined 30 degrees from the X-axis. We can use the reference point $(8.0 + 10 * \cos30, 5 + 10 * \sin30, 0) = (16.666, 10, 0)$ to constrain the support. An inclined roller is a type of multi-DOF constraint.

A regular support and multi-DOF constraints may be applied on the same node as long as the support/constrained directions do not interfere with each other.

Multi-DOF constraint forces and moments are listed separately from the regular support reactions in the analysis results.




Figure 4.40




Figure 4.41

Geometry > Supports > Inclined Rollers prompts you with the following dialog box (Figure 4.41). It allows you to define a reference point. When applied to selected nodes, the inclined roller can only move along a line between the reference point and the support location.

2.4.20 Springs

Geometry > Springs prompts you with the following dialog (Figure 4.42).




Figure 4.42

It allows you to assign nodal, line, and surface springs (flexible boundary conditions) to selected nodes, members, or shells in the model (Figure 4.43). A nodal spring may be restrained in one or more of the six global DOFs (D_x , D_y , D_z , D_{ox} , D_{oy} and D_{oz}).

A line or surface spring may be restrained in one or more of the three global translational DOFs (D_x , D_y and D_z). To qualify to be a valid flexible restraint, the corresponding spring constant must be specified.




Figure 4.43

A restraint may be designated as linear, compression-only or tension only. A compression-only restraint is active only when the nodal displacement in the restrained direction is negative. A tension-only restraint is active only when the nodal displacement in the restrained direction is positive. The presence of tension only or compression only springs makes the model nonlinear and requires iterative solution for each load combination.

After clicking “Assign”, you can start to *continuously* assign nodal, line or surface springs by window-selecting nodes, members or shells until you right click the mouse or press the ESC key.

2.4.21 Diaphragms

Geometry > Diaphragms prompts you with the following dialog box (Figure 4.44). It allows you to define regular or generic rigid diaphragms (in-plane) in a 3D model. For example, to model horizontal concrete floors, you may select one node on each floor and apply regular diaphragms to the selected nodes in XZ plane (with normal in the global Y direction). Instead of using plate elements, rigid diaphragms allow you to model stiff in-plane actions quickly. The program further provides the option to ignore the rigid diaphragm actions as an analysis option (Analyze > Analysis Options).




Figure 4.44

2.4.22 Master-Slave

2.4.22.1 Master-Slave

Geometry > Master-Slave > Master-Slave (Figure 4.45) prompts you with the following dialog box (Figure 4.45). It allows you to define a generic constraint at one or two nodes. An equal displacement constraint is one type of multi-DOF constraint.

A regular support and multi-DOF constraints may be applied on the same node as long as the support/constrained directions do not interfere with each other.

Multi-DOF constraint forces and moments are listed separately from the regular support reactions in the analysis results.




Figure 4.45

2.4.22.2 Generic Displacement Constraint

Geometry > Master-Slave > Generic Constraints (Figure 4.46) prompts you with the following dialog box (Figure 4.46). It allows you to define a generic constraint at one or two nodes. If the constraint is applied to the same node, the constraint DOFs must be different. Constrained DOFs must be compatible: Q1 and Q2 must be both translational or rotational. Constraint factors must be non-zero.

A regular support and multi-DOF constraints may be applied on the same node as long as the support/constrained directions do not interfere with each other.

Multi-DOF constraint forces and moments are listed separately from the regular support reactions in the analysis results.




Figure 4.46

2.4.23 Story Drift Nodes

Geometry > Story Drift Nodes prompts you with the following dialog box (Figure 4.47). It allows you to enter nodes that will be used for floor drift calculation.

An empty row is allowed if all rows below it do not contain any non-empty fields. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 4.47

2.5 Loads

The Loads menu provides commands to define load cases and combinations, and assign loads of various types to selected nodes and elements.

2.5.1 Load Cases

Loads > Load Cases prompts you with the following dialog box (Figure 5.1). It allows you to define load cases to be used for loads and load combinations. A number is assigned to each load case automatically by the program. You may assign a label with 127 maximum characters to each load case for easy identification. Duplicate

labels in load cases are not allowed. A load type specifies the characteristics of the load case. Examples are DEAD, LIVE, WIND, EARTHQUAKE. They are used to generate standard load combinations in Loads > Load Combinations.




Figure 5.1

You may add one or more load cases by clicking the “New Rows” button. You may also print all load cases in the list by clicking the “Print” button.

The program always has a default load case labeled “Default”. You may not delete this load case or change its label. You may however change its type.

2.5.2 Load Combinations

Loads > Load Combinations prompts you with the following dialog box (Figure 5.2). It allows you to define combinations of existing load cases in the model. The program solves for load combinations but not for load cases. You may assign a label with 127 maximum characters to each load combination for easy identification. Duplicate labels in load combinations are not allowed.

You may add one load combination by clicking the “Add” button. You may then define the new load combination in the following dialog box (Figure 5.3). The definition includes a label with 127 maximum characters, a load factor for each load case, and a P-Delta flag. A load factor of zero excludes the respective load case from participating in the load combination. You may print all load cases and their corresponding load factors in the list by clicking the “Print” button.

If you need to design concrete beams, columns and/or plates, check or uncheck “Perform Concrete Design using this Load Combination”. In addition, a sustained load factor must also be entered. This is the load factor that applies to the sustained load cases included in this load combination. It is used to compute the infamously during concrete column design. Therefore, if there are concrete columns to be designed, you should define a separate load combination that contains only sustained load cases (each case with a unit factor). You can then designate this load combination as the sustained load combination by RC Design > Design Options before performing concrete design.

If you need to design steel members, check or uncheck “Perform Steel Design using this Load Combination”. If you need to use the load combination to check total or live load deflection, check or uncheck appropriate boxes.

You may modify, copy, or delete a load combination by clicking the “Modify”, “Copy”, or “Delete” button. You may also create a load combination for every load case with a unit load factor for the load case but zeros for the rest of the load cases. To do that, click the “Unit Cases” button.

You may also generate standard load combinations based on design codes such as ACI 318-02/05/08/11 by clicking the button “Generate Std”.

There must be at least one load combination in a model.




Figure 5.2




Figure 5.3

2.5.3 Nodal Loads

Loads > Nodal Loads prompts you with the following dialog box (Figure 5.4). It allows you to assign nodal loads to selected nodes in the model. You must select a load case to which the nodal loads belong. Nodal loads are specified in the global coordinate system. The loads are nodal forces in the X, Y, or Z direction if radio button “X”, “Y”, or “Z” is selected. The loads are nodal moments in the X, Y, or Z direction if radio button “OX”, “OY”, or “OZ” is selected. The load magnitude may be any non-zero value.




Figure 5.4

2.5.4 Point Loads

Loads > Point Loads prompts you with the above dialog box (Figure 5.5). It allows you to assign point loads to selected members in the model. You must select a load case to which the point loads belong. Point loads may be specified in either the local or global coordinate system. The loads are point forces in the X, Y, or Z direction if radio button “X”, “Y”, or “Z” is selected. The loads are point moments in the X, Y, or Z direction if radio button “OX”, “OY”, or “OZ” is selected. The load magnitude may be any non-zero value. The load distance is the ratio of the load location (measured from the member start) to the member length. A distance of 0.5 places the load at the middle of each selected member.




Figure 5.5

2.5.5 Line Loads

Loads > Line Loads prompts you with the following dialog box (Figure 5.6). It allows you to assign line loads to selected members in the model. You must select a load case to which the line loads belong. Line loads may be specified in either the local or global coordinate system. The loads are line forces in the X, Y, or Z direction. The start and end magnitudes of the load may be zero for either end but not for both. The load distances are the ratios of the load start and end locations (measured from the member start) to the member length. A start distance of 0.0 and an end distance of 1.0 place the line load on the entire span of each selected member.

The screenshot shows the 'Line Load' dialog box. It features a title bar with a close button. The main content area includes a 'Load Case' dropdown menu currently set to '1: Default'. Below this, there are two sections: 'Direction' with radio buttons for X, Y (selected), and Z; and 'Coordinate System' with radio buttons for Local (selected) and Global. At the bottom, there are input fields for 'Start' (-2) and 'End' (-3) with the unit 'kip/ft', and 'Distances' (0 and 1) with the unit 'x100 % length from member start'. There are two buttons at the bottom: 'Apply to Selected Members' and 'Cancel'.

Figure 5.6

2.5.6 Area Loads

Loads > Area Loads prompts you with the following dialog box (Figure 5.7). It allows you to assign area loads to enclosed areas of members in the model. You must select a load case to which the area loads belong. Area loads may be specified in either the local or global coordinate system. Global area loads may be in the global X, Y, or Z direction. Local area loads may only be in the local z direction, which is perpendicular to the load area.

A load area is defined by specifying three or four coplanar nodes. The area load is then distributed as line loads to perimeter members of enclosed areas within the load area prior to static or dynamic solution. Various area load distribution methods are available. It is recommended that area loads be defined in their own load cases. In this way, you will find it easier to identify, edit, and delete area loads later on.

The program also allows you to convert area loads to line loads automatically. This feature lets you see how the program would convert the area loads prior to the solution. For more information on the load conversion, see Input Data > Area Loads.




Figure 5.7

2.5.7 Surface Loads

Loads > Surface Loads prompts you with the following dialog box (Figure 5.8). It allows you to assign surface loads to selected shells in the model. You must select a load case to which the surface loads belong. Surface loads may be specified in either the local or global coordinate system. The loads are surface forces in the X, Y, or Z direction. Surface load applies to the entire surface of a shell element.




Figure 5.8

2.5.8 Thermal Loads

Loads > Thermal Loads prompts you with the following dialog box (Figure 5.9). It allows you to assign thermal loads to selected elements in the model. You must select a load case to which the surface loads belong. Currently, ENERCALC 3D considers thermal effect in longitudinal direction of members, membrane directions of shells, and bricks. It does not consider thermal gradients in members or shells.




Figure 5.9

2.5.9 Self Weights

Loads > Self Weights prompts you with the following dialog box (Figure 5.10). It allows you to define how the program computes self weights for all elements in the model. You must select a load case to which self weights belong. The self weights may act in the global X, Y, or Z direction. By default, self weights act in the global Y direction. You may specify a self weight multiplier (applied to material densities). A zero multiplier ignore self weights altogether.




Figure 5.10


2.5.10 Self Weight Exclusion

Loads > Self Weight Exclusion allows self weight to be considered or ignored for selected members, shells, and bricks.

2.5.11 Generate Loads

2.5.11.1 Generate Loads > Fluid Loads

Loads > Generate Loads > Fluid Loads prompts you with the dialog box above (Figure 5.11). It allows you to generate fluid loads applied to selected shells in the model. You must select a load case to which the fluid loads belong. Fluid loads are applied in the local coordinate system. The load variation must be in global X, Y or Z direction.



The image shows a software dialog box titled "Fluid Load" with a red close button in the top right corner. The dialog contains the following elements:

- Load Case:** A dropdown menu currently showing "1: Default".
- Loading:** A section containing three radio buttons for "Global direction of variation": X, Y, and Z. The Y radio button is selected.
- Values:** Two input fields labeled "Start" and "End", both containing the value "0". To the right of these fields is the unit "lb/ft^2".
- Coordinates:** Two input fields labeled "Start" and "End", both containing the value "0". To the right of these fields is the unit "ft".
- Notes:** A text area containing the text: "Notes: surface loads will be applied to the selected shells in their local z directions."
- Buttons:** "Apply" and "Cancel" buttons at the bottom right.

Figure 5.11

2.5.11.2 Generate Loads > Pattern Loads

Loads > Generate Loads > Pattern Loads prompts you with the following dialog box (Figure 5.12). It allows you to generate pattern loads applied to specified members in the model. You must select a load case (generally live case) that contains loads to be patterned. A pattern ratio (e.g., ACI 318-05 specifies 0.75) is also available. Load patterning allows us to generate maximum positive and negative moment at each span, maximum positive and negative moment at each support as well as maximum shear at each support. The existing point and line loads in the load case will be patterned based on odd, even and adjacent/alternate spans. These patterned loads are assigned to their own load cases. The program automatically generates additional load cases and load combinations based on the load patterning.




Figure 5.12

It should be pointed out that the program does not consider support conditions for pattern load generation. One pattern load case cannot be used in more than one load combination prior to load pattern generation.

2.5.11.3 Generate Loads > Moving Loads

Loads > Generate Loads > Moving Loads prompts you with the dialog box above (Figure 5.13). It allows you to generate moving loads applied to specified members in the model. You must select a load case that contains moving loads. Only point loads on the specified members in the load case will be moved. These moving loads are

assigned to their own load cases. The program automatically generates additional load cases and load combinations based on the moving step size.

It should be pointed out that one moving load case cannot be used in more than one load combination prior to moving load generation.




Figure 5.13

2.5.12 Case-Copy Loads

Loads > Case-Copy Loads prompts you with the following dialog box (Figure 5.14). It allows you to copy all loads from one load case to another. You have the option to delete existing loads in the target load case. The loads copied may also be multiplied

by a factor. At least two load cases must exist in the model in order to use this command.




Figure 5.14

2.5.13 Convert Area Loads to Line Loads

Loads > Convert Area Loads to Line Loads will convert all area loads to line loads in every load case. This is useful in checking how area loads would be converted during the solution process. You can always undo the area loads to line loads conversion.

2.5.14 Convert Local Loads to Global Loads

Loads > Convert Local Loads to Global Loads will convert all member point loads, line loads and shell surface loads from local coordinate systems to global coordinate system in every load case. This is useful for data transfer from ENERCALC 3D to Revit Structure using FastFrame Revit Link. You can always undo the local loads to global loads conversion.

2.5.15 Additional Masses

Loads > Additional Masses prompts you with the dialog box above (Figure 5.15). It allows you to assign additional masses and mass moment of inertia to selected nodes. The mass can be applied to X, Y and/or Z directions while the mass moment of inertia can be applied to OX, OY and/or OZ directions. Additional Masses are added to the mass calculated from the load combination for frequency analysis (see the command: Run > Frequency Analysis). Mass moment of inertia values can only be input using the Additional Masses command.

The mass unit is a force unit divided by the acceleration of gravity, while the mass moment of inertia has units of mass times length squared. The acceleration of gravity is taken as 386.09 in/sec² or 9.8 m/sec².




Figure 5.15

A more flexible way to assign additional masses is to use Assign > Additional Masses command, which allows you to continuously assign additional masses to nodes.

2.5.16 Response Spectra Library

Loads > Response Spectra Library prompts you with the dialog box below (Figure 5.16). It allows you to define spectrums for current and future projects. You can then use one or more spectrums in Run > Response Spectrum Analysis.

You may view/modify a user-defined spectrum by double clicking the spectrum (Figure 5.17). The first spectrum can not be edited or deleted. Spectra generated based on building codes cannot be edited but can be deleted.




Figure 5.16




Figure 5.17

2.6 Assign

The Assign menu provides commands to *continuously* assign supports, springs, and element properties to relevant objects (nodes and elements). Unlike commands in other menus, you do NOT need to select objects before running these commands.

2.6.1 Supports

Assign > Supports prompts you with the following dialog (Figure 6.1). It allows you to assign supports (rigid boundary conditions) to selected nodes in the model. One or more of the six global degrees of freedom (DOFs) may be restrained. In addition, you may specify enforced displacements in the restrained DOFs. The enforced displacements may be used to model support settlements. You may regard them as special loads. For normal supports, enforced displacements in the restrained DOFs are zero. The program provides three commonly used supports, namely, pinned, fixed and roller. In order for support assignments to take place, nodes must be selected beforehand.

After clicking “Assign”, you can start to *continuously* assign supports by window-selecting nodes until you right click the mouse or press the ESC key.




Figure 6.1

2.6.2 Springs

Assign > Springs prompts you with the following dialog (Figure 6.2).




Figure 6.2

It allows you to assign nodal, line, and surface springs (flexible boundary conditions) to selected nodes, members, or shells in the model (Figure 6.3). A nodal spring may be restrained in one or more of the six global DOFs (D_x , D_y , D_z , D_{ox} , D_{oy} and D_{oz}).

A line or surface spring may be restrained in one or more of the three global translational DOFs (D_x , D_y and D_z). To qualify to be a valid flexible restraint, the corresponding spring constant must be specified.




Figure 6.3

A restraint may be designated as linear, compression-only or tension only. A compression-only restraint is active only when the nodal displacement in the restrained direction is negative. A tension-only restraint is active only when the nodal displacement in the restrained direction is positive. The presence of tension only or compression only springs makes the model nonlinear and requires iterative solution for each load combination.

After clicking “Assign”, you can start to *continuously* assign nodal, line or surface springs by window-selecting nodes, members or shells until you right click the mouse or press the ESC key.

2.6.3 Member Properties

Assign > Member Properties prompts you with the following dialog (Figure 6.4). It allows you to assign one or more properties such as material, section etc to members. Make sure the “Use” checkbox by each property is set correctly. After clicking “Assign”, you can start to *continuously* assign all checked properties by window-selecting members until you right click the mouse or press the ESC key.




Figure 6.4

2.6.4 Shell Properties

Assign > Shell Properties prompts you with the following dialog (Figure 6.5). It allows you to assign one or more properties such as material, thickness etc to shells. Make sure the “Use” checkbox by each property is set correctly. After clicking “Assign”, you can start to *continuously* assign all checked properties by window-selecting shells until you right click the mouse or press the ESC key.




Figure 6.5

2.6.5 Nodal Loads

Assign > Nodal Loads prompts you with the following dialog box (Figure 6.6). It allows you to assign nodal loads to selected nodes in the model. You must select a load case to which the nodal loads belong. Nodal loads are specified in the global coordinate system. The loads are nodal forces in the X, Y, or Z direction if radio button “X”, “Y”, or “Z” is selected. The loads are nodal moments in the X, Y, or Z direction if radio button “OX”, “OY”, or “OZ” is selected. The load magnitude may be any non-zero value.




Figure 6.6

2.6.6 Point Loads

Assign > Point Loads prompts you with the above dialog box (Figure 6.7). It allows you to assign point loads to selected members in the model. You must select a load case to which the point loads belong. Point loads may be specified in either the local or global coordinate system. The loads are point forces in the X, Y, or Z direction if radio button “X”, “Y”, or “Z” is selected. The loads are point moments in the X, Y, or Z direction if radio button “OX”, “OY”, or “OZ” is selected. The load magnitude may be any non-zero value. The load distance is the ratio of the load location (measured from the member start) to the member length. A distance of 0.5 places the load at the middle of each selected member.




Figure 6.7

2.6.7 Line Loads

Assign > Line Loads prompts you with the following dialog box (Figure 6.8). It allows you to assign line loads to selected members in the model. You must select a load case to which the line loads belong. Line loads may be specified in either the local or global coordinate system. The loads are line forces in the X, Y, or Z direction. The start and end magnitudes of the load may be zero for either end but not for both. The load distances are the ratios of the load start and end locations (measured from the member start) to the member length. A start distance of 0.0 and an end distance of 1.0 place the line load on the entire span of each selected member.




Figure 6.8

2.6.8 Surface Loads

Assign > Surface Loads prompts you with the following dialog box (Figure 6.9). It allows you to assign surface loads to selected shells in the model. You must select a load case to which the surface loads belong. Surface loads may be specified in either the local or global coordinate system. The loads are surface forces in the X, Y, or Z direction. Surface load applies to the entire surface of a shell element.




Figure 6.9

2.6.9 Additional Masses

Assign > Additional Masses prompts you with the dialog box above (Figure 6.10). It allows you to assign additional masses and mass moment of inertia to selected nodes. The mass can be applied to X, Y and/or Z directions while the mass moment of inertia can be applied to OX, OY and/or OZ directions. Additional Masses are added to the mass calculated from the load combination for frequency analysis (see the command: Run > Frequency Analysis). Mass moment of inertia values can only be input using the Additional Masses command.

The mass unit is a force unit divided by the acceleration of gravity, while the mass moment of inertia has units of mass times length squared. The acceleration of gravity is taken as 386.09 in/sec² or 9.8 m/sec².




Figure 6.10

2.6.10 Deletion

Assign > Deletion prompts you with the following dialog (Figure 6.11). The input is essentially the same as Edit > Delete. After clicking “Assign”, you can start to *continuously* delete objects by window-selecting nodes and elements until you right click the mouse or press the ESC key.




Figure 6.11

2.7 Input Data

The Tables menu provides commands to create or modify all input data of a model using spreadsheets. Spreadsheets provide an alternative method to the graphic input described in earlier chapters. You may combine both methods to create a model quickly.

The spreadsheets support the common clipboard actions such as “CTRL+X” to cut, “CTRL+C” to copy and “CTRL+V” to paste data. You may even share data between the spreadsheets in the ENERCALC 3D and other spreadsheet programs such as Microsoft Excel. For example, you may generate node data in an Excel spreadsheet, copy the nodal coordinate data and paste to the Nodes spreadsheet in the program. In this way, you can take advantage of the more powerful data manipulation functions in the Excel.

In each spreadsheet, you may add one or more rows by clicking the “New Row” button. You may also print data in the spreadsheet by clicking the “Print” button. You

have the option to view only the selected data. To do that, click Settings > Data Options and check the “Show only selected entities in spreadsheet”. You may not modify the data in the spreadsheet when this option is chosen.

2.7.1 Materials

The Input Data > Materials command opens the Material Data table to display the materials that have been defined in the current model. It also offers assignment options.

2.7.2 Sections

The Input Data > Sections command opens the Section Data table to display the sections that have been defined in the current model. It also offers assignment options.

2.7.3 Shell Thicknesses

The Input Data > Shell Thicknesses command opens the Shell Thickness Data table to display the thicknesses that have been defined in the current model. It also offers assignment options.

2.7.4 Nodes

Input Data > Nodes prompts you with the following dialog box (Figure 7.1). It allows you to enter nodes in a spreadsheet. Each node includes the nodal coordinates and the selection status. You may not modify the node Ids.

An empty row is allowed if all rows below it are empty (except the node Id and status fields). You may not delete the existing nodes in the dialog box. To delete the existing nodes, you must dismiss this dialog box and click Edit > Delete.

Due to machine inaccuracy of floating point values, some commands (such as Edit > Rotate) may cause the presence of very small numerical coordinate values. You may round off these tiny values to be zeros by clicking the Round-off Coordinates button. The epsilon used for the round-off may be set from Settings > Data Options. The default epsilon value is 1e-10 and must be less than or equal to 1e-6.




Figure 7.1

2.7.5 Members

Input Data > Members prompts you with the following dialog box (Figure 7.2).




Figure 7.2

It allows you to enter members in a spreadsheet. Each member includes the Ids of start and end nodes, the material and section Ids, the element local angle, and the selection status. You may not modify the member Id. All other Ids must be valid (defined). Material and section combo boxes are provided for you to correctly pick and apply proper material and section Ids to selected members.

An empty row is allowed if all rows below it are empty (except the member Id and status fields). You may not delete the existing members in this dialog box. To delete the existing members, you must dismiss this dialog box and click Edit > Delete.

2.7.6 Shells

Input Data > Shells prompts you with the following dialog box (Figure 7.3).

4-Node Shell Data ✕

	Shell4 Id	Node-1	Node-2	Node-3	Node-4	Material	Thick	Local Angle (deg)	Status
1	1	1	2	9	8	1: Default	1: Default	0	Normal
2	2	2	3	10	9	1: Default	1: Default	0	Normal
3	3	3	4	11	10	1: Default	1: Default	0	Normal
4	4	4	5	12	11	1: Default	1: Default	0	Normal
5	5	5	6	13	12	1: Default	1: Default	0	Selected
6	6	6	7	14	13	1: Default	1: Default	0	Normal
7	7	8	9	16	15	1: Default	1: Default	0	Normal
8	8	9	10	17	16	1: Default	1: Default	0	Normal
9	9	10	11	18	17	1: Default	1: Default	0	Normal
10	10	11	12	19	18	1: Default	1: Default	0	Normal
11	11	12	13	20	19	1: Default	1: Default	0	Normal
12	12	13	14	21	20	1: Default	1: Default	0	Normal
13	13	15	16	23	22	1: Default	1: Default	0	Selected
14	14	16	17	24	23	1: Default	1: Default	0	Normal
15	15	17	18	25	24	1: Default	1: Default	0	Normal
16	16	18	19	26	25	1: Default	1: Default	0	Normal
17	17	19	20	27	26	1: Default	1: Default	0	Normal
18	18	20	21	28	27	1: Default	1: Default	0	Normal
19	19	22	23	30	29	1: Default	1: Default	0	Normal
20	20	23	24	31	30	1: Default	1: Default	0	Normal
21	21	24	25	32	31	1: Default	1: Default	0	Normal
22	22	25	26	33	32	1: Default	1: Default	0	Normal
23	23	26	27	34	33	1: Default	1: Default	0	Normal

New Rows Print... Save...

Figure 7.3

It allows you to enter shells in a spreadsheet. Each shell includes the Ids of four element nodes, the material and thickness Ids, the element local angle, and selection status. You may not modify the shell Ids. All other Ids must be valid (defined). Material and thickness combo boxes are provided for you to correctly pick and apply proper material and thickness Ids to selected shells.

An empty row is allowed if all rows below it are empty (except the shell Id and status fields). You may not delete the existing shells in this dialog box. To delete the existing shells, you must dismiss this dialog box and click Edit > Delete.

2.7.7 Bricks

Input Data > Bricks prompts you with the following dialog box (Figure 7.4). It allows you to enter bricks in a spreadsheet. Each brick includes the Ids of eight element

nodes, the material Id and selection status. You may not modify the brick Ids. All other Ids must be valid (defined). The material combo box is provided for you to correctly pick and apply proper material Ids to selected bricks.




Figure 7.4

2.7.8 Supports

Input Data > Supports prompts you with the following dialog box (Figure 7.5). It allows you to enter supports in a spreadsheet. Each support includes the node Id, the fixity flag, and enforced displacements for all restrained DOFs. The node Ids must be valid (defined).

The fixity flag is a string of 6 characters representing restrained DOFs in D_x , D_y ... D_{oz} . For each character in the flag, enter '1' if the DOF is restrained and '0' if unrestrained. For example, "111111" represents a fixed support while "111000" represents a pinned support. Enforced displacements may be applied to the restrained DOFs. They may be regarded as special loads and can be used to model known support settlements. For normal support, they are 0s. Enforced displacements applied to unrestrained DOFs will be discarded.

An empty row is allowed if all rows below it are empty. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 7.5

2.7.9 Springs

Input Data > Springs offers options to access the tables for Nodal Springs, Line Springs and Surface Springs.

2.7.9.1 Springs > Nodal Springs

Input Data > Springs > Nodal Springs prompts you with the following dialog box (Figure 7.6).




Figure 7.6

It allows you to enter nodal springs in a spreadsheet. Each nodal spring includes the node Id, the spring non-linearity flag and six spring coefficients K_x , K_y , ..., K_{Oz} . The node Id must be valid (defined).

The spring flag is a string of 6 characters representing the spring non-linearity in three translational DOFs (D_x , D_y , D_z) and three rotational DOFs (D_{Ox} , D_{Oy} , D_{Oz}). For each character in the flag, enter '0' if the restrained DOF is linear, '1' if compression-only and '2' if tension only. For the unrestrained DOFs, just enter 0s for the corresponding spring coefficients.

An empty row is allowed if all rows below it are empty. Selected rows (whole row must be selected) may be cut by clicking the button "Cut Selected Rows".

2.7.9.2 Springs > Line Springs

Input Data > Springs > Line Springs offers options to access the table for Line Springs.

2.7.9.3 Springs > Surface Springs

Input Data > Springs > Surface Springs prompts you with dialog boxes similar to that in Input Data > Springs > Nodal Springs. However, only three translational DOFs D_x , D_y , D_z are available for line or surface spring coefficients.

2.7.10 Member Releases

Input Data > Member Moment Releases prompts you with the following dialog box (Figure 7.7). It allows you to enter member moment releases in a spreadsheet. Each moment release includes the member Id, four 1-character release codes for major moment release (the local oz), and minor moment release (the local oy) for both ends of members. Enter '1' for the released local DOF and '0' for the un-released local DOF. The member Id must be valid.

An empty row is allowed if all rows below it are empty. Selected rows (whole row must be selected) may be cut by clicking the button "Cut Selected Rows".




Figure 7.7

2.7.11 Diaphragms

Input Data > Diaphragms prompts you with the following dialog box (Figure 7.8). It allows you to enter generic or regular rigid diaphragms in a spreadsheet. For a generic diaphragm, four distinct nodes are required to define the diaphragm plane. For a regular diaphragm in global XZ, YZ and XY plane, only the first node is required to define the diaphragm plane.

An empty row is allowed if all rows below it are empty. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.

Rigid diaphragms may be used instead of plate finite elements to model stiff in-plane actions such as concrete floors. Internally, the program creates multiple in-plane rigid links for each diaphragm prior to static or frequency analysis. A rigid link is simply a member with very large sectional properties that can be adjusted with the diaphragm stiffness factor (see Settings > Data Options). The larger the diaphragm stiffness factor, the stronger the in-plane rigid diaphragm action is. The presence of rigid links with large diaphragm stiffness factor (say 1E10) could create numerical difficulties during the solution if 64-bit floating point solver is used. However, the unique 128-bit floating point solver in ENERCALC 3D makes this problem nonexistent in that much larger diaphragm stiffness factor (say 1E20) may be used without creating numerical difficulties during solution.

The program further provides the option to ignore the rigid diaphragm actions as an analysis option (Analyze > Analysis Options).




Figure 7.8

2.7.12 Load Cases

Input Data > Load Cases command is identical to the one found in the Loads menu. It is provided here for convenience only.

2.7.13 Load Combinations

Input Data > Load Combinations command is identical to the one found in the Loads menu. It is provided here for convenience only.

2.7.14 Nodal Loads

Input Data > Nodal Loads prompts you with the following dialog box (Figure 7.9). It allows you to enter nodal loads in a spreadsheet. Each nodal load includes the node Id, the load direction, and magnitude. The load direction is specified in the global coordinate system. The load is a force if the load direction is in the X, Y or Z direction and moment if in the OX, OY or OZ. The node Id must be valid (defined).

An empty row is allowed if all rows below it do not contain any non-empty fields. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 7.9

2.7.15 Point Loads

Input Data > Point Loads prompts you with the following dialog box (Figure 7.10). It allows you to enter member point loads in a spreadsheet. Each point load includes the member Id, the load coordinate system, direction, magnitude, and distance. The load is a force if the load direction is in the X, Y or Z direction and moment if in the OX, OY or OZ. The load distance is the ratio of load location (measured from the start of the member) to member length. The member Id must be valid (defined).

An empty row is allowed if all rows below it are empty. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 7.10

2.7.16 Line Loads

Input Data > Line Loads prompts you with the following dialog box (Figure 7.11). It allows you to enter member line loads in a spreadsheet. Each line load includes the member Id, the load coordinate system, direction, start and end magnitudes, and the start and end distances. The load is a force in the local or global X, Y, Z directions. The load distances are the ratio of load start and end locations (measured from the start of the member) to the member length. The member Id must be valid (defined).

An empty row is allowed if all rows below it are empty. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 7.11

2.7.17 Area Loads

Input Data > Area Loads prompts you with the following dialog box (Figure 7.12). It allows you to enter member area loads in a spreadsheet. Each area load includes four node Ids, the load coordinate system, direction, load distribution, and load magnitude. The area load may be in global X, Y or Z direction, or in local Z direction. The four nodes form a quadrilateral load area and must be in the same plane. Node-4 may also be the same as Node-1, in which case the load area is a triangle. Area loads in one or all load cases may be converted to lines loads in their respective load cases.

An empty row is allowed if all rows below it are empty. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 7.12

2.7.18 Surface Loads

Input Data > Surface Loads prompts you with the following dialog box (Figure 7.13). It allows you to enter shell surface loads in a spreadsheet. Each surface load includes the shell Id, the load coordinate system, direction, and magnitude. The load is always a force in the local or global X, Y or Z directions. The shell Id must be valid (defined).

An empty row is allowed if all rows below it are empty. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 7.13

2.7.19 Self Weights

The Input Data > Self Weights command is identical to the one found in the Loads menu. It is provided here for convenience only.

2.7.20 Thermal Loads

2.7.20.1 Member Thermal Loads

Input Data > Thermal Loads > Member Thermal Loads displays a table of members and their temperature increase (Figure 7.14).




Figure 7.14

2.7.20.2 Shell Thermal Loads

Input Data > Thermal Loads > Shell Thermal Loads displays a table of shells and their temperature increase (Figure 7.15).




Figure 7.15

2.7.20.3 Brick Thermal Loads

Input Data > Thermal Loads > Brick Thermal Loads displays a table of bricks and their temperature increase (Figure 7.16).




Figure 7.16

2.7.21 Calculated Masses

Input Data > Calculated Masses prompts you with the following dialog box (Figure 7.17). It allows you to view the masses calculated from the load combination for frequency analysis set in Analyze > Frequency Analysis. The program will automatically convert all forces (not moments) in the positive or negative gravity direction to masses and apply them in all available mass degrees of freedom.




Figure 7.17

Obviously, the calculated mass values cannot be modified. However, you may convert all the calculated masses to additional masses. In this case, the “Convert loads to masses” option in Analyze > Frequency Analysis will be turned off. This technique may be useful when you want to account for the influence of axial loads on frequencies.

2.7.22 Additional Masses

Input Data > Additional Masses prompts you with the following dialog box (Figure 7.18). It allows you to enter additional nodal mass and nodal mass moment of inertia values. Each nodal mass or mass moment of inertia includes the node Id, the mass direction, and magnitude. The mass direction is specified in the global coordinate system. The unit of measurement for mass is force divided by the acceleration of gravity. For mass moment of inertia, the unit of measurement is mass times length units squared. The acceleration of gravity is generally takes as a constant value of 386.09 in/sec² or 9.8 m/sec².

An empty row is allowed if all rows below it do not contain any non-empty fields. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 7.18

2.7.23 Response Spectra Library

Input Data > Response Spectra Library prompts you with the dialog box below (Figure 7.19). It allows you to define spectrums for current and future projects. You can then use one or more spectrums in Run > Response Spectrum Analysis.

You may view/modify a user-defined spectrum by double clicking the spectrum (Figure 7.20). The first spectrum can not be edited or deleted. Spectra generated based on building codes cannot be edited but can be deleted.




Figure 7.19




Figure 7.20

2.7.24 Story Drift Nodes

Input Data > Story Drift Nodes prompts you with the following dialog box (Figure 7.21). It allows you to enter nodes that will be used for floor drift calculation.

An empty row is allowed if all rows below it do not contain any non-empty fields. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 7.21

2.7.25 Comments

Input Data > Comments prompts you with the following dialog box (Figure 7.22). It allows you to add or delete comments at different locations in the model. You may also add an individual comment using View > Options > Comment. A comment must be less than 256 characters in length.

An empty row is allowed if all rows below it do not contain any non-empty fields. Selected rows (whole row must be selected) may be cut by clicking the button “Cut Selected Rows”.




Figure 7.22

2.8 Analysis

The Analysis menu provides commands to set the analysis options and to perform analyses. For more information on analysis, please refer to "Technical Topics".

2.8.1 Analysis Options

Analysis > Analysis Options prompts you with the following dialog box (Figure 8.1). It allows you to set important options before performing analysis on the model.

The "Model type" determines the type of the model to analyze. Model type "3D Frame & Shell" is the most general. It has all six degrees of freedom (DOFs) available to every node in the model. Any model may be analyzed with this model type. However, computer memory or time may be wasted if a simpler model can be used.




Figure 8.1

Model type “2D Frame” may be used to model a 2D frame (beams and trusses) structure in the XY plane. Only three DOFs (D_x , D_y and D_{oz}) are available to every node in the model. The rest of the DOFs are suppressed.

Model type “3D Truss” may be used to model 3D truss structures. Only three DOFs (D_x , D_y , and D_z) are available to every node in the model. The rest of the DOFs are suppressed. If the model contains both 3D trusses and beams, “3D Frame & Shell” model type must be used and appropriate moment releases assigned.

Model type “2D Truss” may be used to model 2D truss structures in the XY plane. Only two DOFs (D_x and D_y) are available to every node in the model. The rest of the DOFs are suppressed. If the model contains both 2D trusses and beams, “2D Frame” model type must be used and appropriate moment releases assigned.

Model type “2D Plate Bending” may be used to model 2D plate bending structures such as flat slabs or mat foundations in the XY plane. It uses only the plate bending action of the shell formulation. Only three DOFs (D_z , D_{ox} and D_{oy}) are available to every node in the model. The rest of the DOFs are suppressed. The self weight should be in either $-Z$ or $+Z$ direction depending on your sign convention for loads.

Model type “2D Plane Stress” may be used to model 2D plane stress structures such as shear walls in the XY plane. It uses only the membrane action of the shell formulation. Only two DOFs (D_x and D_y) are available to every node in the model. The rest of the DOFs are suppressed.

Model type “3D Brick” may be used to model 3D solid structures. Only three DOFs (D_x , D_y , D_z) are available to every node in the model. The rest of the DOFs are suppressed.

Non-linear convergence control includes the maximum iterations and axial force tolerance between adjacent P-Delta iterations. The maximum iterations apply to both P-Delta analysis and analysis involving non-linear springs. It is provided to avoid excessive number of nonlinear iterations during the solution. A default value of 10 is usually sufficient. Axial force tolerance between adjacent P-Delta iterations reflects the actual convergence of the P-Delta analysis. The default value of 0.5% should be good for most cases. It is a good idea to perform a linear analysis before the P-Delta analysis. In this way, you may identify any problems in the model before the more rigorous analysis option is undertaken.

By default, the program considers shear deformations on members in the model. You must also set shear areas of member sections for this option to take effect. To do that, click Assign Properties > Sections. You may ignore member shear deformations by unchecking “Consider shear deformation on members”. Generally, shear deformations on members are insignificant. However, you should check this option when members are of relatively great depths. *Shear deformation, when considered, applies to both the element stiffness matrix and local (segmental) deflections.*

The number of segments for member segmental output may be set from 1 to 127. A value of 20 segments is recommended in most cases. More segments produce more accurate results, but require more usage of computer memory. The accuracy may be reflected in the smoothness of moment, shear and deflection diagrams. Since member local deflection is computed based on the moment and shear diagrams, a value of more than 20 segments may be needed if very accurate local deflection is desired.

You may specify whether to use cracked section properties for the analysis. The cracking factors are specified by Input Data > Members, Input Data > Shells or RC Design > Cracking Factors. Cracking factors will not be applied until “Use cracked section properties (lcr) for members and finite elements” is checked here. This option is given so that you do not need to reenter cracking factors if you decide to use gross section properties in a different analysis run.

Usually, stresses in finite elements are not continuous across element boundary. You may average them for adjacent shells/bricks at nodes. This usually makes the results more accurate and the contours smoother. However, it may also disguise insufficient convergence for an unsatisfactory (coarse) finite element mesh. *Obviously, stress averaging can only apply to adjacent elements that have compatible local coordinate systems. For planar elements, stress averaging should only apply to adjacent elements that share the same local coordinate systems. Special attention should be given to shear stress averaging at supports since shears of adjacent elements may have opposite signs.*

By default, the program uses the MITC4 for shell bending formulation. The MITC4 is a thick plate formulation and accounts for the out-of-plane shear deformation. However, if the shell elements are all rectangular, you may use the classical Kirchhoff plate bending formulation. The Kirchhoff plate element is a thin plate formulation and ignores the out-of-plane shear deformation.

For the membrane formulation of the shell element or of the brick element, incompatible modes may be added to the standard isoparametric (compatible) formulation. The incompatible shell element models the in-plane bending more accurately than the standard compatible element. The incompatible brick element, which produces much more accurate results than the compatible one, should almost always be preferred.

There are three kinds of solvers available in ENERCALC 3D:

Double precision 64-bit floating point Skyline solver:

- standard solver similar to many analysis programs in the market
- enough for most structures

Double precision 64-bit floating point Sparse solver:

- fastest, but lacks informative messages when something goes wrong during a solution
- can only be used for static analysis
- useful to solve extremely large structural models
- offers an out-of-core approach to minimize the requirement of computer memory

Quad precision 128-bit floating point Skyline solver:

- provides an invaluable alternative for some large or numerically sensitive models where the 64-bit floating point (double precision) solver may fail
- extremely stable and accurate, but relatively slow
- the recommended solver if the model contains rigid diaphragms to avoid numerical difficulties.

You have the option to consider rigid diaphragm actions during the solution. This is useful to ignore rigid diaphragms without deleting the existing diaphragms.

2.8.2 Static Analysis

Analysis > Static Analysis performs the static analysis of the model. You should set the appropriate analysis options before running this command. To do that, just click Analyze > Analysis Options.

A solver dialog box (Figure 8.2) is displayed showing the progress of the solver. The solver first solves all linear load combinations, then all nonlinear load combinations. If the model contains compression-only or tension-only springs, every load combination is a nonlinear load combination. Otherwise, only P-Delta load combinations are nonlinear. The nonlinear load combinations are solved iteratively and therefore may require considerable solution time.

You may abort the solving process by pressing ESC if a non-sparse solver is used.




Figure 8.2

2.8.3 Frequency Analysis

Analysis > Frequency Analysis prompts you with the following dialog box (Figure 8.3). It allows you to set important options before performing frequency analysis on the model.

The load combination for mass and stiffness must be specified. If you want to input nodal mass and/or mass moment of inertia directly, you may do so from Loads > Additional Masses or Input Data > Additional Masses. The load combination is also used to form the correct stiffness matrix if the model response is not linear.

The number of modes is used to determine how many frequencies and mode shapes are to be computed. This value must be less than the total number of mass degrees of freedom. Practically speaking, only the lowest eigen modes are used for design purposes.

The number of iteration vectors q is normally set as the minimum of $(2 * p, p + 8)$, where p is the number of modes requested [Ref. 1]. A higher convergence rate can be achieved by using more iteration vectors. This may be necessary if some eigen modes are missing after the solution or if the solution becomes unstable.

The tolerance of eigenvalues is used to measure the convergence of eigenvalues during each successive solver iteration. It is expressed as the following:
 $(i = 1, 2, \dots \text{number of requested modes})$
 where k is the subspace iteration counter.

A maximum number of subspace iterations is used to prevent excessive solution time. If the solver reaches this limit without convergence, the eigen results should not be trusted.




Figure 8.3

2.8.4 Response Spectrum Analysis

Analysis > Response Spectrum Analysis prompts you with the dialog box below (Figure 7.4). It allows you to perform response spectrum analysis in global X, Y and/or Z directions. There are three mode combination methods available in the program: CQC (complete quadratic combination), SRSS (Square root of sum of squares) and ABSSUM (absolute sum). CQC method for modal combination is

applicable to a wider class of structures and is therefore recommended method. Critical damping ratio ($0 \leq \text{damp} < 1.0$) affects CQC results. When critical damping ratio is 0, CQC method is the same as SRSS method.

You must first run from Analysis > Frequency Analysis prior to running this command. Response spectra can be defined from Loads > Response Spectra Library or Input Data | Response Spectra Library. Inertia forces in global direction X, Y or/and Z from response spectrum analysis will be calculated and then converted to nodal loads.

These nodal forces will be placed in respective load cases such as INERTIA_LOADCASE_X_MODE_1, INERTIA_LOADCASE_X_MODE_2 etc. Existing loads in these load cases will be deleted prior to the load conversion.

In addition, response spectrum load combinations **INERTIA_LOADCOMB_X_MODE_1, INERTIA_LOADCOMB_X_MODE_2 etc.** will be created or recreated.

Static analysis will be performed on spectrum load combinations (as well as normal user-defined load combinations) automatically. Modal combinations will be subsequently calculated for results such as displacements, forces and stresses etc. using CQC, SRSS or ABSSUM on the response spectrum load combinations. Normally, modal combination results are all positive due to the sign lost during SRSS, CQC and ABSSUM procedures. However, you can choose to use signage for modal combination results based on the dominant mode (with maximum participation factor) in each global direction.

Modal combination results is done in each global direction first. Using directional factors, these directional modal results will be combined into final modal combination results, which can be added to any user-defined load combination results if non-zero response spectrum load factor is specified in the load combination definition (see Loads | Load Combinations).




Figure 7.4

2.9 Analysis Result

The Analysis Results menu provides commands to view and print analysis results for each load combination in spreadsheets.

2.9.1 Nodal Displacements

Analysis Result > Nodal Displacements displays the following dialog box (Figure 9.1). It allows you to view nodal displacements for each load combination. The displacements for each node include three translational components D_x , D_y and D_z and three rotational components D_{ox} , D_{oy} and D_{oz} . You have the option to view the displacements for the selected nodes only.

Nodal Displacements - [Default]

Load Combination: 1: Default Show selected only Print... Save... Close

	Node Id	Dx [in]	Dy [in]	Dz [in]	Dox [rad]	Doy [rad]	Doz [rad]
1	1	-5.067e-009	-2.405e-010	0.000e+000	0.000e+000	0.000e+000	5.016e-003
2	2	-3.310e-002	2.405e-010	0.000e+000	0.000e+000	0.000e+000	-9.120e-004
3	3	-3.167e-009	-3.088e-011	0.000e+000	0.000e+000	0.000e+000	5.918e-003
4	4	-2.069e-002	3.088e-011	0.000e+000	0.000e+000	0.000e+000	-5.391e-003

Figure 9.1

2.9.2 Story Drifts

Analysis Result > Story Drifts displays the following dialog box (Figure 9.2). It allows you to view story drifts for each load combination. You have the option to view the story drifts for the selected nodes only.

Story Drift - [Linear]

Load Combination: 1: Linear Show selected only Print... Save... Close

	Node Id	Story Height [ft]	Dx [in]	X Drift [in]	X Drift Ratio	Dz [in]	Z Drift [in]	Z Drift Ratio
1	1		-0.000			0.000		
2	2	12.000	1.965	1.965	1.365 %	0.000	0.000	0.000 %
3	3	12.000	4.387	2.421	1.681 %	0.000	0.000	0.000 %

Figure 9.2

2.9.3 Support Reactions

Analysis Result > Support Reactions displays the following dialog box (Figure 9.3). It allows you to view support reactions for each load combination. The reactions for each support include three force components R_x , R_y and R_z and three moment components R_{Ox} , R_{Oy} and R_{Oz} . You have the option to view the reactions for the selected supports only.

Support Reactions - [Linear]

Load Combination: 1: Linear Show selected only Print... Save... Close

	Node Id	Rx [kip]	Ry [kip]	Rz [kip]	Rox [kip-in]	Roy [kip-in]	Roz [kip-in]
1	1	1.10	37.60	0.00	0.00	0.00	0.00
2	5	-7.10	142.40	0.00	0.00	0.00	0.00
3	Sum	-6.00	180.00	0.00	0.00	0.00	0.00

Figure 9.3

2.9.4 Spring Reactions

2.9.4.1 Spring Reactions > Nodal

Analysis Result > Spring Reactions > Nodal displays the following dialog box (Figure 9.4). It allows you to view nodal spring reactions for each load combination. The reactions for each nodal spring include three force components SR_x , SR_y and SR_z and three moment components SR_{ox} , SR_{oy} and SR_{oz} . You have the option to view the reactions for the selected nodal springs only.

Spring Reactions - [Default]

Load Combination: 1: Default Show selected only Print... Save... Close

	Node Id	SRx [lb]	SRy [lb]	SRz [lb]	SRox [lb-in]	SRoy [lb-in]	SRoz [lb-in]
1	1	0.000e+000	1.000e+001	0.000e+000	0.000e+000	0.000e+000	0.000e+000
2	2	0.000e+000	-1.000e+001	0.000e+000	0.000e+000	0.000e+000	0.000e+000
3	3	0.000e+000	0.000e+000	0.000e+000	0.000e+000	0.000e+000	0.000e+000

Figure 9.4

2.9.4.2 Spring Reactions > Line

Analysis Result > Spring Reactions > Line displays the following dialog box (Figure 9.5). It allows you to view line spring reactions for each load combination. The reactions for each line spring include three force components SR_x , SR_y and SR_z . You have the option to view the reactions for the selected line springs only.

Spring Reactions - [Default]

Load Combination: 1: Default Show selected only Print... Save... Close

	Member Id	SRx [lb/in]	SRy [lb/in]	SRz [lb/in]
1	1	0.0000e+000	5.9938e+000	0.0000e+000
2	2	0.0000e+000	1.9648e+001	0.0000e+000
3	3	0.0000e+000	3.8170e+001	0.0000e+000
4	4	0.0000e+000	6.4335e+001	0.0000e+000
5	5	0.0000e+000	1.0010e+002	0.0000e+000
6	6	0.0000e+000	1.4605e+002	0.0000e+000
7	7	0.0000e+000	2.0064e+002	0.0000e+000

Figure 9.5

2.9.4.3 Spring Reactions > Surface

Analysis Result > Spring Reactions > Surface displays the following dialog box (Figure 9.6). It allows you to view surface spring reactions for each load combination. The reactions for each surface spring include three force components SR_x , SR_y and SR_z . You have the option to view the reactions for the selected surface springs only.

Spring Reactions - [Default]

Load Combination: 1: Default Show selected only Print... Save... Close

	Shell4 Id	SRx [lb/in^2]	SRy [lb/in^2]	SRz [lb/in^2]
1	7	0.0000	0.0000	-0.0326
2	8	0.0000	0.0000	-0.0636
3	9	0.0000	0.0000	-0.0848
4	10	0.0000	0.0000	-0.0956
5	11	0.0000	0.0000	-0.0956
6	12	0.0000	0.0000	-0.0848

Figure 9.6

2.9.5 Multi-DOF Constraint Forces & Moments

Analysis Result > Multi-DOF Constraint Forces & Moments displays the following dialog box (Figure 9.7). It allows you to view constraint forces and moments for each load combination. The value columns can be either constraint forces (for DOF X, Y and Z) or moments (for DOF OX, OY and OZ).

Constraint Id	Node-1	DOF-1	Value-1 [kip or kip-ft]	Node-2	DOF-2	Value-2 [kip or kip-ft]
1	2	X	-4.500	2	Y	7.794

Figure 9.7

2.9.6 Member End Forces & Moments

Analysis Result > Member End Forces & Moments displays the following dialog box (Figure 9.8). It allows you to view forces and moments at the ends of each member for each load combination. The end forces and moments include axial force F_x , major shear F_y , minor shear F_z , torsion M_x , minor moment M_y , and major moment M_z . You have the option to view the end forces and moments for the selected members only.

Member Id	Distance (%L)	Fx (Axial) [kip]	Fy (Major Shear) [kip]	Fz (Minor Shear) [kip]	Mx (Torsion) [kip-in]	My (Minor Moment) [kip-in]	Mz (Major Moment) [kip-in]
1	0.000	-37.60	-1.10	0.00	0.00	0.00	-0.00
2	1.000	-37.60	-1.10	0.00	0.00	0.00	-158.13
3							
4	0.000	-37.60	-1.10	0.00	0.00	0.00	-158.13
5	1.000	-37.60	-1.10	0.00	0.00	0.00	-316.25
6							
7	0.000	-7.10	37.60	0.00	0.00	0.00	-316.25
8	1.000	-7.10	-22.40	0.00	0.00	0.00	-2044.25
9							

Figure 9.8

2.9.7 Member Segmental Results

Analysis Result > Member Segmental Results displays the following dialog box (Figure 9.9). It allows you to view member segmental results for each load combination. The segmental results are shown at each segmental point designated by a distance along the member. They include axial force F_x , major shear F_y , minor shear F_z , torsion M_x , minor moment M_y , major moment M_z , major local deflection D_y , and minor local deflection D_z . You have the option to view the segmental forces and moments for the selected members only.

Member Segmental Results - [Linear]

Load Combination: 1: Linear Show selected only Print... Save... Close

Member Id	Distance (%L)	Fx (Axial) [kip]	Fy (Major Shear) [kip]	Fz (Minor Shear) [kip]	Mx (Torsion) [kip-in]	My (Minor Moment) [kip-in]	Mz (Major Moment) [kip-in]	Dy (Major Deflection) [in]	Dz (Minor Deflection) [in]
1	0.000	-37.60	-1.10	0.00	0.00	0.00	-0.00	0.000	0.000
2	0.050	-37.60	-1.10	0.00	0.00	0.00	-7.91	0.004	0.000
3	0.100	-37.60	-1.10	0.00	0.00	0.00	-15.81	0.008	0.000
4	0.150	-37.60	-1.10	0.00	0.00	0.00	-23.72	0.011	0.000
5	0.200	-37.60	-1.10	0.00	0.00	0.00	-31.63	0.015	0.000
6	0.250	-37.60	-1.10	0.00	0.00	0.00	-39.53	0.018	0.000
7	0.300	-37.60	-1.10	0.00	0.00	0.00	-47.44	0.021	0.000
8	0.350	-37.60	-1.10	0.00	0.00	0.00	-55.34	0.023	0.000
9	0.400	-37.60	-1.10	0.00	0.00	0.00	-63.25	0.026	0.000
10	0.450	-37.60	-1.10	0.00	0.00	0.00	-71.16	0.027	0.000

Figure 9.9

2.9.8 Shell Forces & Moments

Analysis Result > Shell Forces & Moments displays the following dialog box (Figure 9.10). It allows you to view shell forces and moments for each load combination. The shell forces and moments include in-plane normal forces F_{xx} , F_{yy} and shear force F_{xy} ; out-of-plane bending moments M_{xx} , M_{yy} , M_{xy} ; and out-of-plane shear forces V_{xx} , V_{yy} . You may specify the force and moment locations to be at the nodes and/or the center of each shell by running Settings > Data Options. You have the option to view the forces and moments for the selected shells only.

Shell4 Forces and Moments - [Default]

Load Combination: 1: Default Show selected only Print... Save... Close

Shell Id	Node Id	Fxx [lb/in]	Fyy [lb/in]	Fxy [lb/in]	Mxx [lb-in/in]	Myy [lb-in/in]	Mxy [lb-in/in]	Vxx [lb/in]	Vyy [lb/in]
1	1	-20.308	5653.921	1726.988	10.772	633.868	-58.255	-4.006	-20.044
2	2	-20.779	943.317	1726.667	10.756	473.851	-58.459	-4.006	19.775
3	9	-21.699	943.317	-1648.668	10.169	473.851	-173.117	-4.048	19.775
4	8	-21.228	5653.921	-1648.347	10.185	633.868	-172.913	-4.048	-20.044
5									
6	2	-84.501	943.310	801.017	-196.918	479.803	-58.459	-17.145	-19.965
7	3	-84.706	-1101.416	800.115	-196.934	320.250	-57.905	-17.145	19.709
8	10	-87.294	-1101.416	-664.979	-195.345	320.250	-172.229	-16.982	19.709
9	9	-87.089	943.310	-664.076	-195.329	479.803	-172.783	-16.982	-19.965

Figure 9.10

2.9.9 Shell Principal Forces & Moments

Analysis Result > Shell Principal Forces & Moments displays the following dialog box (Figure 9.11). It allows you to view shell principal forces and moments for each load combination. The shell principal forces and moments include in-plane principal forces

F_{max} , F_{min} and the principal angle F-angle; out-of-plane principal moments M_{max} , M_{min} and the principal angle M-angle; out-of-plane principal shear force V_{max} and the principal angle V-angle. You may specify the principal force and moment locations to be at the nodes and/or the center of each shell by running Settings > Data Options. You have the option to view the principal forces and moments for the selected shells only.

	Shell Id	Node Id	Fmax [lb/in]	Fmin [lb/in]	F-Angle [deg]	Mmax [lb-in/in]	Mmin [lb-in/in]	M-Angle [deg]	Vmax [lb/in]	V-Angle [deg]
1	1	1	6138.207	-504.594	74.335	639.267	5.372	-84.704	20.441	-101.303
2		2	2253.962	-1331.424	52.799	481.117	3.490	-82.915	20.177	101.453
3		9	2178.633	-1257.015	-53.156	531.354	-47.334	-71.626	20.185	101.568
4		8	6097.943	-465.250	-74.924	678.599	-34.546	-75.496	20.449	-101.417
5										
6	2	2	1381.102	-522.293	61.341	484.816	-201.931	-85.099	26.317	-130.655
7		3	354.888	-1541.010	28.785	326.654	-203.338	-83.689	26.123	131.020
8		10	241.891	-1430.601	-26.337	372.489	-247.584	-73.127	26.016	130.749
9		9	1268.603	-412.382	-63.902	521.453	-236.979	-76.447	26.210	-130.384

Figure 9.11

2.9.10 Shell Stresses [Top & Bottom]

Analysis Result > Shell Stresses displays the following dialog box (Figure 9.12). It allows you to view shell top or bottom stresses for each load combination. The shell stresses include three normal components S_{xx} , S_{yy} , S_{zz} and three shear components S_{xy} , S_{xz} and S_{yz} . You may specify the stress locations to be at the nodes and/or the center of each shell by running Settings > Data Options. You have the option to view the stresses for the selected shells only.

	Shell Id	Node Id	Sxx [lb/in^2]	Syy [lb/in^2]	Szz [lb/in^2]	Sxy [lb/in^2]	Sxz [lb/in^2]	Syz [lb/in^2]
1	1	1	-13.95	1462.06	0.00	614.50	-6.68	-1.34
2		2	-14.10	-1.46	0.00	614.53	6.59	-1.34
3		9	-14.01	-1.46	0.00	-434.14	6.59	-1.35
4		8	-13.87	1462.06	0.00	-434.17	-6.68	-1.35
5								
6	2	2	103.11	-5.43	0.00	305.98	-6.66	-5.72
7		3	103.05	-580.64	0.00	305.31	6.57	-5.72
8		10	101.13	-580.64	0.00	-106.84	6.57	-5.66

Figure 9.12

2.9.11 Shell Principal Stresses

Analysis Result > Shell Principal Stresses displays the following dialog box (Figure 9.13). It allows you to view shell top or bottom principal stresses and Von Mises stresses for each load combination. You may specify the stress locations to be at the nodes and/or the center of each shell by running Settings > Data Options. You have the option to view the stresses for the selected shells only.

Shell Id	Node Id	Top-S1 [lb/in ²]	Top-S2 [lb/in ²]	Top-Von Mises [lb/in ²]	Bot-S1 [lb/in ²]	Bot-S2 [lb/in ²]	Bot-Von Mises [lb/in ²]
1	1	1684.40	-236.29	1814.12	2426.03	-118.40	2487.34
2	2	606.78	-622.34	1064.48	937.53	-306.94	1122.91
3	9	426.45	-441.93	752.08	1050.92	-421.03	1313.07
4	8	1580.31	-132.11	1650.34	2485.01	-178.08	2578.66
5							
6	2	359.59	-261.91	540.45	695.15	-220.29	827.59
7	3	219.54	-697.13	829.00	71.54	-384.70	425.01
8	10	117.48	-596.99	663.58	180.01	-492.97	603.46
9	9	166.68	-70.92	211.27	757.81	-282.76	931.94

Figure 9.13

2.9.12 Shell Nodal Resultants

Analysis Result > Shell Nodal Resultants displays the following dialog box (Figure 9.14). It allows you to view shell nodal resultants for each load combination. The nodal resultants are concentrated forces and moments at element nodes that keep individual elements in equilibrium. They are expressed in the local coordinate system. You have the option to view the nodal resultants for the selected shells only.

Shell Id	Node	Fx [lb]	Fy [lb]	Fz [lb]	Mx [lb-in]	My [lb-in]
1	1	-162.758	-86276.063	-218.617	-10664.670	-0.000
2	2	-1203.394	-28800.927	213.920	-8774.928	-529.595
3	9	153.221	30758.927	-12.565	8661.368	3518.358
4	8	1212.931	84318.063	17.262	10543.394	4035.800
5						
6	2	947.532	-12370.636	-544.845	-7973.896	529.595
7	3	-3320.534	15128.574	540.383	-6093.468	10352.631
8	10	-974.346	-11727.614	312.795	5981.929	14336.455
9	9	3347.347	8969.676	-308.333	7862.344	4546.340
10						

Figure 9.14

2.9.13 Brick Stresses

Analysis Result > Brick Stresses displays the following dialog box (Figure 9.15). It allows you to view brick stresses for each load combination. The brick stresses include three normal components S_{xx} , S_{yy} , S_{zz} and three shear components S_{xy} , S_{yz} and S_{xz} . You may specify the stress locations to be at the nodes and/or the center of each brick by running Settings > Data Options. You have the option to view the stresses for the selected bricks only.

	Brick Id	Node Id	Sx [lb/in ²]	Sy [lb/in ²]	Sz [lb/in ²]	Sxy [lb/in ²]	Syz [lb/in ²]	Sxz [lb/in ²]
1	1	Center	1999.982	1999.982	1999.982	399.999	399.999	399.999
2		1	1999.982	1999.982	1999.982	399.999	399.999	399.999
3		2	1999.982	1999.982	1999.982	399.999	399.999	399.999
4		3	1999.982	1999.982	1999.982	399.999	399.999	399.999
5		4	1999.982	1999.982	1999.982	399.999	399.999	399.999
6		5	1999.982	1999.982	1999.982	399.999	399.999	399.999
7		6	1999.982	1999.982	1999.982	399.999	399.999	399.999
8		7	1999.982	1999.982	1999.982	399.999	399.999	399.999
9		8	1999.982	1999.982	1999.982	399.999	399.999	399.999
10								

Figure 9.15

2.9.14 Brick Principal Stresses

Analysis Result > Brick Principal Stresses displays the following dialog box (Figure 9.16). It allows you to view brick principal stresses and Von Mises stresses for each load combination. Brick principal stresses are shown at locations of nodes and/or center of each shell. You may control the locations by running Settings > Data Options. Brick principal stresses include three principal components S_1 , S_2 , S_3 and direction vectors (V_{1x} , V_{1y} and V_{1z}) and (V_{3x} , V_{3y} and V_{3z}). You have the option to view the principal stresses for selected bricks only.

Brick Principal Stresses - [Default]

Load Combination: 1: Default Show selected only Print... Save... Close

	Brick Id	Node Id	S1 [lb/in ²]	S2 [lb/in ²]	S3 [lb/in ²]	Von Mises [lb/in ²]	v1x	v1y	v1z	v3x	v3y	v3z
1	1	Center	2799.979	1599.983	1599.983	1199.996	0.577	0.577	0.577	-0.417	0.816	-0.399
2		1	2799.979	1599.983	1599.983	1199.996	0.577	0.577	0.577	-0.672	-0.066	0.738
3		2	2799.979	1599.983	1599.983	1199.996	0.577	0.577	0.577	-0.751	0.653	0.098
4		3	2799.979	1599.983	1599.983	1199.996	0.577	0.577	0.577	-0.417	0.816	-0.399
5		4	2799.979	1599.983	1599.983	1199.996	0.577	0.577	0.577	-0.182	-0.598	0.780
6		5	2799.979	1599.983	1599.983	1199.996	0.577	0.577	0.577	-0.011	-0.702	0.712
7		6	2799.979	1599.983	1599.983	1199.996	0.577	0.577	0.577	0.615	-0.772	0.157
8		7	2799.979	1599.983	1599.983	1199.996	0.577	0.577	0.577	0.707	-0.707	0.000
9		8	2799.979	1599.983	1599.983	1199.996	0.577	0.577	0.577	-0.672	-0.066	0.738

Figure 9.16

2.9.15 Eigenvalues

Analysis Result > Eigenvalues displays the following dialog box (Figure 9.17). It allows you to view eigenvalues (λ) and their derivatives such as periods (T), frequencies (f), and circular frequencies (ω). In addition, an error measure is calculated for each eigenvalue according to the following (see Ref. 1):

$$\text{Error Measure} = \sqrt{1 - \frac{(\lambda_i^{(k)})^2}{(q_i^{(k)})^T (q_i^{(k)})}}$$

Where $q_i^{(k)}$ is the vector in the matrix $Q^{(k)}$ corresponding to $\lambda_i^{(k)}$.

Eigenvalues

Print... Save... Close

	Mode	Period (sec)	Frequency (cycle/sec)	Circular Frequency (rad/sec)	Eigenvalue (rad/sec) ²	Error Measure
1	1	0.1444	6.9255	43.5140	1893.4658	2.0507e-011
2	2	0.0234	42.6551	268.0099	7.1829e+004	3.4321e-013
3	3	0.0085	117.5983	738.8919	5.4596e+005	7.8421e-014
4	4	0.0047	213.1035	1338.9691	1.7928e+006	4.1887e-010
5	5	0.0044	226.7377	1424.6352	2.0296e+006	2.1897e-014
6	6	0.0027	367.7854	2310.8637	5.3401e+006	4.5093e-014

Figure 9.17

2.9.16 Eigenvectors

Analysis Result > Eigenvectors displays the following dialog box (Figure 9.18). It allows you to view eigenvectors (mode shapes) for each mode of vibration. It is worthwhile to point out that eigenvectors are meaningful only in their relative values.

	Node Id	Dx [mm]	Dy [mm]	Dz [mm]	Dox [rad]	Doy [rad]	Doz [rad]
1	2	0.000e+000	0.000e+000	0.000e+000	0.000e+000	0.000e+000	0.000e+000
2	3	-4.542e-029	1.663e+000	0.000e+000	0.000e+000	0.000e+000	9.729e-003
3	12	-2.023e-030	4.287e-002	0.000e+000	0.000e+000	0.000e+000	2.816e-003
4	13	4.538e-030	1.611e-001	0.000e+000	0.000e+000	0.000e+000	5.107e-003
5	14	1.177e-029	3.394e-001	0.000e+000	0.000e+000	0.000e+000	6.885e-003
6	15	-2.075e-029	5.629e-001	0.000e+000	0.000e+000	0.000e+000	8.174e-003
7	16	-1.443e-029	8.178e-001	0.000e+000	0.000e+000	0.000e+000	9.020e-003
8	17	3.770e-029	1.092e+000	0.000e+000	0.000e+000	0.000e+000	9.493e-003
9	18	6.618e-030	1.376e+000	0.000e+000	0.000e+000	0.000e+000	9.687e-003

Figure 9.18

2.9.17 Mode Participation Factors

Analysis Result > Mode Participation Factors displays the following dialog box (Figure 9.19). It allows you to view mode participation factors for each mode in global X, Y and Z directions. You must perform response spectrum analysis beforehand.

	Mode	Period (sec)	SX Participation	SY Participation	SZ Participation
1	1	0.5788	0.7883	0.0000e+000	0.0000e+000
2	2	0.2534	0.1455	0.0000e+000	0.0000e+000
3	3	0.1873	0.0516	0.0000e+000	0.0000e+000

Figure 9.19

2.9.18 Modal Displacements SX, SY and SZ

Analysis Result > Modal Displacements > Modal Displacements SX, SY and SZ displays the following dialog box (Figure 9.20). It allows you to view modal displacements for each mode as well as their SRSS combination in global X, Y and Z directions. You must perform response spectrum analysis beforehand.

SX Modal Displacements - [Mode-1]

Mode Shape: Mode-1: (Period=0.5788 sec) Show selected only

	Node Id	Dx [mm]	Dy [mm]	Dz [mm]	Dox [rad]	Doy [rad]	Doz [rad]
1	1	5.193e+001	1.598e-027	0.000e+000	0.000e+000	0.000e+000	2.944e-035
2	2	4.046e+001	-4.575e-028	0.000e+000	0.000e+000	0.000e+000	2.470e-035
3	3	2.579e+001	-1.548e-027	0.000e+000	0.000e+000	0.000e+000	1.269e-035
4	4	1.221e+001	1.219e-027	0.000e+000	0.000e+000	0.000e+000	4.561e-036
5	5	0.000e+000	0.000e+000	0.000e+000	0.000e+000	0.000e+000	0.000e+000

Figure 9.20

2.9.19 Inertial Forces SX, SY and SZ

Analysis Result > Inertial Forces > Inertia Forces SX, SY and SZ displays the following dialog box (Figure 9.21). It allows you to view inertia forces for each mode in global X, Y and Z directions. You must perform response spectrum analysis beforehand. Inertia forces are converted to nodal loads in different inertia load cases automatically during response spectrum analysis.

SX Inertial Forces - [Mode-1]

Mode Shape: Mode-1: (Period=0.5788 sec) Show selected only

	Node Id	Fx [kN]	Fy [kN]	Fz [kN]	Mx [kN-m]	My [kN-m]	Mz [kN-m]
1	1	9.17	0.00	0.00	0.00	0.00	0.00
2	2	14.30	-0.00	0.00	0.00	0.00	-0.00
3	3	9.11	-0.00	0.00	0.00	0.00	-0.00
4	4	6.47	0.00	0.00	0.00	0.00	-0.00
5	5	0.00	0.00	0.00	0.00	0.00	0.00

Figure 9.21

2.9.20 Modal Combinations

The sub-items in the Modal Combinations menu provide results from a modal analysis.

2.9.20.1 Nodal Displacements

Analysis Result > Modal Combinations > Nodal Displacements displays the following dialog box (Figure 9.22). It allows you to view nodal displacements in modal combinations (including directional combinations). You must perform response spectrum analysis beforehand.

	Node Id	Dx [in]	Dy [in]	Dz [in]	Dox [rad]	Doz [rad]	Doz [rad]
1	1	1.082843e-011	3.188305e-011	0.000000e+000	0.000e+000	0.000e+000	1.205e-009
2	2	1.624383e-011	6.877240e-027	0.000000e+000	0.000e+000	0.000e+000	1.628e-009
3	3	1.082843e-011	3.188305e-011	0.000000e+000	0.000e+000	0.000e+000	1.205e-009
4	4	7.001705e-001	1.984637e-002	0.000000e+000	0.000e+000	0.000e+000	4.579e-003
5	5	7.001709e-001	3.667173e-018	0.000000e+000	0.000e+000	0.000e+000	3.604e-003

Figure 9.22

2.9.20.2 Support Reactions

Analysis Result > Modal Combinations > Support Reactions displays the following dialog box (Figure 9.23). It allows you to view support reactions in modal combinations (including directional combinations). You must perform response spectrum analysis beforehand.

Note: The support reactions do not include multi-DOF constraint forces and moments.

	Node Id	Rx [kip]	Ry [kip]	Rz [kip]	Rox [kip-ft]	Roxy [kip-ft]	Roz [kip-ft]
1	1	88.743	261.292	0.000	0.000	0.000	822.806
2	2	133.124	0.000	0.000	0.000	0.000	1111.768
3	3	88.743	261.292	0.000	0.000	0.000	822.806
4	Sum	310.609	522.584	0.000	0.000	0.000	2757.380

Figure 9.23

2.9.20.3 Nodal, Line and Surface Spring Reactions

Analysis Result > Modal Combinations > Nodal, Line, Surface Spring Reactions a dialog box similar to Modal Combinations > Support Reactions above (Figure 9.23). You must perform response spectrum analysis beforehand.

2.9.20.4 Multi-DOF Constraint Forces & Moments

Analysis Result > Modal Combinations > Multi-DOF Constraint Forces & Moments displays the following dialog box (Figure 9.24). It allows you to view multi-DOF constraint forces & moments in modal combinations (including directional combinations). You must perform response spectrum analysis beforehand.

Constraint Id	Node-1	DOF-1	Value-1 [kip or kip-ft]	Node-2	DOF-2	Value-2 [kip or kip-ft]
1	2	X	2.424e+01	2	Y	4.848e+01

Figure 9.24

2.9.20.5 Member End Forces & Moments

Analysis Result > Modal Combinations > Member End Forces & Moments displays the following dialog box (Figure 9.25). It allows you to view member end forces and moments in modal combinations (including directional combinations). You must perform response spectrum analysis beforehand.

Member Id	Distance (%L)	Fx (Axial) [kip]	Fy (Major Shear) [kip]	Fz (Minor Shear) [kip]	Mx (Torsion) [kip-ft]	My (Minor Moment) [kip-ft]	Mz (Major Moment) [kip-ft]
3	0.000	0.002	56.545	0.000	0.000	0.000	882.274
4	0.000	0.002	56.545	0.000	0.000	0.000	814.066

Figure 9.25

2.9.20.6 Member Segmental Results

Analysis Result > Modal Combinations > Member Segmental Results displays the following dialog box (Figure 9.26). It allows you to view member segmental results in modal combinations (including directional combinations). You must perform response spectrum analysis beforehand.

Member Id	Distance (%L)	Fx (Axial) [kip]	Fy (Major Shear) [kip]	Fz (Minor Shear) [kip]	Mx (Torsion) [kip-ft]	My (Minor Moment) [kip-ft]	Mz (Major Moment) [kip-ft]	Dy (Major Deflection) [in]	Dz (Minor Deflection) [in]
3	0.000	0.002	56.545	0.000	0.000	0.000	882.274	0.000000e+000	0.000000e+000
2	0.050	0.002	56.545	0.000	0.000	0.000	797.457	7.056494e-002	0.000000e+000
3	0.100	0.002	56.545	0.000	0.000	0.000	712.640	1.206022e-001	0.000000e+000
4	0.150	0.002	56.545	0.000	0.000	0.000	627.824	1.522950e-001	0.000000e+000
5	0.200	0.002	56.545	0.000	0.000	0.000	543.007	1.678268e-001	0.000000e+000

Figure 9.26

2.9.20.7 Shell Forces & Moments

Analysis Result > Modal Combinations > Shell4 Forces & Moments displays the following dialog box (Figure 9.27). It allows you to view shell4 forces and moments in modal combinations (including directional combinations). You must perform response spectrum analysis beforehand.

	Shell Id	Node Id	Fxx [lb/in]	Fyy [lb/in]	Fxy [lb/in]	Mxx [lb-in/in]	Myy [lb-in/in]	Mxy [lb-in/in]	Vxx [lb/in]	Vyy [lb/in]
1	1	Center	0.000	0.000	0.000	0.000	0.000	0.003	0.000	0.000
2										
3	2	Center	0.000	0.000	0.000	0.000	0.000	0.002	0.000	0.001
4										
5	3	Center	0.000	0.000	0.000	0.000	0.000	0.002	0.000	0.001
6										
7	4	Center	0.000	0.000	0.000	0.000	0.000	0.002	0.000	0.001

Figure 9.27

2.9.20.8 Brick Stresses

Analysis Result > Modal Combinations > Brick Stresses displays the following dialog box (Figure 9.28). It allows you to view brick stresses in modal combinations (including directional combinations). You must perform response spectrum analysis beforehand.

	Brick Id	Node Id	Sx [N/m^2]	Sy [N/m^2]	Sz [N/m^2]	Sxy [N/m^2]	Syz [N/m^2]	Sxz [N/m^2]
1	1	Center	9.922e-006	2.076e-012	1.306e-016	3.625e-006	2.613e-014	4.459e-014
2								
3	2	Center	5.870e-006	5.561e-013	7.261e-017	3.476e-006	3.029e-014	3.112e-014
4								
5	3	Center	7.726e-007	1.490e-013	7.821e-018	3.115e-006	4.716e-014	1.885e-014
6								
7	4	Center	3.602e-006	4.033e-014	6.012e-017	2.503e-006	6.002e-014	1.127e-014

Figure 9.28

2.9.20.9 Base Shears

Analysis Result > Modal Combinations > Base Shears displays the following dialog box (Figure 9.29). It allows you to view modal base shears in X and Z directions. You can compare them with the base shears computed by equivalent lateral force procedure using relevant code such as ASCE 7-10. You must perform response spectrum analysis beforehand.

Base Shears are not computed by the program if the model contains multi-DOF constraints.



Figure 9.29

2.10 Concrete Design

The Concrete menu provides commands related to input, run, and output of concrete design for beams, columns, and slabs. With the exception of the cracking factors command, the commands here do not affect the analysis results. A static analysis must be done successfully before concrete design can be performed.

2.10.1 RC Materials

Concrete Design > RC Materials prompts you with the following dialog box (Figure 10.1). It allows you to define concrete and reinforcement strength properties for the existing materials. The strength properties include:

- Concrete compressive strength f_c
- Concrete reinforcement strength f_y
- Concrete stirrup or tie strength f_{ys}

If standard materials are used in Geometry > Materials, these strength properties will be set automatically. You may override these properties prior to performing concrete design. No concrete design will be performed on a member or shell if its f_c is zero.

You should not modify materials that are not concrete on this dialog.




Figure 10.1

2.10.2 Design Criteria

2.10.2.1 Design Criteria > Model Design Criteria

Concrete Design > Design Criteria > Model Design Criteria prompts you with the following dialog box (Figure 10.2). It allows you to enter global options for concrete design. You are encouraged to read the method of solution in the technical part of this document in order to understand these options. You should use this command before performing concrete design.




Figure 10.2

Design Code	Specifies design codes. Currently the program supports ACI 318-02/05/08/11 only.
Column min and max reinforcement ratios	Column minimum and maximum reinforcement ratios are used to generate column sections. They should be set between 1% and 8%. For all practical purposes, the maximum reinforcement ratio should be less than 4% to avoid rebar congestion.
Neutral axis steps for accuracy	Neutral axis steps affect the solution accuracy and speed. A value of 250 ~ 500 for neutral axis steps is sufficiently accurate for most sections. The adequacy of neutral axis steps can be determined by smoothness of the $P-M_x$ and/or $P-M_y$ interaction diagrams.
Biaxial angle steps	Biaxial angle steps affects the solution accuracy and speed. For biaxial problems, steps must be multiple of 4. A value of 16 or 32 is sufficiently accurate for most sections. The adequacy of biaxial angle steps can be determined by smoothness of the M_x-M_y interaction diagram. For uniaxial problems, biaxial angle steps should always be set to 4. This will give $P-M_x (+)$ at 0 degree angle, $P-M_x (-)$ at 180 degrees angle, $P-M_y (+)$ at 90 degree angle, $P-M_y (-)$ at 270 degrees angle.
Axial capacity steps for display	Specifies the number of axial steps for the display of interaction diagrams / surfaces and result data in the

Design Code	Specifies design codes. Currently the program supports ACI 318-02/05/08/11 only.
	spreadsheet. This value should be smaller than neutral axis steps. A value of 20 to 50 is usually adequate.
Exclude concrete displaced by steel	Should almost always be checked. This option is provided for verifications with textbooks only!
Always use 1.0 for Cm	If this option is checked, $C_m = 1.0$ will be used for all concrete columns. Otherwise, the program will compute C_m automatically based on moment curvature and the existence of transverse loading on the column.
Sustained load combination for computing Beta-d in columns	Specify the load combination that contains the all sustained load cases with each case load factor equal to 1.0.
Ignore compressive force in concrete shear capacity	Specify whether or not to ignore the increase in column concrete shear capacity due to the influence of compressive force. Axial forces are ignored on concrete beams.
Check capacity at column ends only	If this option is checked, column capacity is checked at its ends only. Otherwise, column capacity is checked at every station along the column that analysis outputs.
Compute minimum moment	If this option is checked, a minimum moment $P_u * (0.6 + 0.03h)$ is used for design
Automatically compute support widths	Select this option so that flexural design starts at the support faces and shear design starts at a distance of 'd' from the face of support.
Slab/plate min. reinf. ratios	Specify slab/plate minimum top and bottom reinforcement ratios for design. According to ACI 318-02/05/08/11 7.12.2.1, area of shrinkage and temperature reinforcement shall provide at least 0.18% of gross concrete area.

2.10.2.2 Design Criteria > Beam Design Criteria

Concrete Design > Design Criteria > Beam Design Criteria prompts you with the following dialog box (Figure 10.3). It allows you to define and/or assign different design criteria to selected concrete beams. An Id is assigned automatically to each design criterion by the program and may not be changed. You may assign a label with 127 maximum characters to each design criterion for easy identification. The beam design criteria include:

- Number of stirrup legs.
- Stirrup bar size.

- Bottom and top concrete covers measured from section edge to the centroid of longitudinal bars.

You may add one or more criteria by clicking the “New Rows” button. You may also print all design criteria in the list by clicking the “Print” button. The “Assign active criteria to selected members” checkbox may be used to assign the active beam design criterion to selected beams. The active criterion refers to the one that currently has focus in the list in the dialog box. In order for beam design criteria assignments to take place, beams must be selected beforehand.

The program always has a default beam design criterion labeled “Default”. You may not delete this criterion or change its label. You may however change its properties.




Figure 10.3

2.10.2.3 Design Criteria > Column Design Criteria

Concrete Design > Design Criteria > Column Design Criteria prompts you with the following dialog box (Figure 10.4). It allows you to define and/or assign different design criteria to selected concrete columns. An Id is assigned automatically to each design criterion by the program and may not be changed. You may assign a label with 127 maximum characters to each design criterion. The column design criteria include:

- Sway flags in x and y directions.
- Unbraced lengths in x and y directions. You may enter zero if you want the program to use the member lengths as the unbraced lengths.
- Effective length factors in x and y directions.

- Number of tie legs.
- Tie bar size.
- Concrete cover to the outside surface of ties. Since different longitudinal bar sizes may be used during automatic section generation, the program computes concrete cover to bar center based on the following formula: “cover to tie” + “tie diameter” + one half of “longitudinal bar diameter” *Note: This is different from concrete cover for beams.*
- Start and end bar trial sizes for section generation.
- Bar layout. 0=bars will be placed on all sides of the section; 1=bars will be placed only on the sides parallel to the section major axis; 2=bars will be placed only on the sides parallel to the section minor axis; 3=bars will be distributed equally on all sides.
- Confinement: Confining reinforcement can be either tied or spiral. Spiral applies to circular sections only.




Figure 10.4

You may add one or more criteria by clicking the “New Rows” button. You may also print all design criteria in the list by clicking the “Print” button. The “Assign active criteria to selected members” checkbox may be used to assign the active column design criterion to selected columns. The active criterion refers to the one that currently has focus in the list in the dialog box. In order for column design criteria assignments to take place, columns must be selected beforehand.

The program always has a default column design criterion labeled “Default”. You may not delete this criterion or change its label. You may however change its properties.

2.10.2.4 Design Criteria > Plate Design Criteria

Concrete Design > Design Criteria > Plate Design Criteria prompts you with the following dialog box (Figure 10.5). It allows you to define and/or assign different design criteria to selected concrete plates. An Id is assigned automatically to each design criterion by the program and may not be changed. You may assign a label with 127 maximum characters to each design criterion. The plate design criteria include:

- Bottom-x, bottom-y, top-x and top-y concrete covers measured from plate edge to the centroid of bars

You may add one or more criteria by clicking the “New Rows” button. You may also print all design criteria in the list by clicking the “Print” button. The “Assign active criteria to selected shells” checkbox may be used to assign the active plate design criterion to selected plates. The active criterion refers to the one that currently has focus in the list in the dialog box. In order for plate design criteria assignments to take place, plates must be selected beforehand.

The program always has a default plate design criterion labeled “Default”. You may not delete this criterion or change its label. You may however change its properties.




Figure 10.5

2.10.2.5 Design Criteria > Exclude Elements

Concrete Design > Design Criteria > Exclude Elements prompts you with the following dialog box (Figure 10.6). It allows you to include or exclude concrete design for selected beams, columns, and plates. For example, you might want to exclude some plate elements (such as those near supports) from concrete design where large stress spikes are present. Plate envelope contours do not include the excluded shell elements. This makes the contour bands appear more distinct from each other.




Figure 10.6

2.10.2.6 Design Criteria > Cracking Factors

Concrete Design > Design Criteria > Cracking Factors prompts you with the following dialog box (Figure 10.7). It allows you to assign cracking factors to selected beams, columns, and plates. Cracking factors apply only to bending stiffness of members and shell elements.

Note: Cracking factors are not considered by the program unless you check the option “Use cracked section properties (Icr) for members and finite elements” in Analyze > Analysis Options. Analysis results are cleared after assignment of cracking factors.




Figure 10.7

2.10.3 Assign

2.10.3.1 Assign > Beam Design Properties

Concrete Design > Assign > Beam Member Properties prompts you with the following dialog box (Figure 10.8). It allows you to *continuously* assign concrete beam design properties to members. After clicking “Assign”, you can start to *continuously* assign concrete beam design properties by window-selecting members until you right click the mouse or press the ESC key.




Figure 10.8

2.10.3.2 Assign > Column Design Properties

Concrete Design > Assign > Column Member Properties prompts you with the following dialog box (Figure 10.9). It allows you to *continuously* assign concrete column design properties to members. After clicking “Assign”, you can start to *continuously* assign concrete column design properties by window-selecting members until you right click the mouse or press the ESC key.





Figure 10.9

2.10.3.3 Assign > Plate Design Properties

Concrete Design > Assign > Plate Member Properties prompts you with the following dialog box (Figure 10.10). It allows you to *continuously* assign concrete plate design properties to shells. After clicking “Assign”, you can start to *continuously* assign concrete plate design properties by window-selecting shells until you right click the mouse or press the ESC key.



The dialog box titled "Assign Concrete Plate Design Properties" features a red close button in the top right corner. It contains three rows of settings, each with a "Use" checkbox on the right:

- Design Criteria:** A dropdown menu showing "1: Default" and a "Use" checkbox.
- Design Exclusion:** A dropdown menu showing "Included" and a "Use" checkbox.
- Cracking Factor:** A text input field containing the value "1" and a "Use" checkbox.

Below these settings is a checked checkbox labeled "Assign entries to currently selected shells". At the bottom, there are four buttons: "Use All", "Clear Use", "Assign" (highlighted with a blue border), and "Cancel".

Figure 10.10

2.10.4 Design Input

2.10.4.1 Design Input > RC Member Input

Concrete Design > Design Input > RC Member Input prompts you with the following dialog box (Figure 10.11). It allows you to enter beams and columns for concrete design in a spreadsheet. Each element includes the class ("B" for beam, "C" for column), design criteria Id, cracking factor, and exclusion design flag (0 for included, 1 for excluded). The element cracking factor with a value between 0 (fully cracked) and 1 (uncracked) applies to the moments of inertia of member elements. You may not modify the member Id. Design criteria Ids must be valid (defined). Beam and column design criteria combo boxes are provided for you to correctly pick and apply proper element class and design criteria to selected members.




Figure 10.11

2.10.4.2 Design Input > RC Plate Input

Concrete Design > Design Input > RC Plate Input prompts you with the following dialog box (Figure 10.12). It allows you to enter plates for concrete design in a spreadsheet. Each element includes design criteria Id, cracking factor, and exclusion design flag (0 for included, 1 for excluded). The element cracking factor with a value between 0 (fully cracked) and 1 (uncracked) applies to the moments of inertia of member elements. You may not modify the plate (shell) Id. Design criteria Ids must be valid (defined). Plate design criteria combo box is provided for you to correctly pick and apply proper element design criteria to selected shells.




Figure 10.12

2.10.5 Perform Design

Concrete Design > Perform Design performs the concrete design based on the design criteria and design input. You must run the analysis successfully prior to running this command.

2.10.6 Design Output

2.10.6.1 Design Output > RC Analysis Envelope

Concrete Design > Design Output > RC Analysis Envelope displays the following dialog box (Figure 10.13). It allows you to view the negative and positive moment envelope as well as the shear envelope for concrete design. You have the option to view the envelope for the selected beams/columns only.

Note: The envelope only considers the load combinations that are designated for concrete design.

Member Envelope for Concrete Design

Load Combination: 1: Default Show selected only Print... Save... Close

	Member Id	Distance (%L)	max Mz [Major Moment] [kip-ft]	min Mz [Major Moment] [kip-ft]	abs Fy [Major Shear] [kip]	max Mz Comb#	min Mz Comb#	abs Fz Comb#
1	1	0.000	0.000	-294.568	99.212	1	3	3
2		0.050	0.000	-160.513	88.409	1	3	3
3		0.100	0.000	-41.896	77.606	1	3	3
4		0.110	0.000	-21.096	75.506	4	3	3
5		0.111	1.145	-18.968	75.292	4	3	3
6		0.115	6.608	-8.817	74.267	4	3	3
7		0.120	11.352	0.000	73.377	4	1	3
8		0.150	67.309	0.000	66.802	2	1	3
9		0.200	151.011	0.000	55.999	2	1	3
10		0.250	221.329	0.000	45.196	3	1	3
11		0.300	278.195	0.000	34.393	3	1	3

Figure 10.13

2.10.6.2 Design Output > RC Beam Results

Concrete Design > Design Output > RC Beam Results displays the following dialog box (Figure 10.14). It allows you to view top and bottom required steel for flexure and their corresponding design moments at every analysis output station along the member. You have the option to view the RC beam results for the selected beams only.

Concrete Beam Design Result

Show selected only Print... Save... Close

	Member Id	Distance (%L)	fc [kip/in ²]	fy [kip/in ²]	Bot-Mu [kip-ft]	Bot-As [in ²] (-1.0 means section too small)	Top-Mu [kip-ft]	Top-As [in ²] (-1.0 means section too small)
1	1							
2	Rect36x19.5	0.000	4.0	60.0	0.000	2.04	-232.028	3.18
3		0.050	4.0	60.0	0.000	2.04	-160.513	2.17
4		0.100	4.0	60.0	0.000	2.04	-41.896	0.55
5		0.110	4.0	60.0	0.000	2.04	-21.096	0.28
6		0.111	4.0	60.0	1.145	2.04	-18.968	0.25
7		0.115	4.0	60.0	6.608	2.04	-8.817	0.12
8		0.120	4.0	60.0	11.352	2.04	0.000	0.00
9		0.150	4.0	60.0	67.309	2.04	0.000	0.00
10		0.200	4.0	60.0	151.011	2.04	0.000	0.00
11		0.250	4.0	60.0	221.329	3.03	0.000	0.00

Figure 10.14

2.10.6.3 Design Output > RC Column Results

Concrete Design > Design Output > RC Column Results displays the following dialog box (Figure 10.15). It allows you to view the final column design sections and their capacity ratios. Some intermediate results such as moment magnification factors,

Beta-d and Cm's are output as well. You have the option to view the RC column results for the selected columns only.

Concrete Column Design Result

Load Combination: 1: Default Show selected only Print... Save... Close

Member Id	Section	Unity Check	Comb	Distance (%)	P [kip]	Mz [kip-ft]	My [kip-ft^2]	Mz-Factor	My-Factor	Beta-d	Cmx	Cmy
1	Y003_cc2.375	0.835	2	0.00	134.400	-94.400	0.000	1.000	2.019	0.714	0.439	0.439
2	Y002_cc2.375	0.792	2	0.00	82.400	-68.480	0.000	1.191	1.453	0.728	0.899	0.899

Figure 10.15

2.10.6.4 Design Output > Flexural/Axial Interaction > Sections

Concrete Design > Design Output > Flexural/Axial Interaction > Sections displays all column sections generated by the program based on the input of material, section and column design criteria (Figure 10.16).

Concrete Column Sections

Section	Label
1	Rect_BH14x14_fc3_fy60_Bars004#8_NX002_NY002_cc2.375
2	Rect_BH14x14_fc3_fy60_Bars006#8_NX002_NY003_cc2.375
3	Rect_BH14x14_fc3_fy60_Bars008#8_NX002_NY004_cc2.375
4	Rect_BH14x14_fc3_fy60_Bars010#8_NX002_NY005_cc2.375

Width (b): 14 in

Height (h): 14 in

fc: 3 kip/in²

fy: 60 kip/in²

Cover to bar center: 2.375 in

Bar size: #8

Top bars: 2

Bottom bars: 2

Left bars: 2

Right bars: 2

As: 3.16 in²

Ag: 196 in²

Reinf. ratio: 1.61 %

OK

Figure 10.16

2.10.6.5 Design Output > Flexural/Axial Interaction > P-Mx (+)

Concrete Design > Design Output > Flexural/Axial Interaction > P-Mx (+) displays the $P-M_x$ result data in a spreadsheet, with positive moment about the section major axis (at biaxial angle of 0 degree) (Figure 10.17).

	Neutral Axis Depth [in]	phi * Pn [kip]	phi * Mnx [kip-ft]	Eccentricity [in]	Maximum Steel Tensile Strain	Phi
1	[Pure Compression]	354.298	0.000	0.00	0.00000	0.650
2	14.27	354.297	39.350	1.33	0.00000	0.650
3	13.47	336.583	46.384	1.65	0.00000	0.650
4	12.77	318.868	52.659	1.98	0.00000	0.650
5	12.10	301.153	58.328	2.32	0.00000	0.650
6	11.63	288.296	62.090	2.58	0.00000	0.650
7	11.45	283.438	63.430	2.69	0.00005	0.650
8	10.82	265.723	68.013	3.07	0.00022	0.650
9	10.21	248.008	72.154	3.49	0.00042	0.650
10	9.92	239.171	74.082	3.72	0.00052	0.650
11	9.63	230.294	75.912	3.96	0.00062	0.650
12	9.07	212.579	79.351	4.48	0.00085	0.650
13	8.64	198.692	81.875	4.94	0.00103	0.650
14	8.53	194.864	82.540	5.08	0.00109	0.650
15	8.02	177.149	85.539	5.79	0.00135	0.650
16	7.55	159.434	88.216	6.64	0.00162	0.650
17	7.14	141.719	90.140	7.63	0.00189	0.650
18	[Balanced] 6.88	129.972	91.383	8.44	0.00207	0.650
19	6.40	124.004	93.917	9.09	0.00246	0.683
20	5.24	106.289	99.900	11.28	0.00366	0.786
21	4.44	88.574	103.863	14.07	0.00486	0.888

Figure 10.17

2.10.6.6 Design Output > Flexural/Axial Interaction > P-Mx (-)

Concrete Design > Design Output > Flexural/Axial Interaction > P-Mx (-) displays the $P-M_x$ result data in a spreadsheet, with negative moment about the section major axis (at biaxial angle of 180 degrees).

2.10.6.7 Design Output > Flexural/Axial Interaction > P-My (+)

Concrete Design > Design Output > Flexural/Axial Interaction > P-My (+) displays the $P-M_y$ result data in a spreadsheet, with positive moment about the section minor axis (at biaxial angle of 90 degrees).

2.10.6.8 Design Output > Flexural/Axial Interaction > P-My (-)

Concrete Design > Design Output > Flexural/Axial Interaction > P-My (-) displays the $P-M_y$ result data in a spreadsheet, with negative moment about the section minor axis (at biaxial angle of 270 degrees).

2.10.6.9 Design Output > Flexural/Axial Interaction > P-Mx-My

Concrete Design > Design Output > Flexural/Axial Interaction > P-Mx-My displays the $P-M_x-M_y$ result data in a spreadsheet at each biaxial angle step and axial capacity step.

2.10.6.10 Design Output > Flexural/Axial Interaction > Print Diagrams

Concrete Design > Design Output > Flexural/Axial Interaction > Print Diagrams allows you to view and print the interaction diagrams for each column section (Figure 10.18). The red and blue lines are the interaction diagrams about section major and minor axes respectively. A sketch of the section and the key control points are listed above the diagrams as well.




Figure 10.18

2.10.6.11 Design Output > Member Shear Design Results

Concrete Design > Design Output > Member Shear Design displays the following dialog box (Figure 10.19). It allows you to view the required stirrup (tie) spacing for concrete beam and column shear design. You have the option to view the shear design results for the selected beams and columns only.

Member Id	Distance (%L)	fc [kip/in ²]	fys [kip/in ²]	Stirrup/tie-size	Stirrup/tie-legs	Shear [kip]	Axial [kip]	Stirrup/tie-spacing [in] (blank means stirrup)	phi*Vc [kip]	
1										
2	Rect14x14	0.000	3.0	60.0	#3	2	6.207	-134.400	14.00	17.956
3		0.050	3.0	60.0	#3	2	6.207	-134.400	14.00	17.956
4		0.100	3.0	60.0	#3	2	6.207	-134.400	14.00	17.956
5		0.150	3.0	60.0	#3	2	6.207	-134.400	14.00	17.956
6		0.200	3.0	60.0	#3	2	6.207	-134.400	14.00	17.956
7		0.250	3.0	60.0	#3	2	6.207	-134.400	14.00	17.956
8		0.300	3.0	60.0	#3	2	6.207	-134.400	14.00	17.956
9		0.350	3.0	60.0	#3	2	6.207	-134.400	14.00	17.956

Figure 10.19

2.10.6.12 Design Output > Wood-Armer Moments

Concrete Design > Design Output > Wood-Armer Moments displays the following dialog box (Figure 10.20). It allows you to view the critical Wood-Armer moments (top and bottom, local-x and local y directions) and the corresponding load combinations for concrete plates (shells). These moments are used directly in computing the required plate reinforcement areas. You have the option to view the Wood-Armer moments for the selected plates only.

Shell Id	Node Id	Bot-Mux [lb-ft/ft]	Bot-Muy [lb-ft/ft]	Top-Mux [lb-ft/ft]	Top-Muy [lb-ft/ft]	Bot-Mux Comb#	Bot-Muy Comb#	Top-Mux Comb#	Top-Muy Comb#
1	Center	0.000	0.000	-142.359	-142.359	1	1	1	1
2	1	70.562	70.562	-70.562	-70.562	1	1	1	1
3	2	0.000	0.000	-37.226	-182.156	1	1	1	1
4	33	87.841	87.841	-420.614	-420.614	1	1	1	1
5	32	0.000	0.000	-182.156	-37.226	1	1	1	1
6									
7	Center	0.000	0.000	-268.337	-528.902	1	1	1	1
8	2	0.000	0.000	-37.226	-182.156	1	1	1	1
9	3	0.000	0.000	-114.790	-703.897	1	1	1	1
10	34	249.798	0.000	-500.717	-808.940	1	1	1	1
11	33	87.841	87.841	-420.614	-420.614	1	1	1	1

Figure 10.20

2.10.6.13 Design Output > RC Plate Results

Concrete Design > Design Output > RC Plate Results displays the following dialog box (Figure 10.21). It allows you to view the required plate reinforcement areas (top and bottom, local-x and local y directions) and the corresponding Wood-Armer moments for concrete plates (shells). You have the option to view the plate design results for the selected plates only.

Concrete Plate Design Result

Show selected only
 Print...
Save...
Close

	Shell Id	Node Id	Design-H [in]	fc [kip/in ²]	fy [kip/in ²]	Bot-Mux [lb-ft/ft]	Bot-Muy [lb-ft/ft]	Top-Mux [lb-ft/ft]	Top-Muy [lb-ft/ft]	Bot-Assx [in ² /ft]	Bot-Assy [in ² /ft]	Top-Assx [in ² /ft]	Top-Assy [in ² /ft]
1	1	Center	6.50	4.0	60.0	0.000	0.000	-142.359	-142.359	0.000	0.000	0.006	0.006
2		1	6.50	4.0	60.0	70.562	70.562	-70.562	-70.562	0.003	0.003	0.003	0.003
3		2	6.50	4.0	60.0	0.000	0.000	-37.226	-182.156	0.000	0.000	0.002	0.008
4		33	6.50	4.0	60.0	87.841	87.841	-420.614	-420.614	0.004	0.004	0.018	0.018
5		32	6.50	4.0	60.0	0.000	0.000	-182.156	-37.226	0.000	0.000	0.008	0.002
6													
7	2	Center	6.50	4.0	60.0	0.000	0.000	-268.337	-528.902	0.000	0.000	0.011	0.022
8		2	6.50	4.0	60.0	0.000	0.000	-37.226	-182.156	0.000	0.000	0.002	0.008
9		3	6.50	4.0	60.0	0.000	0.000	-114.790	-703.897	0.000	0.000	0.005	0.030
10		34	6.50	4.0	60.0	249.798	0.000	-500.717	-808.940	0.011	0.000	0.021	0.034
11		33	6.50	4.0	60.0	87.841	87.841	-420.614	-420.614	0.004	0.004	0.018	0.018

Figure 10.21

2.10.7 Diagrams

2.10.7.1 Diagrams > RC Member Envelope Diagram

Concrete Design > Diagrams > RC Member Envelope Diagram displays the following dialog box (Figure 10.22). It allows you to view the required flexural reinforcement as well as the moment and shear envelope used for designing concrete beams. It also allows you to view required stirrup or tie spacing for concrete beams and columns. You have the option to view the member envelope diagrams for the selected members only.




Figure 10.22

2.10.7.2 Diagrams > RC Plate Envelope Contour

Concrete Design > Diagrams > RC Plate Envelope Contour displays the following dialog box (Figure 10.23). It allows you to view the required flexural reinforcement as well as the Wood-Armer moments (top and bottom, local x and y directions) for concrete plates (shells). You have the option to view the plate envelope contours for the selected plates only.




Figure 10.23

2.10.8 RC Report

Concrete Design > RC Report displays the following dialog box (Figure 10.24). It allows you to print concrete design report on beams and columns. You have the options to include flexural design for concrete beams, axial-flexural design for concrete columns as well as shear design for concrete beams and columns. You also have the option to print the report on selected members only.




Figure 10.24

Figure 10.25 shows the print preview for a column axial-flexural design report.




Figure 10.25

2.10.9 RC Tools

2.10.9.1 RC Tools > Rebar Database

Concrete Design > RC Tools > Rebar Database displays the following dialog box (Figure 10.26). It allows you to select different rebar databases for use in concrete design.




Figure 10.26

2.10.9.2 RC Tools > K Calculator

Concrete Design > RC Tools > K Calculator (Figure 10.27) allows you to accurately calculate effective length factors (braced and unbraced Ks) based on the beam and column relative stiffness input.




Figure 10.27

2.10.9.3 RC Tools > Quick Rectangular Beam Flexural Design

Concrete Design > RC Tools > Quick R-Beam Flexural Design (Figure 10.28) allows you to quickly design a rectangular concrete beam according to ACI 318-02/05/08/11/14. Minimum reinforcement may be optionally computed. You have the option to design the rectangular beam as singly or doubly reinforced. A negative reinforcement area means the design fails.

Compute Rectangular Beam Flexural Reinforcement

✕

Flexural reinforcement of rectangular beam according to ACI318-02, -05, -08 and -11

<p>Width (b): <input style="width: 60px;" type="text" value="10"/> in</p> <p>Height (h): <input style="width: 60px;" type="text" value="20"/> in</p> <p>Top cover: <input style="width: 60px;" type="text" value="2.5"/> in</p> <p>Bottom cover: <input style="width: 60px;" type="text" value="4"/> in</p>	<p>fc: <input style="width: 60px;" type="text" value="4"/> kip/in²</p> <p>fy: <input style="width: 60px;" type="text" value="60"/> kip/in²</p> <p>Mu: <input style="width: 60px;" type="text" value="211"/> kip-ft</p>
---	--

Compute minimum reinforcement
 Singly reinforced only

<div style="border: 2px solid blue; padding: 5px; display: inline-block;">Compute</div>	<p>As: <input style="width: 60px;" type="text" value="3.484"/> in²</p> <p>As': <input style="width: 60px;" type="text" value="0.702"/> in²</p>	<div style="border: 1px solid gray; padding: 5px; display: inline-block;">Close</div>
---	--	---

Figure 10.28

2.10.9.4 RC Tools > Quick Tee Beam Flexural Design

Concrete Design > RC Tools > Quick T-Beam Flexural Design (Figure 10.29) allows you to quickly design a concrete tee beam according to ACI 318-02/05/08/11/14. Minimum reinforcement may be optionally computed. The tee beam is always designed as singly reinforced. A negative reinforcement area means the design fails.

Compute Tee Beam Flexural Reinforcement

Flexural reinforcement of rectangular beam according to ACI318-02, -05, -08 and -11

Width (b): 47 in

Height (h): 22.5 in

Flange: 3 in

Web width: 11 in

Bottom cover: 2.5 in

fc: 3 kip/in²

fy: 60 kip/in²

Mu: 533.3 kip-ft

Compute minimum reinforcement

Compute As: 6.456 in²

Close

Figure 10.29

2.11 Steel Design

2.11.1 Steel Materials

Steel Design > Design Criteria > Steel Materials prompts you with the following dialog box (Figure 11.1). It allows you to define steel strength properties for the existing materials. The strength properties include:

- Steel yield stress F_y
- Steel rupture stress F_u

If standard materials are used in Tables > Material Data, these strength properties will be set automatically. You may override these properties prior to performing steel design. No steel design will be performed on a member if its modulus is not close (within 10%) to 29E3 ksi. You should not modify materials that are not steel on this dialog.




Figure 11.1

2.11.2 Design Criteria

2.11.2.1 Model Design Criteria

Steel Design > Design Criteria > Model Design Criteria prompts you with the following dialog box (Figure 11.2).

Use Direct Design Method currently only affects how the moment magnification factor B1 is calculated. You also have the option not to consider moment magnification factor B1 altogether. Please be advised that P-Delta analyses should be performed on load combinations that are used for steel design.

To be conservative, you can always use 1.0 for Cm that accounts for nonuniform moment. Uncheck the Always use 1.0 for Cm” if you would like the program to calculate Cm for automatically.

Model Steel Design Options ✕

Design code: AISC 14th Edition (360-10) LRFD ▼

Use Direct Design Method

Consider moment magnification factor B1
(P-delta effect associated with individual member curvature)

Always use 1.0 for Cm (Uncheck this box to compute automatically)

Check capacity at column ends only

Only use sections from the Section Pool (defined in Steel Design | Criteria Criteria | Section Pool) during design

Connector distance for double angles: 0 ft

Maximum number of steel section candidates: 10

Total load deflection denominator
e.g. 240 means the total deflection will be limited to L/240: 240

Live load deflection denominator
e.g. 360 means the total deflection will be limited to L/360: 360

OK Cancel

Figure 11.2

You have the option to only use sections defined in Steel Design > Design Criteria > Section Pool during the design process. This is useful if you do not want the program to use too many steel section sizes for the entire model.

Connector distance for double angles is used for sections that are double angles.

The default number of section candidates designed for each member is 10.

You can also specify limits for total load deflection and live load deflection.

2.11.2.2 Member Design Criteria

Steel Design > Design Criteria > Member Design Criteria prompts you with the following dialog box (Figure 11.3). It allows you to define and assign design criteria for members.

An Id is assigned automatically to each design criterion by the program and may not be changed. You may assign a label with 127 maximum characters to each design criterion. The column design criteria include:

- Section Prefix, which is a comma delimited list. For example, if you want the member section to be with W10 or W12 size, enter the prefix as “w10,w12”. You also specify the prefix as the exact AISC shapes. Use the prefix “Default” if you do not want the member section changed from the original shape.
- Sway flags in x and y directions.
- The length between points that are braced against lateral displacement of compression flange Lb. Currently, the program only supports equal Lb along the member length. For non-continuously braced, the program will use the member length for Lb if the value is entered 0. For continuously braced, 0 must be entered for Lb.




Figure 11.3

- Lateral-torsional buckling modification factor for nonuniform moment diagrams C_b. The program will automatically calculate C_b if the value is entered 0. You can always use C_b = 1.0 for conservative reasons.
- Unbraced lengths in x, y and z directions. You may enter zero if you want the program to use the member lengths as the unbraced lengths.
- Effective length factors in x, y and z directions.
- You have the option to set the maximum capacity ratio. By default, this ratio is 1.0. You can set a value less than 1.0 (but greater than 0.0) for conservative reasons.

2.11.2.3 Section Pool

Steel Design > Design Criteria > Section Pool prompts you with the following dialog box (Figure 11.4). It allows you to define a list of sections that may be used exclusively for design.

You can copy a list of section labels from the AISC table. You can also enter sections manually. Each line in the section pool box can only contain one section. Furthermore, you can automatically add all the section candidates to the section pool (from Steel > Design Results).




Figure 11.4

2.11.2.4 Exclude Elements

Steel Design > Design Criteria > Exclude Elements prompts you with the following dialog box (Figure 11.5). It allows you to include or exclude steel design for selected members.




Figure 11.5

2.11.3 Assign Member Design Properties

Steel Design > Assign Member Design Properties prompts you with the following dialog box (Figure 11.6). It allows you to continuously assign steel design properties to members. After clicking “Assign”, you can start to continuously assign steel design properties by window-selecting members until you right click the mouse or press the ESC key.




Figure 11.6

2.11.4 Steel Member Input

Steel Design > Design Input > Steel Member Input prompts you with the following dialog box (Figure 11.7). It allows you to enter members for steel design in a spreadsheet. Each element includes the design criteria Id, and exclusion design flag (0 for included, 1 for excluded). You may not modify the member Id. Design criteria Ids must be valid (defined). Steel design criteria combo box is provided for you to correctly pick and apply proper steel design criteria to selected members.




Figure 11.7

2.11.5 Perform Design

The Steel Design > Perform Design menu allows you to run the steel design.

2.11.6 Design Results

The Steel Design > Design Results allows you to view the steel design results (Figure 11.8). It also allows you to update member sections.




Figure 11.8

The section column on Figure 11.8 includes a combobox that contains the member original section (first entry in the combobox) and designed section candidates (second or more entries in the combobox). You can change the member sections by picking the proper section candidates. Please be advised you need to re-analyze and design after one or more member sections are updated.

In addition, you can add all the section candidates to Section Pool, which can be used in the next round of design.

Finally, you can view the detailed calculation procedure for each member for the most critical load condition.

2.11.7 Steel Tools

2.11.7.1 K Calculator

Steel Design > Steel Tools > K Calculator offers a tool to calculate the K value of columns by entering the ratios of the sum of the EI/L values at the top and bottom of the column segment.

2.11.7.2 Section Check

Steel Design > Steel Tools > Section Check (Figure 11.9) allows you to perform steel section capacity check.

L_{ux} , L_{uy} and L_{uz} are unbraced lengths in local x, y and z directions.
 K_x , K_y and K_z are unbraced length factors in local x, y and z directions.

L_b is the unbraced lateral length.
 C_b is the lateral-torsional buckling modification factor for non-uniform moment diagrams. It should be greater or equal to 1.0. You can use 1.0 for C_b conservatively.

Connector Distance is used for double angles only.

Steel Beam-Column Check

Code: Consider Moment Magnification

Section: Use Direct Design Method Steel Yield Stress (Fy): ksi

Geometry

Length: ft L_b : ft C_b : Connector Distance (for double angles only): ft

L_{ux} : ft L_{uy} : ft L_{uz} : ft

K_x : K_y : K_z :

Load Effects & Results:

	P_u (kip)	M_{ux} (kip-ft)	M_{uy} (kip-ft)	V_{ux} (kip)	V_{uy} (kip)	C_{mx}	C_{my}	$\phi-P_n$ (kip)	$\phi-M_{nx}$ (kip-ft)	$\phi-M_{ny}$ (kip-ft)	$\phi-V_{nx}$ (kip)	$\phi-V_{ny}$ (kip)	B_{1x}	B_{1y}	Critical Ratio
1	497.145	450.59						66.15	212.447	204.021	1.0000	1.0000	0.0000		
2															
3															
4															
5															
6															
7															
8															
9															
10															
11															
12															
13															
14															
15															

Figure 11.9

P_u , M_{ux} , M_{uy} , V_{ux} , V_{uy} are required axial, major moment, minor moment, major shear and minor shear. For P_u , the compressive force is positive while tensile force is negative. Moment M_{ux} is positive when section top most fiber is under compression. Moment M_{uy} is positive when section rightmost fiber is under compression. Moment magnification may be optionally considered to account for the P-delta ($P-\delta$) effect.

If direct design method is chosen, the program will calculate stiffness reduction parameter based on Eq. C2-2a and C2-2b of the code.

C_{mx} , C_{my} are coefficients accounting for non-uniform moments when computing moment magnification. You can use 1.0 for C_{mx} and C_{my} conservatively. If C_{mx} or C_{my} is 0, 1.0 is used in the computation instead.

Results include axial capacity ($\phi-P_n$), moment capacity ($\phi-M_{nx}$, $\phi-M_{ny}$), shear capacity ($\phi-V_{nx}$, $\phi-V_{ny}$), moment magnification factors (B_{1x} , B_{1y}) and critical ratio. The section is deemed safe to resist a load if the critical ratio is less than 1.0, otherwise, the section is deemed unsafe. Please note that for single angle, the moment capacity is given about the principal axes (w-w and z-z).

The following is produced by sCheck, Computations
& Graphics, Inc.

08/21/14 19:10:38

W12X65 - using AISC 360-10 LRFD Method

Section Input

Section W12X65

$A = A_g = 19.1 \text{ in}^2$; $bf = 12 \text{ in}$; $tf = 0.605 \text{ in}$; $tw = 0.39 \text{ in}$; $d = 12.1 \text{ in}$; $h/tw = 24.9$; $C_w = 5780 \text{ in}^6$; $h_0 = 11.5 \text{ in}$; $r_{ts} = 3.38 \text{ in}$;

$Z_x = 96.8 \text{ in}^3$; $S_x = 87.9 \text{ in}^3$; $I_x = 533 \text{ in}^4$; $r_x = 5.28 \text{ in}$; $Z_y = 44.1 \text{ in}^3$; $S_y = 29.1 \text{ in}^3$; $I_y = 174 \text{ in}^4$; $r_y = 3.02 \text{ in}$; $J = 2.18 \text{ in}^4$;

Using Direct Design Method; Consider Multiplier B1 for P- δ Effect

$P_u = P_r = 15 \text{ kips}$; $M_{ux} = M_{xr} = 180 \text{ kip-ft}$; $M_{uy} = M_{yr} = 5 \text{ kip-ft}$; $C_{mx} = 1$; $C_{my} = 1$; $V_{ux} = 2.3 \text{ kips}$; $V_{uy} = 1.1 \text{ kips}$;

$F_y = 36 \text{ ksi}$; $C_b = 1$; $L_b = 12 \text{ ft}$; $K_x = 1$; $K_y = 1$; $K_z = 1$; $L_x = 12 \text{ ft}$; $L_y = 12 \text{ ft}$; $L_z = 12 \text{ ft}$;

Axial Capacity Calculation

$$b = bf / 2$$

$$\text{Unstiffened } b / tf = 9.91736$$

$$0.56 \sqrt{\frac{E}{F_y}}$$

$$= 15.8941$$

$$\frac{b}{t} \leq 0.56 \sqrt{\frac{E}{F_y}}$$

$$Q_s = 1.0 \quad (\text{E7-4})$$

$$= 1$$

$$\text{Stiffened } b / t = h / tw = 24.9$$

$$\lambda_r = 1.49 \sqrt{\frac{E}{F_y}}$$

$$= 42.2896$$

The section has non-slender stiffened element

$$Q_a = 1$$

Compressive strength to account for Flexural Buckling

$$\frac{K_x L_x}{r_x}$$

$$= 27.2727$$

$$\frac{K_y L_y}{r_y}$$

$$= 47.6821$$

$$\frac{KL}{r} = \max\left(\frac{K_x L_x}{r_x}, \frac{K_y L_y}{r_y}\right)$$

$$= 47.6821$$

$$F_e = \frac{\pi^2 E}{\left(\frac{KL}{r}\right)^2} \tag{E3-4}$$

$$= 125.889 \text{ ksi}$$

$$4.71 \sqrt{\frac{E}{F_y}}$$

$$= 133.681$$

$$\frac{KL}{r} \leq 4.71 \sqrt{\frac{E}{F_y}}$$

$$F_{cr} = \left[0.658 \frac{F_y}{F_e} \right] F_y \tag{E3-2}$$

$$= 31.939 \text{ ksi}$$

$$P_n = F_{cr} A_g \tag{E3-1}$$

$$= 610.035 \text{ kips}$$

Flexural Buckling Controls: Pn = 610.035 kips

$$\phi_c P_n$$

$$= 549.031 \text{ kips}$$

Moment Magnification Calculation

$$\alpha = 1.00 \text{ (LRFD)}$$

$$P_r / P_y = 0.021815$$

$$\alpha P_r / P_y \leq 0.5$$

$$\begin{aligned} \tau_b &= 1.0 && \text{(C2-2a)} \\ &= 1 \end{aligned}$$

Moment magnifier B1 for P-delta effects in local x direction

$$Pr / Py = 0.021815$$

$$\alpha Pr / Py \leq 0.5$$

$$\begin{aligned} \tau_b &= 1.0 && \text{(C2-2a)} \\ &= 1 \end{aligned}$$

$$\begin{aligned} EI^* &= 0.8 \tau_b EI \\ &= 1.23656e+007 \text{ ksi} \end{aligned}$$

$$\begin{aligned} P_{e1} &= \frac{\pi^2 EI^*}{(K_1 L)^2} && \text{(A-8-5)} \\ &= 5885.59 \text{ kips} \end{aligned}$$

$$\begin{aligned} B_1 &= \frac{C_m}{1 - \alpha Pr / P_{e1}} \geq 1 && \text{(A-8-3)} \\ &= 1.00256 \end{aligned}$$

$$\text{Magnified Mux} = \text{Mux} * B_1 = 180.46 \text{ kip-ft}$$

Moment magnifier B1 for P-delta effects in local y direction

$$Pr / Py = 0.021815$$

$$\alpha Pr / Py \leq 0.5$$

$$\begin{aligned} \tau_b &= 1.0 && \text{(C2-2a)} \\ &= 1 \end{aligned}$$

$$\begin{aligned} EI^* &= 0.8 \tau_b EI \\ &= 4.0368e+006 \text{ ksi} \end{aligned}$$

$$\begin{aligned} P_{e1} &= \frac{\pi^2 EI^*}{(K_1 L)^2} && \text{(A-8-5)} \\ &= 1921.37 \text{ kips} \end{aligned}$$

$$\begin{aligned} B_1 &= \frac{C_m}{1 - \alpha Pr / P_{e1}} \geq 1 && \text{(A-8-3)} \\ &= 1.00787 \end{aligned}$$

$$\text{Magnified Muy} = \text{Muy} * B_1 = 5.03934 \text{ kip-ft}$$

$$M_{rx} = M_{ux}; M_{ry} = M_{uy}$$

Major Flexural Capacity Calculation

Web compactness:

$$\lambda = \frac{h_c}{t_w}$$

$$= 24.9$$

$$\lambda_{pw} = 3.76 \sqrt{\frac{E}{F_y}}$$

$$= 106.717$$

$$\lambda_{rw} = 5.70 \sqrt{\frac{E}{F_y}}$$

$$= 161.779$$

Web is compact

Flange compactness:

$$\lambda = \frac{b_f}{2t_f}$$

$$= 9.91736$$

$$\lambda_{pf} = 0.38 \sqrt{\frac{E}{F_y}}$$

$$= 10.7853$$

$$\lambda_{rf} = 1.0 \sqrt{\frac{E}{F_y}}$$

$$= 28.3823$$

Flange is compact

M_n to account for Yielding

$$M_n = M_p = F_y Z_x \quad (F2-1)$$

$$= 290.4 \text{ kip-ft}$$

M_n to account for Flange Local Buckling

$$\lambda < \lambda_{pf}$$

$$M_n = M_p$$

$$= 290.4 \text{ kip-ft}$$

Mnx to account for Lateral-Torsional Buckling

$$L_p = 1.76r_y \sqrt{\frac{E}{F_y}} \tag{F2-5}$$

$$= 12.5715 \text{ ft}$$

For I section, c = 1

$$L_r = 1.95r_{ts} \frac{E}{0.7F_y} \sqrt{\frac{Jc}{S_x h_o} + \sqrt{\left(\frac{Jc}{S_x h_o}\right)^2 + 6.76 \left(\frac{0.7F_y}{E}\right)^2}} \tag{F2-6}$$

$$= 45.9286 \text{ ft}$$

$$M_n = M_p = F_y Z_x \tag{F2-1}$$

$$= 290.4 \text{ kip-ft}$$

Lb < Lp

$$M_n = M_p$$

$$= 290.4 \text{ kip-ft}$$

Therefore Mnx = 290.4 kip-ft

$$M_{cx} = \phi_b M_{nx}$$

$$= 261.36 \text{ kip-ft}$$

Minor Flexural Capacity Calculation

Mny to account for Yielding

$$M_n = M_p = F_y Z_y \leq 1.6F_y S_y \tag{F6-1}$$

$$= 132.3 \text{ kip-ft}$$

Mny to account for Lateral-Torsional Buckling

$$\lambda < \lambda_{pf}$$

$$M_n = M_p$$

$$= 132.3 \text{ kip-ft}$$

Therefore Mny = 132.3 kip-ft

$$M_{cy} = \phi_b M_{ny}$$

$$= 119.07 \text{ kip-ft}$$

Flexural and Axial Interaction Calculation

$$\frac{P_r}{P_c} = \frac{P_u}{\phi_c P_n}$$

$$= 0.0273209$$

$$\frac{P_r}{P_c} < 0.2$$

$$\frac{P_r}{2P_c} + \left(\frac{M_{rx}}{M_{cx}} + \frac{M_{ry}}{M_{cy}} \right) \leq 1.0 \quad (\text{H1-1b})$$

$$= 0.746448$$

Axial-Flexural Strength: OK

Major Shear Capacity Calculation

$$A_w = dt_w$$

$$k_v = 5$$

$$h/t_w$$

$$= 24.9$$

$$2.24\sqrt{E/F_y}$$

$$= 63.5764$$

$$h/t_w \leq 2.24\sqrt{E/F_y}$$

$$C_v = 1.0$$

(G2-2)

$$V_n = 0.6F_y A_w C_v$$

(G2-1)

$$= 101.93 \text{ kips}$$

$$h/t_w \leq 2.24\sqrt{E/F_y}$$

$$\phi_v = 1.00$$

$$\phi_v V_n$$

$$= 101.93 \text{ kips}$$

$$\frac{V_u}{\phi_v V_n}$$

$$= 0.0225644$$

Shear Strength (Major Axis): OK

Minor Shear Capacity Calculation

$$A_w = 2b_f t_f$$

$$k_v = 1.2$$

$$h/t_w = b/t_f$$

$$= 9.91736$$

$$1.10\sqrt{k_v E / F_y}$$

$$= 34.2004$$

$$1.37\sqrt{k_v E / F_y}$$

$$= 42.595$$

$$h / t_w \leq 1.10\sqrt{k_v E / F_y}$$

$$C_v = 1.0 \quad (G2-3)$$

$$= 1$$

$$V_n = 0.6F_y A_w C_v \quad (G2-1)$$

$$= 313.632 \text{ kips}$$

$$\phi_v = 0.90$$

$$\phi_v V_n$$

$$= 282.269 \text{ kips}$$

$$\frac{V_u}{\phi_v V_n}$$

$$= 0.00389699$$

Shear Strength (Minor Axis): OK

2.11.7.3 Section Design

Steel Design > Steel Tools > Section Design (Figure 11.10) allows you to quickly design steel sections against a set of load effects. The Section Design input and output are shown below:

Steel Beam-Column Design

Code: ANSI/AISC 360-10 LRFD
 Shape: W
 Section Filter Criteria (Optional)
 Section Prefixes (Comma delimited list, e.g. W12, W14): W12,W14
 Section Min Depth: 0 in Section Max Depth: 0 in
 Section Min Width: 0 in Section Max Width: 0 in

Loads:

	Pu (kip)	Mux (kip-ft)	Muy (kip-ft)	Vux (kip)	Vuy (kip)	Cmx	Cmy
1	35	23	12	23	11	1	1
2							
3							
4							
5							
6							
7							
8							
9							
10							

Geometry

Length: 10 ft
 Lxx: 10 ft Kx: 1
 Lyy: 10 ft Ky: 1
 Lzz: 10 ft Kz: 1
 Lb: 10 ft Cb: 1
 Connector Distance (for double angles only): 0 ft

Section Candidates

	Section	Critical Ratio	Critical Load
1	W12x26	0.9872	1
2	W12x30	0.8294	1
3	W14x30	0.8513	1
4	W14x34	0.7152	1
5	W12x35	0.6814	1
6	W14x38	0.6206	1
7	W12x40	0.4913	1
8	W14x43	0.4519	1
9	W12x45	0.4332	1
10	W14x48	0.3978	1

Buttons: Compute, Detail Check..., Close

Figure 11.10

For Section Filter Criteria, you can use either Section Prefixes or section dimension limits (but not both). The section prefixes is a comma delimited list such as W12, W14. If section prefixes is used, the section dimension limits will be ignored. If a section dimension limit is zero, then that limit criteria is ignored.

By default, a maximum of ten section candidates will be provided after a successful design. You can then view the detailed check for each of the section candidate.

2.12 Settings

The Settings menu provides commands related to settings for model data and graphical entities in model views. Some of these settings may be applied beyond the current model, that is, they may be saved for use in future models.

2.12.1 Units & Precisions

Settings > Units & Precisions prompts you with the following dialog box (Figure 12.1). You may select different units and precisions for various physical measurements used in the model. You may use this command as many times as you like. You may convert existing data associated with a unit in the model by checking or unchecking the check box to the right of that unit. For example, if you mistakenly enter all nodal coordinates in a wrong length unit, you may select the correct length unit and uncheck the conversion checkbox to correct nodal coordinate input.




Figure 12.1

Default English and Default Metric let you quickly set predefined units commonly used for the imperial or metric system. Consistent English and Consistent Metric buttons let you set predefined consistent units for the imperial or metric system. In a consistent unit system, units for the same type of physical measurements are the same. For example, units for both length and dimension are the same, which is inches for imperial system and meters for metric system.

You may set the precision for each unit in either decimal or scientific format. Precision settings are used in displaying data in spreadsheets, diagrams, and reports.

By checking “Save as defaults for future use”, units will be remembered for use in future models. It is a good idea to also save graphic scales at the same time. To do that, just click Settings > Graphic Scales.

2.12.2 Data Options

Settings > Data Options prompts you with the following dialog box (Figure 12.2).

Distance tolerance is used for distance comparisons in certain commands such as **Edit > Merge Nodes** and **Edit > Explode Members**. Distances less than distance tolerance are considered zero by the program.

The “Undo/redo levels” sets the maximum undo/redo levels which the program will perform. The program requires extra computer memory for each undo/redo level. The default undo levels setting is 100. Depending on your computer memory and model sizes, you may want to set undo levels to be smaller.

Data Options ✕

Distance tolerance: ft

Undo/redo levels:

Round-off epsilon:

Show finite elements stresses at:

Show only selected entities in spreadsheets.

Save results when the document is saved

Fictitious or stiffness factor for shell element:

Note: A value of 1e-5 or less is recommended for very thin, curved shell structure. However, too small value may cause numerical difficulties during solution.

Diaphragm stiffness factor:

Note: A value between 1e3 and 1e10 is recommended. The bigger the value, the stronger the rigid diaphragm action. A smaller value may be needed for solution stability or convergency.

Figure 12.2

Round-off epsilon is used to truncate floating point numbers such as those found in results. For example, a fixed support may have a displacement of 1.077e-10 when in fact it should zero. A round-off epsilon of 1e-9 will do just that.

Stresses are computed at the center and at the nodes of finite elements such as shells or solids. However, you may request the program to show stresses at the finite element center only, nodes only, or both. The checkbox “Show only selected entities in spreadsheet” determines if all or selected nodes, elements and their dependents will be shown in the spreadsheet. By checking this checkbox, you may easily query selected entities in a large model. It is important to point out that data in some input spreadsheets may not be modified when this option is checked. The checkbox “Save results when the document is saved” gives you the option to save results (when

available) to a file when the model input data is saved. The result file is a binary file and has the same file name as model input file, but with an extension of “rst” (static results) or “dyn” (dynamic results). The result file could be much larger than the model input file.

The fictitious oz stiffness factor is used to multiply the minimum of diagonal terms (excluding oz) in the shell stiffness matrix to construct the fictitious oz stiffness terms. The smaller this factor, the more accurate the solution, especially for very thin and doubly curved shells. The valid range for this factor is [1e-12, 1e-3]. You normally do not need to change its default value (1e-7). Numerical difficulties may arise during solution if this value is set too small.

The diaphragm stiffness factor is used to control the diaphragm rigidity. The larger this factor, the more rigid the diaphragm action is. The valid range for this factor is [0, 1e20]. The default value is 1e4. Numerical difficulties may be present during static or frequency analysis if the diaphragm stiffness factor is set too large (say 1e13 for 64-bit floating point solver). It is generally recommended to use 128-bit floating point solver to avoid the aforementioned problem.

2.12.3 New Origin

Settings > New Origin prompts you with the following dialog box (Figure 12.3). It allows you to reset the model origin. In particular, the origin may be set at the current model center. This allows you to center the model so its view may be rotated more smoothly.




Figure 12.3

2.12.4 Graphic Scales

Settings > Graphic Scales prompts you with the following dialog box (Figure 12.4). You may set scales for graphical entities such as loads, nodes, supports etc. By “Save as defaults for future use”, these scales will be saved for future use. It is a good idea to save units at the same time. To do that, click Settings > Units & Precisions.




Figure 12.4

2.12.5 Colors

Settings > Colors prompts you with the following dialog box (Figure 12.5). It allows you to set colors of different graphical entities in the model. You may modify the color(s) of one or more items at a time. By checking “Use color cues for different materials”, concrete, steel and wood materials will show different colors in rendering mode.

By checking “Use white background for image captures”, a white background will be used for the captured image even if a different background color is used in the model views. This option will reduce the amount of ink required to print the images. Color settings can be optionally saved for future use.




Figure 12.5

2.12.6 Preferences

Settings > Preferences prompts you with the following dialog box (Figure 12.6).

The “Automatic file backup period” determines how frequently the model files are saved automatically. Enter 0 for no auto-backups. Backup files have the extension “.r3a”.

Settings for “Response Animation” can be set here. You may activate the Response Animation command from the View menu after an analysis has been performed successfully.

You have the options to lock the model after analysis is performed successfully. By default, an internal HTML viewer is used to view text and graphical reports.

By default, rubber-banding is enabled while drawing beams, shells or bricks. You may want to disable this feature if your computer graphic card is not fully OpenGL compatible.

Additional settings related to the font for graphics and the spreadsheet appearance are available.

When the sparse solver is used for static analysis, you may choose an out-of-core approach so computer memory usage is minimized. You may specify the maximum amount of memory to be used in the out-of-core sparse solver. This value should be smaller than the physical memory available in your system.

Preferences are always saved for future use.




Figure 12.6

2.12.7 Tools

2.12.7.1 Tools > Unit Conversion

Settings > Tools > Unit Conversion displays a tool for conversion between various units (Figure 12.7).




Figure 12.7

2.12.7.2 Tools > Calculator

Settings > Tools > Calculator displays the Windows Calculator.

2.12.7.3 Tools > Text Editor

Settings > Tools > Text Editor displays the Windows Notepad.

2.12.7.4 Tools > Copy Command History

Settings > Tools > Copy Command History copies the history in the command window to the clipboard. You may then paste the command history content to a text editor using Ctrl + V. A command history is associated with each open document.

2.12.7.5 Tools > Clear Command History

Settings > Tools > Clear Command History clears the history in the command window. You may want to copy the command history before running this command.

2.12.8 Toolbars

Settings > Toolbars offers options to show or hide the available toolbars.

2.13 Window

The Window menu provides commands to create new windows and arrange existing windows. In this program, a window may be used interchangeably with a view. The program has two types of views: model view and report view. The model view contains the graphical display of the input in a model. The report view contains text or graphical report in html format for the input or output of a model.

2.13.1 New Window

Window > New Window creates a new window or view based on the current view. You may create different model views with different display settings with respect to zooming, panning, loading diagram, shear or moment diagrams, contours, etc. For example, you may have one model view to display moment diagram, another view to display shear diagram. You may create as many views as you want. However, too many views may clutter the view area and make graphic display sluggish.

2.13.2 Close

Window > Close closes the current window.

2.13.3 Close All

Window > Close All closes all windows that are currently open. You will be prompted to save file(s) if necessary.

2.13.4 Tile Horizontal

Window > Tile Horizontal arranges all opened windows horizontally.

2.13.5 Tile Vertical

Window > Tile Vertical arranges all opened windows vertically.

2.13.6 Tile Cascade

Window > Cascade arranges all opened windows in an overlapped manner

This page is intentionally left blank.
Remove this text from the manual
template if you want it completely blank.

Toolbars

3 Toolbars

3.1 Main Toolbar

Settings > Toolbars > Main Toolbar shows or hides the main toolbar.

The Main toolbar is fairly long. So for clarity, it is broken into three portions below with each toolbar button annotated:



- | | |
|-------------------------|---------------------------------|
| 1: Save & Close | 7: Redo |
| 2: Save Only | 8: Drawing Grid |
| 3: Close without Saving | 9: Generate Rectangular Frames |
| 4: Print Text Report | 10: Generate Rectangular Shells |
| 5: Print Preview | 11: Generate Arc Members |
| 6: Undo | 12: Generate 2D Truss/Frame |



- | | |
|---------------------|-----------------------|
| 13: Draw Members | 23: Load Cases |
| 14: Draw Nodes | 24: Load Combinations |
| 15: Draw Shells | 25: Nodal Loads |
| 16: Materials | 26: Point Loads |
| 17: Sections | 27: Line Loads |
| 18: Thickness | 28: Area Loads |
| 19: Moment Releases | 29: Surface Loads |
| 20: Supports | 30: Nodal Masses |
| 21: Springs | 31: Load Combination |
| 22: Local Angle | |

3.2 View Toolbar

Settings > Toolbars > View Toolbar shows or hides the toolbar that contains commands for controlling the view.

The View toolbar is fairly long. So for clarity, it is broken into two portions below with each toolbar button annotated:



- | | |
|----------------------------|--------------------|
| 1: Window Select | 9: Zoom In |
| 2: Invert Selection | 10: Zoom Out |
| 3: Freeze | 11: Real-time Zoom |
| 4: Freeze All Except Plane | 12: Pan Left |
| 5: Thaw | 13: Pan Right |
| 6: Zoom Window | 14: Pan Up |
| 7: Zoom Extent | 15: Pan Down |
| 8: Zoom Previous | 16: Real-time Pan |



- | | |
|----------------------|---------------------|
| 17: Rotate +X | 25: Quick Render |
| 18: Rotate -X | 26: Loading Diagram |
| 19: Rotate +Y | 27: Front View |
| 20: Rotate -Y | 28: Right View |
| 21: Rotate +Z | 29: Top View |
| 22: Rotate -Z | 30: Isometric View |
| 23: Real-time Rotate | 31: Restore Model |
| 24: Query | |



- 32: Annotate Node
Related Items
- 33: Annotate Member
Related Items
- 34: Annotate Shell
Related Items
- 35: Annotation Dialog
- 36: Toggle Grid
Display


3.3 Edit/Run Toolbar

Settings > Toolbars > Edit/Run Toolbar shows or hides the toolbar related to edit, analysis, and result visualization commands.

1		1: Duplicate
2		2: Array
3		3: Mirror
4		4: Move
5		5: Rotate
6		6: Scale
7		7: Delete
8		8: Lock or Unlock
9		9: Toggle Show-Selected-Only
10		10: Static Analysis
11		11: Frequency Analysis
12		12: Fast Shear & Moment Diagrams
13		13: Shear & Moment Diagrams
14		14: Fast Contours
15		15: Contours
16		16: Deflections
17		17: Mode Shape
18		18: Response Animation

3.4 Input Toolbar

Settings > Toolbars > Input Toolbar shows or hides the toolbar that contains input buttons. They are an alternate way to open the named tables.



3.5 Output Toolbar

Settings > Toolbars > Output Toolbar shows or hides the toolbar that contains output buttons. They are an alternate way to open the named tables.



3.6 Status Bar

Settings > Toolbars > Status Bar shows or hides the status bar at the bottom of the screen.



- 1: Currently selected command
- 2: Type of model
- 3: Cursor coordinates (when cursor is on a grid point)
- 4: Current Load Combination
- 5: Solution status

Coordinate Systems

4 Coordinate Systems

Two kinds of coordinate systems are used in the program, namely, the global coordinate system and the local coordinate system. The global coordinate system is the one and only fixed Cartesian system in a structural model. The local coordinate system applies to each individual member or finite element.

4.1 Global Coordinate System



The global coordinate system is a fixed Cartesian system that is used for entire model. The three axes are denoted by capital letters X, Y and Z. They follow the right-hand rule. By default, that is, when a model is not rotated for viewing purpose, the X axis points from left to right (horizontal), the Y axis points from bottom to top (vertical), and the Z axis points from screen to out of screen (perpendicular to screen).

The global coordinate system is used in the following input:

- nodal coordinates, nodal loads
- degrees of freedom related to nodes, supports and springs
- self weights
- point, line, and surface loads on members and finite elements [may also be specified in the element local coordinate system]

The global coordinate system is used in the following output:

- nodal displacements
- support and spring reactions
- brick stresses

4.2 Local Coordinate Systems - General

Each member or finite element has a local coordinate system. It is a Cartesian system that has a default orientation (when local angle equals 0) and may be changed at any time. The three axes are denoted by small letters x, y, z. They follow the right-hand rule.

The local coordinate system exists to facilitate input and output for member and finite elements. For example, point or line loads on a member may be most conveniently

specified in the local coordinate system of the member. The element results such as shears and moments are output in the local coordinate system for design purposes.

Since the local coordinate systems directly affect input and results, it is always prudent to check them for correctness using the commands such as View > Annotate or Render. You may change the local coordinate systems using the commands such as Edit > Element Local Angle or Reverse Node Order for Selected Elements. *It is the directional vectors that matter...the origin of the local coordinate system is insignificant in this program.*

The local coordinate system is used in the following input:

- point, line, and surface loads on members and finite elements [may also be specified in the global coordinate system]
- member moment releases


The local coordinate system is used in the following output:

- member forces, moments, and local deflections
- shell forces, moments, and stresses

In the following sections, V_x , V_y and V_z (with lowercase subscripts) represent the local x, y, and z vectors respectively. V_X , V_Y and V_Z (with uppercase subscripts) represent the global X, Y, and Z vectors respectively. For vector algebra, please refer to relevant math textbooks.

4.3 Member Local Coordinate System


The local coordinate system of a member is determined by the start and end nodes, and an element local angle. The default (local angle equals 0 degrees) local coordinate system of a member is defined using the following procedures:



Steps	Description	Mathematical Notations
A	V_x points from node 1 (N1) to node 2 (N2)	$V_x = N2 - N1$
B1	For vertical members: V_z is always parallel to V_Z	For vertical members $V_z = V_Z$

Steps	Description	Mathematical Notations
B2	For non-vertical members: V_z is perpendicular to a plane formed by V_x and V_y	For non-vertical members $V_z = V_x \times V_y$
C	V_y is determined based on V_x and V_z and the right-hand rule	$V_y = V_z \times V_x$

For a member with a non-zero local angle (γ), first follow the procedures above that determine the default local coordinate system. Then rotate the default system a γ angle about its local x vector V_x . The rotated V_x , V_y and V_z define the local coordinate system. Figure 13.1 shows the local coordinate systems of some members with different local angles (γ).




Local coordinate systems for members with different local angles

Figure 13.1

4.4 Four-Node Shell Local Coordinate System

The local coordinate system of a shell is determined by its four nodes, and an element local angle. The default (local angle equals 0 degrees) local coordinate system of a four-node shell is defined based on the shape of the shell element.




For rectangular shells, the default local coordinate system is easily defined by the following: local x points from N1 to N2, local y points from N1 to N4 and local z is perpendicular to the shell surface.

For non-rectangular shells, the default local coordinate system is defined using the following procedures:

Steps	Description	Mathematical Notations
A	Local z is perpendicular to the shell surface	Let $\mathbf{V}_1 = \mathbf{N}_2 - \mathbf{N}_1$, Let $\mathbf{V}_2 = \mathbf{N}_4 - \mathbf{N}_1$ $\mathbf{V}_z = \mathbf{V}_1 \times \mathbf{V}_2$
B1	For horizontal shells that are parallel to global XZ plane, local x is parallel to global X	For horizontal shells $\mathbf{V}_x = \mathbf{V}_X$
B2	For non-horizontal shells, \mathbf{V}_x is perpendicular to a plane formed by \mathbf{V}_y and \mathbf{V}_z	For non-horizontal shells $\mathbf{V}_x = \mathbf{V}_y \times \mathbf{V}_z$
C	\mathbf{V}_y is determined based on \mathbf{V}_x and \mathbf{V}_z and the right-hand rule	$\mathbf{V}_y = \mathbf{V}_z \times \mathbf{V}_x$

For a shell with a non-zero local angle (γ), first follow the procedures above that determine the default local coordinate system. Then rotate the default system a γ

angle about is its local z vector V_z . The rotated V_x , V_y and V_z define the local coordinate system. Figure 13.2 shows the local coordinate systems of some shell elements with different local angles (γ)



Local coordinate systems for shells with different local angles

Figure 13.2

4.5 Eight-Node Brick Local Coordinate System

The local coordinate system for a brick element is always identical to the global coordinate system. It is fixed and cannot be changed.

Nodes

5 Nodes

Nodes are numbered points in space. They are used to define the geometry and connectivity of all members and finite elements in a model. For members, a node is sometimes referred to as a joint, which has a physical meaning of the intersection of two members such as a beam and a column. However, in this program, the term “node” is generally preferred because it carries a more general meaning.

5.1 Nodal Coordinates

The location of a node is defined by the global X, Y, and Z coordinates. Since each member or finite element connects to two or more nodes, nodal coordinates define the geometry of a model. For example, when you move an element, you actually move the locations of the nodes connected to that element.

5.2 Degrees of Freedom (DOFs)

Each node may have a maximum of six global degrees of freedom (DOFs) associated with it. They are three translational DOFs along the global X, Y, Z directions (D_x , D_y and D_z) and three rotational DOFs about the global X, Y, Z directions (D_{ox} , D_{oy} and D_{oz}).

Some of these DOFs may not be available depending upon the type of a model.

For example, the model type “2D Truss” has D_x and D_y available and D_z , D_{ox} , D_{oy} , D_{oz} unavailable or suppressed; while the model type “2D Plate Bending” only has D_z , D_{ox} , D_{oy} available and D_x , D_y , D_{oz} suppressed.

You may always use the model type “3D Frame and Shell” to analyze any structure, however, time and computer memory may be wasted if a simpler model type can be used instead. You may choose the appropriate model type by command Analyze > Analysis Options.

Six nodal displacements associated with 6 DOFs are output for each node. For restrained or unavailable DOFs, the program outputs the corresponding displacements as zero. Nodal displacements should be the first thing to check for when determining result correctness since the solution is displacement-based. If the displacements are wrong, nothing else will be correct.

5.3 Node Numbers


A distinct integral number is assigned to each node. Node numbers are used to define the connectivity of member and finite elements. Duplicate numbers in nodes are not permitted. There can be gaps in node numbering sequence. The program will automatically renumber the nodes internally before performing the solution. The order of node numbering in a model is insignificant to the final results, but it may affect the time and computer memory required to solve the model. For a very large model, node renumbering may be important in order to reduce the half band width in the global stiffness matrix and therefore the solution time. You may renumber the nodes sequentially based on nodal coordinates using the command Edit > Renumber Nodes.

Half Band Width (HBW) is defined as [Ref.7] as follows:

$$HBW = \max_{1 \leq el \leq m} (\max dof_{el} - \min dof_{el})$$


where m is the total number of structural elements, and the $\max dof_{el}$ and $\min dof_{el}$ are the maximum and minimum global degrees of freedom numbers associated with element el .

For example, in Figure 14.1 and 14.2, models A and B are identical 3D frames (6 DOFs per node) but with different node numbering schemes. Model A has a HBW of $6 * (9 + 1) = 60$ while model B has a HBW of $6 * (5 + 1) = 36$. Therefore, model B is more economical than model A because of the reduction of half band width.



Model A: HBW=60

Figure 14.1



Model B: HBW=36

Figure 14.2

5.4 Loads

Forces or moments may be applied to a node. These forces and moments are specified in the global coordinate system. You may regard enforced displacements as special kinds of loads. They are specified in supports.

5.5 Supports

By default, a node is unrestrained, that is, it is free to move in any of the six available DOFs. However, for a model to be stable, restraints on one or more DOFs must be imposed on some nodes. Restraints may be rigid or flexible. Rigid restraints are referred to as supports while flexible restraints are referred to as springs. You may regard supports as springs with infinite spring constants.

You may assign a support with one or more DOFs (D_x , D_y , D_z , D_{ox} , D_{oy} and D_{oz}) restrained to a node. The program uses a six-character code to represent restraint conditions of a support in six DOFs. For example, "111111" represents a fixed support while "111000" represents a pinned support. By default, restrained DOFs have zero enforced displacements. You may specify non-zero enforced displacements to any or all of restrained DOFs. The enforced displacements are discarded if they are assigned to unrestrained DOFs. You may regard these

enforced displacements as special kinds of loads. They participate in all load combinations but always with a load factor of 1.0.

The forces or moments required to enforce rigid restraints are called support reactions. They are computed by the program.

5.6 Springs

Springs are flexible restraints. Springs applied to nodes are referred to as nodal springs. You may assign a nodal spring to a node with one or more global DOFs (D_x , D_y , D_z , D_{ox} , D_{oy} and D_{oz}) restrained. To qualify to be a valid flexible restraint, the corresponding spring constant must be specified. A restraint may be designated as linear, compression-only or tension only. A compression-only restraint is active only when the nodal displacement in the restrained direction is negative. A tension-only restraint is active only when the nodal displacement in the restrained direction is positive. If a model contains one or more compression-only or tension-only springs, the whole problem becomes nonlinear and the solution becomes iterative for each load combination.

The forces or moments required to enforce the flexible restraints are called spring reactions. They are computed by the program.

This page is intentionally left blank.
Remove this text from the manual
template if you want it completely blank.

Members

6 Members

A member is a two-node straight frame element with a constant cross section. The term “frame element”, “beam element”, and “member” are used interchangeably in this program. The truss element is a special frame element with moments fully released at both ends. The frame element formulation accounts for axial, torsional, and bending about strong and weak axes, with options to include shear deformations and axial stress stiffening (P-Delta) effects. Moment releases may be applied to either or both ends of the element.

The frame element may be used to model continuous beams, 2D or 3D frames, 2D or 3D trusses or a mixture of two. The program provides powerful commands to generate commonly used framed structures such as continuous beams, 2D or 3D frames, arc beams, and non-prismatic beams. A non-prismatic member is approximated by subdividing the original member into several prismatic members. You may access these commands from the Generate menu.

6.1 Member Sections

Each member must have a section assigned to it. The section properties include:

- A : axial section area
- A_y : shear area along the member local y direction
- A_z : shear area along member the local z direction
- I_{zz} : moment of inertia about strong the local axis z
- I_{yy} : moment of inertia about weak the local axis y
- J : torsional moment of inertia

A_y and A_z may be zero, in which case, the program ignores shear deformations of the element. Mathematically speaking, the program interprets them as being infinite. For rectangular sections, $A_y = A_z = 5/6A$. For solid circular sections, $A_y = A_z = 0.9A$. For thin-walled hollow circular sections, $A_y = A_z = 0.5A$. For wide flange sections, A_y = web area, A_z = area of two flanges [Ref. 6]. To consider member shear deformation, you must choose the proper option from the command Run > Analysis Options. *Shear deformation, when considered, applies to both element stiffness and local deflections.*

6.2 Local Coordinate System

Each member has its own local coordinate system. The element local coordinate systems are used in element stiffness formulations. They are also used for inputs

such as loads and releases and outputs such as internal shears and moments. For the definition of the member local coordinate system, refer to Coordinate Systems.

6.3 Member Numbers

A distinct integral number is assigned to each member. Duplicate numbers in members are not permitted. There can be gaps in the member numbering sequence.

The order of member numbering in a model is insignificant to the results or solution time. You may renumber the members sequentially using the command Edit > Renumber Members.

6.4 Beams Vs. Trusses

By default, a member or frame element is a beam. However, if you choose the model type to be either “2D Truss” or “3D Truss”, then the frame element becomes a truss element. The program assigns full moment releases automatically to the ends of all members and suppresses all three rotational DOFs D_{ox} , D_{oy} , D_{oz} for each and every node. For the model type “2D Truss”, the program also suppresses translational DOF D_z . Generally speaking, if a model contains only 2D or 3D truss elements, you should choose the model type as “2D Truss” or “3D Truss”. If a model contains both trusses and beams, you should choose the model type “2D Frame” or “3D Frame & Shell”, and assign appropriate moment releases to individual beams. It may also be necessary to assign appropriate restraints to nodes to ensure stability of the model. You may choose the appropriate model type by running the command Analyze > Analysis Options.

6.5 Elastic Stiffness Matrix

Total number of DOFs of a member is the summation of DOFs of the two nodes. Therefore, for a 3D beam, the stiffness matrix is of size 12 x 12. The elastic stiffness matrix in the local coordinate system with shear deformation is given [Ref. 8] as follows:

$$\begin{bmatrix} F_{x1} \\ F_{y1} \\ F_{z1} \\ M_{x1} \\ M_{y1} \\ M_{z1} \\ F_{x2} \\ F_{y2} \\ F_{z2} \\ M_{x2} \\ M_{y2} \\ M_{z2} \end{bmatrix} = \begin{bmatrix} EAL & 0 & 0 & 0 & 0 & 0 & -EAL & 0 & 0 & 0 & 0 & 0 \\ 0 & 12\beta_1/L^2 & 0 & 0 & 0 & 6\beta_1/L & 0 & -12\beta_1/L^2 & 0 & 0 & 0 & 6\beta_1/L \\ 0 & 0 & 12\beta_2/L^2 & 0 & -6\beta_2/L & 0 & 0 & 0 & -12\beta_2/L^2 & 0 & -6\beta_2/L & 0 \\ 0 & 0 & 0 & J/(GD) & 0 & 0 & 0 & 0 & 0 & -J/(GD) & 0 & 0 \\ 0 & 0 & 0 & 0 & (4+\alpha_2)\beta_2 & 0 & 0 & 0 & 6\beta_2/L & 0 & (2-\alpha_2)\beta_2 & 0 \\ 0 & 0 & 0 & 0 & 0 & (4+\alpha_1)\beta_1 & 0 & -6\beta_1/L & 0 & 0 & 0 & (2-\alpha_1)\beta_1 \\ EAL & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 12\beta_1/L^2 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -6\beta_1/L & 0 \\ 0 & 0 & 12\beta_2/L^2 & 0 & 6\beta_2/L & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & J/(GD) & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & (4+\alpha_2)\beta_2 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & (4+\alpha_1)\beta_1 & 0 & 0 & 0 & 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} \Delta_{x1} \\ \Delta_{y1} \\ \Delta_{z1} \\ \theta_{x1} \\ \theta_{y1} \\ \theta_{z1} \\ \Delta_{x2} \\ \Delta_{y2} \\ \Delta_{z2} \\ \theta_{x2} \\ \theta_{y2} \\ \theta_{z2} \end{bmatrix}$$

where: $G = \frac{E}{2(1+\nu)}$; $\alpha_1 = \frac{12EI_z}{GA_yL^2}$; $\alpha_2 = \frac{12EI_y}{GA_zL^2}$; $\beta_1 = \frac{EI_z}{(1+\alpha_1)L}$; $\beta_2 = \frac{EI_y}{(1+\alpha_2)L}$

6.6 Geometric Stiffness Matrix

When a tensile axial force is present in a member, the bending stiffness of that member is increased. Conversely, when a compressive axial force is present in a member, the bending stiffness of that member is reduced. The stiffness matrix that reflects this kind of stress stiffening effect is called the geometric stiffness matrix [Ref. 3, 7]. It is determined by the element geometry and stress conditions, and is independent of the elastic properties. The geometric stiffness matrix is very effective in accounting for the P-Delta effect and is implemented in the program. It may also be used to perform buckling analysis of the structure but is not implemented in the program directly.

Like the elastic stiffness matrix, the geometric stiffness matrix is of size 12 x 12 and is given [Ref. 3, 7] as follows:

$$\begin{bmatrix} F_{x1} \\ F_{y1} \\ F_{z1} \\ M_{x1} \\ M_{y1} \\ M_{z1} \\ F_{x2} \\ F_{y2} \\ F_{z2} \\ M_{x2} \\ M_{y2} \\ M_{z2} \end{bmatrix} = \frac{P}{L} \begin{bmatrix} 1 & 0 & 0 & 0 & 0 & 0 & -1 & 0 & 0 & 0 & 0 & 0 \\ 6/5 & 0 & 0 & 0 & L/10 & 0 & -6/5 & 0 & 0 & 0 & L/10 & 0 \\ 6/5 & 0 & -L/10 & 0 & 0 & 0 & 0 & -6/5 & 0 & -L/10 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 2L^2/15 & 0 & 0 & 0 & L/10 & 0 & -L^2/30 & 0 & 0 & 0 & 0 & 0 \\ 2L^2/15 & 0 & -L/10 & 0 & 0 & 0 & 0 & -L^2/30 & 0 & 0 & 0 & 0 \\ 1 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 6/5 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & -L/10 & 0 & 0 \\ 6/5 & 0 & L/10 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 2L^2/15 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 2L^2/15 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} \Delta_{x1} \\ \Delta_{y1} \\ \Delta_{z1} \\ \theta_{x1} \\ \theta_{y1} \\ \theta_{z1} \\ \Delta_{x2} \\ \Delta_{y2} \\ \Delta_{z2} \\ \theta_{x2} \\ \theta_{y2} \\ \theta_{z2} \end{bmatrix}$$

where P is the average of the axial forces (positive in tension, negative in compression) at the member ends.

When the linear static (first order) analysis is chosen, the member stiffness matrix is the elastic stiffness matrix. When the P-Delta (second order) analysis option is chosen, the member stiffness matrix is the summation of the elastic stiffness matrix and the geometric stiffness matrix. You may set the appropriate analysis option with the command [Analyze > Analysis Options](#)¹⁶⁸.

6.7 Moment Releases

By default, a member is rigidly connected to two end nodes. You may however assign moment releases to either end of the member. *It is important to note that the releases are applied with respect to the member local coordinate system.* The moment releases may be in major bending direction (D_{Oz}) or minor bending direction (D_{Oy}) or both. The element stiffness matrix is modified to enforce moment releases.

6.8 Tension/Compression-Only

By default, a member is linear. You may assign nonlinearity (tension-only or compression-only) to the selected members. The member stiffness will be ignored if a tension-only member is subjected to compressive forces or if a compression-only member is subjected to tensile forces. The presence of tension- or compression-only members makes the model nonlinear, so an iterative solution is required for each load combination.

6.9 Rigid Links

A rigid link is a member that has very large sectional properties (A, Ay, Az, Iz, Iy and J). There can only be one rigid link section defined in the model and it must be named as "RIGID_LINK". The properties for the RIGID_LINK section must be set to 0's on the member section dialog box. The program will appropriately calculate A, Ay, Az, Iz, Iy and J during the solution process. **Self weight for rigid links will be ignored by the program.**

6.10 Rigid Diaphragms

Rigid diaphragms may be used instead of plate finite elements to model stiff in-plane actions such as concrete floors. Internally, the program creates multiple in-plane rigid links for each diaphragm prior to static or frequency analysis. A rigid link is simply a member with very large sectional properties that can be adjusted with the diaphragm stiffness factor (see Settings > Data Options). The larger the diaphragm stiffness factor, the stronger the in-plane rigid diaphragm action is. The presence of rigid links with large diaphragm stiffness factor (say 1E10) could create numerical difficulties during the solution if the 64-bit floating point solver is used. However, the unique 128-bit floating point solver in ENERCALC 3D makes this problem nonexistent in that much larger diaphragm stiffness factor (say 1E20) may be used without creating numerical difficulties during the solution.

The program further provides the option to ignore the rigid diaphragm actions as an analysis option (Analyze > Analysis Options).

It is important to point out that rigid diaphragm action in the program does not use master-slave nodes.

6.11 Loads

Point loads or line loads may be applied to a member. Point loads may be forces or moments. Line loads must be forces. You may specify loads in either the global or local coordinate system. The locations of loads must be in ratios of the member length, measured from the start of the member. Figure 15.1 shows examples of point and line loads.

The self weight of members may be calculated automatically if the material weight densities and self weight multiplier are nonzero. By default, self weight acts in the negative global Y direction. You may however change the direction to positive or negative direction of the global X, Y, or Z. This flexibility is useful in some circumstances. For example, if you model a grillage on the XY plane, the self weight may be either in the positive or negative global Z direction, depending on your

preference on load sign convention. To activate automatic self weight calculation, use the command Loads > Assign Self Weights.





Point Loads	Line Loads
 <p>local y force, distance=0.6</p>	 <p>local y force, start distance=0, end distance=1</p>
 <p>local z moment, distance=0.4</p>	 <p>global Y force, start distance=0.2, end distance=0.8</p>

Figure 15.1


An area load may be applied to multiple members on a whole planar area. The area is defined by three or four coplanar nodes. The area load is then distributed as line loads to perimeter members of enclosed sub-areas within the load area prior to static or dynamic solution. Area loads are distributed to perimeter members that form each of the enclosed sub-areas according to the following methods:

- Two-way (rectangular sub-areas)
- Short-Sides (rectangular sub-areas)
- Long-Sides (rectangular sub-areas)
- AB-CD Sides (rectangular sub-areas)
- BC-AD Sides (rectangular sub-areas)
- Centroid-based
- Circumference-based

The first five distribution methods apply to four-node rectangular sub-areas only. The centroid-based method may be applied to convex sub-areas only. The circumference-based method may be applied to both convex and concave sub-areas. Loads may also be distributed to sides parallel to AB-CD or BC-AD sides of the load area. The program is intelligent enough to determine the most appropriate load distribution if inconsistencies arise. For example, if you select two-way distribution method for a sub-area that is not rectangular, the program will use the centroid-based method if the sub-area is convex or the circumference-based method if the sub-area is concave.

The program allows you to convert area loads to line loads directly and automatically. This feature allows you to see how exactly the program would distribute area loads to members prior to the solution. Of course, you can always undo the conversion if you want to keep the area loads. For more information on the load conversion, please see Loads > Assign Area Loads.

As an example, let's say we have a 3.5 x 1.5 ft rectangular sub-area subjected to 100 lb/ft². The following line loads (Figure 15.2) are converted from the same area load based on different distribution methods.






Figure 15.2

Area loads may be specified in either the local or global coordinate system. Global area loads may be in the global X, Y, or Z direction. Local area loads may only be in the local z direction, which is perpendicular to the load area. It is recommended that area loads be defined in their own load cases. In this way, you will find it easier to identify, edit, and delete area loads later on.

There are a few limitations to the area load concept in the program. The first limitation is that the sub-areas must be close-formed by perimeter members. In the following Figure 15.3, the sub-area formed by node 97, 98, 104 and 103 is not a closed sub-area because there is no member connecting the node 97 and 98. As a result, no area loading will be distributed to the three perimeter members from the sub-area. The second limitation is that sub-areas must not overlap. In Figure 16.3, the sub-areas in node 101, 102, 120 and 119 are overlapping. This will result more load being distributed to the members in these sub-areas. The program gives a warning when the area load footprint is not equal to the total actual loaded area. The problem may be solved by splitting members 119-108, 107-120 and 113-114 at the intersection point.





Figure 15.3

The third limitation is that any sub-area may not contain more than one concave node (with internal angle more than 180 degrees). The fourth limitation is that any sub-area may not contain the same node more than once in forming the perimeter polygon.

The program offers automatic generation of live load patterning (point and line loads only). The following example (Figure 15.4) shows how the program generates load patterning on a five-span continuous beam. Loads on each generated pattern reside in a separate load case automatically generated. Additional load combinations are generated as needed as well.






Figure 15.4

The program also offers automatic generation of moving loads (point loads only). The mechanism employed by the program is similar to the live load patterning.

6.12 Line Springs

Springs are flexible restraints. Springs applied to members are referred to as line springs. You may assign a line spring to a member with one or more global DOFs (D_x , D_y and D_z) restrained. To qualify as a valid flexible restraint, the corresponding


spring constant must be specified. A restraint may be designated as linear, compression-only or tension-only. A compression-only restraint is active only when the nodal displacement in the restrained direction is negative. A tension-only restraint is active only when the nodal displacement in the restrained direction is positive. If a model contains one or more compression-only or tension-only springs, the whole problem becomes nonlinear and the solution becomes iterative for each load combination

The forces or moments required to enforce the flexible restraints are called spring reactions. They are computed by the program.

6.13 Internal Forces and Moments

The program outputs internal forces and moments at designated stations along the member length. You may specify the number of segments ranging from 1 to 127 for member output by running the command Run > Analysis Options. For smooth moment and shear diagrams, the program may add extra segments.

Figure 15.5 shows the positive direction of the internal forces and moments of members.






Figure 15.5

Figure 15.6 is an alternative way to show the positive direction of the internal shears and moments on the local xy and xz planes.




Figure 15.6

This page is intentionally left blank.
Remove this text from the manual
template if you want it completely blank.

Shells

7 Shells

A shell is a structure or part of a structure which has a relatively small thickness in comparison with the other two dimensions. A general shell forms a curved surface in space. When it forms a flat surface, it is also called a plate. In this program, when the term “plate” is used, it refers to flat shell in the out-of-plane bending action.

The shell element in the program is a four-node (quadrilateral) element that combines the in-plane membrane action and the out-of-plane bending action. The in-plane membrane action is a standard isoparametric compatible formulation with the option to add incompatible modes. The out-of-plane bending action is a thick-plate formulation, with the option to use the thin-plate formulation when the element is rectangular. The element can be used to model both flat-surface plates and curved-surface general shells. Applications of shell elements in structures are wide and far-reaching. Examples are concrete floors, mat foundations, shear wall, folded plates, barrel vaults, cooling towers, spherical domes, water tanks, etc. The program provides powerful commands to generate these and other commonly used plate and shell structures. These commands include Geometry > Generate Shells, Edit > Extrude, Revolve, etc.

For many years, a great number of papers have been published on the subject of plate and shell structures. Although the membrane action of a shell element is relatively simple, the (plate) bending action is much more complex. Many plate elements have been proposed, some of which have been implemented in commercial programs. However, most of these proposed plate elements are either ineffective or unreliable. One of the main hurdles is known as transverse “shear locking”, that is, elements behave too stiff with respect to shear deformation especially when elements are thin or geometrically distorted.

One of the few reliable plate elements is a rectangular thin plate element developed by O.C. Zienkiewicz [Ref. 2]. It is based on the Kirchhoff thin plate bending theory in which a line straight and normal to the mid-surface of the plate before loading is assumed to remain straight and normal to the deformed mid-surface after loading. The transverse shear strain is therefore assumed to be zero. This plate element is important in that it is the first plate element that can be applied reliably in engineering practice. Prior to this, plate analysis depended mainly on very few “closed-form” solutions of simple geometry and boundary conditions, and other very approximate methods such as equivalent frame method of ACI [Ref. 12]. The Kirchhoff rectangular thin plate is implemented in the program. It produces results that converge to “closed-form” solutions as finite element meshes are refined. The element, however, has to be rectangular in shape and does not account for shear deformation.

A much more reliable and effective plate bending element is the MITC4 developed by K.J. Bathe and others [Ref. 1]. It is a thick plate that is based on Mindlin plate theory in which a line straight and normal to the mid-surface of the plate before loading is assumed to remain straight but not necessarily normal to the deformed mid-surface

after loading. The element considers shear as well as bending deformations and may be used for both thick and thin plates. This plate element differs from earlier Mindlin theory based plate elements in that different (mixed) interpolations are used to account for the bending and transverse shear strains. The MITC4 plate bending element is implemented in the program. It is free from “shear locking” and performs well even when element meshes are distorted. The shape of the element may be any general quadrilateral as long as the aspect ratio is within a reasonable range (say 0.2 to 5.0).

7.1 Shell Thicknesses

Each shell must have a thickness assigned to it. Based on the ratio of thickness to span length, you may choose to use the thin or thick plate bending formulation.

The thick plate formulation is generally recommended over the thin plate formulation because it applies equally well to both thick and thin plates. The program therefore uses the thick plate formulation by default. If thickness to span ratio is less than 1/20 and elements are rectangular, you may use the thin plate formulation. The thickness should be compared to the support distances, not to the sizes of individual plate elements.

It is important to point out that out-of-plane shear forces exist in thin plates even though shear deformations are not considered. You may draw an analogy between a plate and a beam. A thin plate is analogous to a Euler-Bernoulli beam while a thick plate is analogous to a Timoshenko beam. We consider shear deformation for the Timoshenko beam but not for the Euler-Bernoulli beam, while shear forces exist in both the Euler-Bernoulli and Timoshenko beams.

7.2 Local Coordinate System

Each shell element has its own local coordinate system. The element local coordinate systems are used in element stiffness formulations. They are also used for inputs such as loads and outputs such as internal shears, moments, and stresses. Local angles for rectangular shells must be 0s if thin plate bending formulation is used in the analysis options. For definition of the shell local coordinate system, refer to Coordinate Systems.

7.3 Shell Numbers

A distinct integral number is assigned to each shell. Duplicate numbers in shells are not permitted. There can be gaps in shell numbering sequence. The order of shell numbering in a model is insignificant to the results or solution time. You may renumber the shells sequentially using the command Edit > Renumber Shells.

7.4 Element In-Plane Stiffness Matrix

The in-plane element formulation accounts for D_x and D_y of the local coordinate system. The in-plane stiffness matrix of the element is based on the standard isoparametric formulation [Ref 1, 2, 3]. However, when the element is rectangular in shape, incompatible modes may be optionally added to the formulation [Ref. 3]. An incompatible element, when applied, yields results of high quality especially when used to model in-plane bending. Full two by two numerical integration is used to calculate the in-plane stiffness matrix of the element.

7.5 Element Out-of-Plane Stiffness Matrix

Out-of-plane bending accounts for D_z , D_{ox} and D_{oy} of the local coordinate system. By default, the MITC4 thick plate formulation is used [Ref. 1]. If the thin plate option is chosen, elements with rectangular shapes will be calculated based on the Kirchhoff thin plate formulation [Ref. 1]. Full two by two numerical integration is used in either case to calculate the out-of-plane stiffness matrix of the element.

7.6 Combining Element In-Plane and Out-of-Plane Stiffness Matrices

The shell element stiffness matrix is the combination of the in-plane and out-of-plane stiffness matrices. In order to avoid singularity of the stiffness matrix, a very small “fictitious” stiffness is added to the diagonal term associated with the local DOF D_{oz} .

7.7 Loads

Surface loads may be applied to a shell. You may specify loads in either the global or local coordinate system. Surface loads are lumped to element nodes before solution. The self weight of shells may be calculated automatically if the material weight densities and self weight multiplier are nonzero. By default, the self weight acts in the negative global Y direction. You may, however, change the direction to positive or negative direction of the global X, Y or Z. This flexibility is useful under certain circumstances. For example, if you select the model type “2D Plate Bending”, the self weight may be either in positive or negative global Z direction, depending on your preference on the sign convention. To activate automatic self weight calculation, use the command `Load > Assign Self Weights`.

7.8 Surface Springs

Springs are flexible restraints. Springs applied to shells are referred to as surface springs. You may assign a surface spring to a shell with one or more global DOFs (D_x , D_y and D_z) restrained. To qualify as a valid flexible restraint, the corresponding spring constant must be specified. A restraint may be designated as linear, compression-only or tension-only. A compression-only restraint is active only when the nodal displacement in the restrained direction is negative. A tension-only restraint is active only when the nodal displacement in the restrained direction is positive. If a model contains one or more compression-only or tension-only springs, the whole problem becomes nonlinear and the solution becomes iterative for each load combination.

The forces or moments required to enforce flexible restraints are called spring reactions. They are computed by the program. Surface springs may be used to model Winkler mat foundations. It may be worthwhile to note that in modeling a mat foundation, surface spring constants are the soil subgrade moduli while surface spring reactions are the soil pressures.

7.9 Internal Forces or Moments

The internal forces and moments exist at every point on the middle surface of the shell element. They represent the resultants of different normal and shear stresses over the element thickness. The internal forces have the units of force per unit length and the internal moments have the units of moment per unit length.

The in-plane or membrane results include the normal forces F_{xx} , F_{yy} and shear force F_{xy} . The out-of-plane results include the shear forces V_x , V_y and bending moments M_{xx} , M_{yy} , M_{xy} . M_{xy} is also called twisting moments. It is important to differentiate these forces and moments

Figure 16.1 shows the positive direction of the internal forces and moments of a shell. They represent forces and moments at one point on the middle surface of the element. The program outputs these forces and moments at the four corner nodes and /or at the center of the element. You may use Analysis Results > Results Diagrams > Contour Diagram to see the distribution of these and other resultants. Generally speaking, internal forces or moments (or result in general) are different across element boundaries. You have the option to average forces and moments for adjacent elements at nodes. To do that, click Analyze > Analysis Options.




Figure 16.1

Based on the internal forces and moments, the program computes the internal stresses at the shell bottom (the $-z$ side) and top (the $+z$ side) as follows. The stresses are expressed in the local coordinate systems. The stress directions correspond to the in-plane normal axial forces and shear, and the out-of-plane shears.

$$\sigma_{xx} = \frac{F_{xx}}{t} + \frac{6M_{xx}}{t^2} \quad (@ \text{ bottom}) \quad \text{or} \quad \sigma_{xx} = \frac{F_{xx}}{t} - \frac{6M_{xx}}{t^2} \quad (@ \text{ top})$$

$$\sigma_{yy} = \frac{F_{yy}}{t} + \frac{6M_{yy}}{t^2} \quad (@ \text{ bottom}) \quad \text{or} \quad \sigma_{yy} = \frac{F_{yy}}{t} - \frac{6M_{yy}}{t^2} \quad (@ \text{ top})$$

$$\sigma_{xy} = \frac{F_{xy}}{t} + \frac{6M_{xy}}{t^2} \quad (@ \text{ bottom}) \quad \text{or} \quad \sigma_{xy} = \frac{F_{xy}}{t} - \frac{6M_{xy}}{t^2} \quad (@ \text{ top})$$

$$\sigma_{xz} = \frac{V_x}{t}$$

$$\sigma_{yz} = \frac{V_y}{t}$$

The program also outputs in-plane principal forces and angles, and out-of-plane principal forces, moments, and angles. In addition, principal stresses S_1 , S_2 , and S_3

are computed based on the stresses σ_{xx} , σ_{yy} , σ_{xy} as follows:

$$S_1 = \frac{\sigma_{xx} + \sigma_{yy}}{2} + \sqrt{\left(\frac{\sigma_{xx} - \sigma_{yy}}{2}\right)^2 + \sigma_{xy}^2}$$

$$S_2 = \frac{\sigma_{xx} + \sigma_{yy}}{2} - \sqrt{\left(\frac{\sigma_{xx} - \sigma_{yy}}{2}\right)^2 + \sigma_{xy}^2}$$

$$S_3 = 0$$

The Von Mises stress, which is often used to estimate the yield of ductile materials, is then computed as follows:

$$\sigma_{VonMises} = \sqrt{\frac{(S_1 - S_2)^2 + (S_1 - S_3)^2 + (S_2 - S_3)^2}{2}}$$

7.10 Membrane Nodal Resultants


The membrane nodal resultants of a shell are concentrated forces F_x and F_y (Unit: Force) at the four nodes of each shell element. They in effect keep each individual element in equilibrium (in-plane). They are expressed in the local coordinate system.

You may view nodal forces of selected shell elements by View > Annotate. The membrane nodal forces may be used to compute shears, axial forces, or moments in a shear wall. For example, the following three shells represent a pier in a shear wall. Each shell is 1.5 x 1.5 ft in size. Membrane nodal resultants F_x and F_y are shown in the first and second rows respectively at each corner of the element. The shear, axial force and moment resultants on the top of the pier may be computed as follows:

Eigenvectors - [Mode-1]

Mode Shape: Mode-1: (Period=0.1444 sec) Show selected only Print... Save... Close

	Node Id	Dx [mm]	Dy [mm]	Dz [mm]	Dox [rad]	Doz [rad]	Doz [rad]
1	2	0.000e+000	0.000e+000	0.000e+000	0.000e+000	0.000e+000	0.000e+000
2	3	-4.542e-029	1.663e+000	0.000e+000	0.000e+000	0.000e+000	9.729e-003
3	12	-2.023e-030	4.287e-002	0.000e+000	0.000e+000	0.000e+000	2.816e-003
4	13	4.538e-030	1.611e-001	0.000e+000	0.000e+000	0.000e+000	5.107e-003
5	14	1.177e-029	3.394e-001	0.000e+000	0.000e+000	0.000e+000	6.885e-003
6	15	-2.075e-029	5.629e-001	0.000e+000	0.000e+000	0.000e+000	8.174e-003
7	16	-1.443e-029	8.178e-001	0.000e+000	0.000e+000	0.000e+000	9.020e-003
8	17	3.770e-029	1.092e+000	0.000e+000	0.000e+000	0.000e+000	9.493e-003
9	18	6.618e-030	1.376e+000	0.000e+000	0.000e+000	0.000e+000	9.687e-003



F_{xi} (kips)	F_{yi} (kips)	X_i (ft)	$F_{yi} * X_i$ (ft-kips)
1.758	-2.284	-2.25	5.139
3.226	1.663	-0.75	-1.24725
7.226	-8.458	-0.75	6.3435
5.786	4.611	0.75	3.45825
3.144	-3.718	0.75	-2.7885
2.722	3.082	2.25	6.9345
Shear $\Sigma F_x = 23.862$	Axial Force $\Sigma F_y = -5.104$		Moment $\Sigma M = 17.8395$

Bricks

8 Bricks

The Brick element in the program is an eight-node solid element based on isoparametric compatible or incompatible formulation [Ref 1, 2, 3]. It may be used to model structures where actions in all three dimensions are significant.

8.1 Local Coordinate System

The local coordinate systems for all Bricks are the same. They are identical to the global coordinate system. The element nodal connectivity must be numbered in such a way so that the normal vector of the surface 1-2-3-4 points to the surface 5-6-7-8 (Figure 17.1). This is to avoid negative diagonals in the element stiffness matrix. You may use the command Edit > Reverse Node Order for Selected Elements if the normal vector is not in accordance with the requirement. For more information about the brick local coordinate system, refer to Coordinate Systems.




Figure 17.1

8.2 Brick Numbers

A distinct integral number is assigned to each Brick. Duplicate numbers in Bricks are not permitted. There can be gaps in Brick numbering sequence. The order of Brick numbering in a model is insignificant to the results or solution time. You may renumber the Bricks sequentially using the command Edit > Renumber Bricks.

8.3 Element Stiffness Matrix

The element formulation accounts for D_x , D_y and D_z of the local coordinate system. The element stiffness matrix is based on isoparametric compatible or incompatible

formulation [Ref 1, 2, 3]. Therefore, the stiffness matrix is of size 24 by 24. Full two by two numerical integration is used to calculate the stiffness matrix.

8.4 Loads

Loads on Brick elements must be input as nodal loads.

The self weight of Bricks may be calculated automatically if material weight densities and self weight multiplier are nonzero. By default, the self weight acts in the negative global Y direction. You may however change the direction to positive or negative direction of the global X, Y or Z. To activate automatic self weight calculation, use the command Loads > Assign Self Weights.

8.5 Internal Stresses

Three normal stresses σ_{xx} , σ_{yy} , σ_{zz} and three shear stresses σ_{xy} , σ_{xz} , σ_{yz} are computed by the program. They are output at the eight nodes and/or at the center of the element.

The program also outputs principal stresses S_1 , S_2 , S_3 and the corresponding directional vectors (V_{1x}, V_{1y}, V_{1z}) and (V_{3x}, V_{3y}, V_{3z}) . The Von Mises stress, which is often used to estimate the yield of ductile materials, is then computed as follows:

$$\sigma_{VonMises} = \sqrt{\frac{(S_1 - S_2)^2 + (S_1 - S_3)^2 + (S_2 - S_3)^2}{2}}$$

This page is intentionally left blank.
Remove this text from the manual
template if you want it completely blank.

Static Analysis

9 Static Analysis

The stiffness (or displacement-based) method is used in the solution of the structural model.

The following outlines the major analysis steps:

- The individual element stiffness matrix $[k]$ is computed in the element local coordinate system.
- Based on the element nodal connectivity, $[k]$ is transformed to the global coordinate system and assembled into the global stiffness matrix $[K]$.
- The load vector $[R]$ for each load combination is formed.
- The equation $[K] [U] = [R]$ is solved for the nodal displacements $[U]$.
- Other structural responses such as internal forces and moments are computed based on the nodal displacements.

9.1 Load Cases and Load Combinations

Each of the nodal loads, point loads, line loads, surface loads, and self weights must be assigned to a load case. The enforced displacements of supports are special loads and are considered in each load combination. The load cases are used as bases for the load combinations and are not solved directly. If you desire to solve for a particular load case, you may form a load combination with a unit load factor for that load case and 0s for all other load cases.

P-Delta analyses may be performed on one or more load combinations.

9.2 Linear, Non-linear Static Analyses

The program is capable of performing linear and nonlinear static analyses. The linear analysis may be applied to models where structural responses such as the displacements are expected to be linearly related to the applied loads. Otherwise the nonlinear analysis must be applied. The program currently handles two types of nonlinearity: the element nonlinearity when compression-only springs or tension-only springs are present, and the geometric nonlinearity which is commonly known as the P-Delta effect. The P-Delta effect refers to the axial stress influence on the element bending stiffness. Generally, a tensile axial force increases the element bending stiffness while a compressive axial force reduces the element bending stiffness. The P-Delta effect exists in both members and shell elements. However, the program only accounts for the P-Delta effect on members.

The program assigns each load combination to be linear or nonlinear just before analysis is performed. If a model includes one or more nonlinear elements (compression-only springs or tension-only springs), the entire problem becomes nonlinear, that is, all load combinations are assigned to be nonlinear. If there are no

nonlinear elements present in the model, only the P-Delta load combinations are set to be nonlinear while the rest of load combinations are linear. The non-linear load combinations must be solved iteratively and therefore are potentially time consuming. Analyses are performed on all linear load combinations first and then on all nonlinear load combinations.

In order to avoid excessive iterations on nonlinear load combinations, you can use the command Analyze > Analysis Options to set “Maximum nonlinear iterations”. For the P-Delta load combinations, you can use the same command to set “Axial force tolerance between P-Delta iterations”. A tolerance of 0.5% is normally acceptable. It is strongly recommended that you perform linear analyses for all load combinations before you attempt P-Delta analyses. In this way, you can identify any modeling problems prior to performing more rigorous and generally more time consuming P-Delta analyses.

It may be interesting to note that the P-Delta analysis may be used to estimate the buckling load of a structure for a P-Delta load combination. To do that, try to apply different scales (λ) uniformly to the load factors of all load cases in the P-Delta load combination, until a zero or negative diagonal term is detected in the global stiffness matrix during the solution process. The lowest scale λ is the buckling load factor.

9.3 P-Delta ($P-\Delta$) vs. P-delta ($P-\delta$)

The P-Delta ($P-\Delta$) refers to the second order effect associated with the lateral translation of the members [Ref. 10, 11, 12]. Consider the moment M at the bottom of the column in Figure 18.1. If the effect of the axial force on bending is ignored, $M = H * L$. However, if the effect of the axial force on bending is considered, $M = H * L + P * \Delta$. The increase in moment in turn increases the deflection Δ , which further increases M , and so on. An equilibrium will eventually be reached unless the axial load P exceeds the column critical buckling load.




Figure 18.1

P-delta ($P-\delta$) refers to the second order effect associated with the member curvature [Ref. 10, 11, 12]. Consider the moment M at the middle of the column in Figure 18.2. A secondary moment $P * \delta$ is induced by the axial load acted upon the lateral deflection of the column. This additional moment will cause more lateral deflection, which in turn will induce more secondary moment, and so on. An equilibrium will eventually be reached unless the axial load P exceeds the column critical buckling load.




Figure 18.2

The presence of the axial force in effect reduces the column bending stiffness. The member geometric stiffness accounts for this reduction. The P-Delta analysis in the program is capable of handling both $P-\Delta$ and $P-\delta$ effects. In order to account for the $P-\delta$ component, however, you must split compression members (columns) into several segments. Normally four segments for each column are enough. The program provides the command Edit > Split Members to automatically split members.

As an example [Ref. 13], assume in Figure 19.2, the beam-column is of $L = 12$ ft in length, and is subjected to an axial compressive load of $P = 100$ kips and a transverse load of $Q = 6$ kips at midspan. The member section: 4 x 4 inches, $I = 21.33 \text{ in}^4$, $A = 16 \text{ in}^2$. The material: $E = 30000 \text{ ksi}$, $\nu = 0.30$. Theoretical results are calculated as follows:

Linear (bending only): $M_{mid} = \frac{QL}{4} = 18$ ft-kips; $\delta_{mid} = \frac{QL^3}{48EI} = 0.583$ in

P- δ (bending and axial load): $u = \frac{L}{2} \sqrt{\frac{P}{EI}} = 0.90$ radian (or 51.57°)

$M_{mid} = \frac{QL}{4} \frac{\tan(u)}{u} = 25.2$ ft-kips; $\delta_{mid} = \frac{QL}{4P} \frac{\tan(u) - u}{u} = 0.864$ in

To solve this problem in the program, we can create one linear load combination and one P-Delta load combination. Since the problem involves the P- δ effects, the beam-column must be modeled with multiple elements (4 beam elements generally sufficient). The results from the program are compared with the theoretical results below:

The moments and deflections at the midspan for linear and P- δ behaviors

Analysis Type	Effects	ENERCALC 3D	Theoretical
Linear	δ_{mid} (in)	0.5832	0.583
	M_{mid} (ft-kips)	18	18
P- δ	δ_{mid} (in)	0.8643	0.864
	M_{mid} (ft-kips)	25.203	25.2

9.4 Solution Algorithm

Mathematically, the static analysis involves solving the following simultaneous equations:

$$[K] [U] = [R]$$

where $[K]$ is the global stiffness matrix, $[U]$ is the displacement vector, and $[R]$ is the load vector for each load combination.

There are two solution algorithms used in ENERCALC 3D: skyline and sparse. The skyline solution algorithm used to solve the equation above was developed by K.J. Bathe [Ref. 1]. It is an active column (also called profile or skyline) solver that involves the factorization of a stiffness matrix and the back-substitution of the load vector. The factorization generally takes most of solution time while the back-substitution is relatively fast. For all linear load combinations, the factorization only needs to be performed once. For nonlinear load combinations, the factorization has to be performed multiple times on each load combination because the global stiffness matrix has to be updated during the solving process. This is the reason why linear and nonlinear load combinations are analyzed separately.

The sparse solver only stores non-zero elements in the global stiffness matrix, thus it is both more memory efficient and much faster than the skyline solver. It also has the option to use an out-of-core approach to minimize the requirement of computer memory. This is useful to solve extremely large structural models. The sparse solver is available for static analysis only. It lacks some of the informative error messages when something goes wrong during the solution process.

9.5 Solution Accuracy and Stability

At the very basic level, the solution involves basic arithmetic operations such as addition, subtraction, multiplication and division on floating point numbers. Since all numbers in computers are stored in finite number of bits or digits, round-off errors are introduced by manipulations of these numbers. Round-off errors depend on the precisions of floating point arithmetic and may affect the solution accuracy and stability under certain circumstances. Two types of precisions are generally available on most computers today: single precision and double precision. A single precision (or 32-bit) floating point value has numerical accuracy of about 7 significant digits while a double precision (or 64-bit) floating point value has numerical accuracy of about 15 or 16 significant digits.

Take a look at the following example:

$$A = 1.00000001; B = -1.0; C = 1.0; D = C / (A + B);$$

Theoretically, $D = 100000000.0$. With 64-bit floating point arithmetic, the statement yields $D = 100000000.60775$ while with 32-bit floating point arithmetic, the statement yields $D = +\infty$. As we can see, D is approximately (not exactly) equal to the theoretical answer with double precision arithmetic. The solution collapsed (division by zero) with single precision arithmetic. The reason for this to happen is during the addition of A and B , the fractional part of A (0.00000001) is rounded off due to lack of enough significant digits. In general, 32-bit floating point arithmetic should never be used in any structural or finite element analysis programs.

The 64-bit floating point (double precision) has been the predominant solver over the last several decades. For most not-so-large and well-conditioned models, standard

64-bit floating point solvers produce results that are sufficiently accurate for practical uses. However for very large and complex models and especially those under ill-conditioned circumstances, standard 64-bit floating point solvers sometimes produce inaccurate results.

Ill-conditioning occurs when small errors in the coefficients of equations before or during the solution process have large impact on solution results. It may make the solution unstable and results unreliable. Very severe ill-conditioning may even make the coefficient matrix singular and thus a solution non-existent. Some examples where ill-conditioning may occur are: finite elements with severe shape distortion or large aspect ratio; shells with very strong in-plane stiffness and very weak out-of-plane bending stiffness; very flexible elements connected to very stiff elements. *It may be worthwhile to note that when ill-conditioning does happen, finer element meshes tend to make the problem worse.*


During the solution process of a large model, round-off errors tend to accumulate. We can determine the number of significant digits lost based on the diagonal decay ratio [Ref. 3].

$$r_i = K_{ii} / P_{ii}$$

where K_{ii} is the original diagonal coefficient of the global stiffness matrix and P_{ii} is the reduced value of K_{ii} just before it is used for back-substitution. The number of significant digits lost is about $\log_{10}(r_i)$. For example, if r_i is 10^8 , then 8 digits are lost. The solution results given by the 64-bit floating point (double precision) are unreliable if 12 or more significant digits are lost during the solution process. The program reports the number of digits lost during the solution process.

Consider the following cantilever beam under a tip load of 10,000 lbs:

- $L = 100$ in; $I_{zz} = 200$ in⁴;
- $E = 2.9e7$ psi; $\nu = 0.3$;
- $P = -10000$ lb



The beam is modeled with 1, 1000, 10000, 20000, 50000 elements and an analysis is performed on each model. Theoretically all models should yield the same tip deflection of -0.5747 inch (shear deformation ignored). The following table shows tip deflections for the all five models using the 64-bit floating point (double precision) in the program.

Effect of number of elements on accuracy (the 64-bit skyline solver) of a cantilever beam

No of elements	1	1,000	10,000	20,000	50,000
Tip deflection (in)	-0.5747	-0.5748	-0.6522	-0.1534	No solution
No of digits lost	0	8	12	12	-

As we can see from the table above, the tip deflections given by the 64-bit skyline solver tend to deteriorate in accuracy as the number of elements increases. For the model with 50,000 elements, some diagonal terms in the global stiffness matrix even become negative. The solver has to abort and the solution is not obtainable anymore.

After identifying a severe ill-conditioning problem, the 64-bit floating point (double precision) generally stops the solution process. **No results are better than wrong results.** To address the problem, a more accurate solver is needed. ENERCALC 3D implements a unique 128-bit floating point (quad precision) solver which offers unparalleled advantages in solution accuracy and most importantly solution stability over the standard 64-bit floating point (double precision) solver. The 128-bit floating point (quad precision) provides numerical accuracy up to 30 significant digits. Many of ill-conditioned problems for the 64-bit floating point solver become well-conditioned problems for the 128-bit floating point solver. The superiority of the 128-bit floating point solver can be demonstrated by running the same cantilever beam above with 50,000 elements, the tip deflection given by the 128-bit floating point (quad precision) is -0.5747 inch, the correct answer.

A more practical application of the 128-bit floating point (quad precision) may be in the modeling of a rigid diaphragm (e.g. floor with much larger in-plane stiffness than out-of-plane stiffness). Most of the other programs model this kind of rigid diaphragm action through master-slave constraints in order to avoid numerical difficulties. With the 128-bit floating point solver available in ENERCALC 3D, you may model the floor as a flexible diaphragm, yielding much more realistic results.

It should be pointed out that the 128-bit floating point (quad precision) requires twice as much memory as the 64-bit floating point (double precision). It is also significantly slower. However, in situations where the standard 64-bit floating point solver produces unreliable or even wrong results, the 128-bit floating point (quad precision) provides an invaluable alternative. Between faster but wrong results and slower but correct results, the latter is obviously preferable.

Frequency Analysis

10 Frequency Analysis

The frequency analysis solves for frequencies and corresponding mode shapes (eigenvectors) of the structural system. Many concepts discussed in the previous chapter-“Static Analysis”, apply to the frequency analysis as well.

10.1 Solution Algorithm

Mathematically, the frequency analysis involves solving the following Eigen problem:

$$[K] [\Phi_i] = \lambda_i [M] [\Phi_i]$$

where $[K]$ is the global stiffness matrix, $[M]$ is the global mass matrix, $[\Phi_i]$ is the i th mode shape and λ_i is the i th eigenvalues which is equal to the free vibration circular frequency squared $(\omega_i)^2$. Other related values are frequency f_i which is $2\pi \omega_i$ and period T_i which is $1 / f_i$. For practical reasons, we are generally interested only in the lowest eigenvalues (and therefore lowest frequencies).

The solution of eigenvalue problems must be iterative in nature because it is equivalent to finding the roots of the polynomial $p(\lambda)$. The solution algorithm to solve the equation above is given by K.J. Bathe [Ref. 1]. It uses the subspace iteration method to iteratively find the lowest p eigenvalues $\lambda_1, \lambda_2, \dots, \lambda_p$ and corresponding vectors $[\Phi_1], [\Phi_2], \dots, [\Phi_p]$. Eigenvalues are extracted in ascending order. Each eigenvector is then normalized such that $[\Phi_i]^T [M] [\Phi_i] = [I]$ where $[I]$ is the identity matrix, a diagonal matrix with unit values along the main diagonal.

A tolerance may be set before the solution to control the convergence of eigenvalues during each successive solver iteration. It is expressed as the following:

$(i = 1, 2, \dots, \text{number of requested modes})$
 where k is the subspace iteration counter.

To prevent excessive computing time, a maximum number of subspace iterations may be set before the solution. If the solver reaches this limit without convergence, the eigen results should not be trusted.

At the completion of the solution, an error measure is computed for each eigenvalue according to the following [Ref 1]:

$$\text{Error Measure} =$$

Where \mathbf{v} is the vector in the matrix corresponding to and the eigenvalues are accurate to about $2s$ digits if Error Measure is less than 10^{-2s} .

10.2 Mass and Stiffness

The global mass matrix $[M]$ is diagonal and is computed based on the load combination for frequency analysis and/or additional nodal masses/mass moments of inertia. The load combination for frequency analysis may be specified in Run > Frequency Analysis. The program will automatically convert all forces (not moments) in the positive or negative gravity direction to nodal masses and apply them in all available mass degrees of freedom. Additional nodal masses and mass moments of inertia may be input from Loads > Additional Masses or Input > Additional Masses. Zero terms in the global mass matrix $[M]$ are allowed. The number of eigenvalues requested must be fewer than the mass DOFs which is the number of nonzero diagonal terms in $[M]$. Due to the lumped mass modeling, the elements should be properly divided or submeshed for a continuous vibration model. For example, a beam with uniformly distributed mass should be divided into at least eight elements in order to find accurate vibration results.

The load combination for frequency analysis is also used to compute the global stiffness matrix $[K]$ if the model response is not linear. This may be the case if 1). The load combination for frequency analysis is of P-Delta type; or 2). The model contains nonlinear elements such as compression-only springs. In the first case (geometric nonlinearity), the compressive forces decrease the model stiffness (and therefore lengthen the vibration periods of the model) while tensile forces increase the model stiffness. The influence of the axial loads is greater on the lower frequencies than on the higher ones. The effect of nonlinearity on the stiffness matrix of the structure is incorporated as follows:

- An iterative (nonlinear) static analysis is first performed with the loads in the load combination for frequency analysis.
- The stiffness matrix at the end of the static analysis will be used in the frequency analysis. The stiffness therefore includes geometric and element nonlinearities corresponding to the end of the nonlinear static analysis.

Forced displacements at supports are ignored in frequency analysis.

10.3 Solution Convergence

Due to the iterative nature in the eigen solution, much more computational effort is required (in order to achieve satisfactory convergence) in frequency analysis than in static analysis. Another important difference is solution stability, which is more difficult to achieve in frequency analysis. To ensure that the smallest required eigenvalues and the corresponding eigenvectors have been computed, the program performs a *Sturm* sequence check after the subspace iterations [Ref 1]. A warning message is given in the solver dialog box if some eigen values are missing after the Sturm sequence check. Under some rare circumstances, the solution may become unstable and the solver has to abort the solution process

Several remedies can be used to address the solution instability and solution divergence.

- 1). Solve for fewer number of modes.
 - 2). Use larger number of iteration vectors.
 - 3). Use 128-bit floating point arithmetics instead of 64-bit floating point arithmetics.
- These remedies may be used in tandem. Once again, the 128-bit floating point arithmetics is especially effective for solution stability.

The maximum number of subspace iterations is set to 18 by default. If no convergence is achieved at this limit, you should rerun the frequency analysis with a larger maximum number of subspace iterations.

Concrete Design – ACI

318 02/05/08/11/14

11 Concrete Design – ACI 318-02/05/08/11/14

The concrete design module performs concrete design for beams, columns and plates (bending only) according ACI 318-02, 05, 08, 11 and 14 [Ref. 19]. Static analysis must be performed successfully before concrete design can be performed. Sound engineering judgment is especially important to interpret and apply the design results given by the program.

Note: The provisions that apply for ACI 318-02 and 05 shall apply to ACI 318-08, 11 and 14 unless explicitly stated otherwise.

11.1 Concrete Column Design

General

The concrete column module designs concrete rectangular or circular columns against axial, uniaxial or biaxial bending as well as shear based on ACI 318-02/05/08/11/14 Code Provisions. The program generates **EXACT** (not approximate or empirical) P-Mx-My interaction surfaces for all sections according to user-specified design criteria.

The capacity ratio is computed for each column based on capacity interaction surfaces and axial force-biaxial bending in each load combination. Slenderness effects are considered for both non-sway (braced) and sway (unbraced) frames. Shear design in columns is based on the shear force envelope with the option to include or exclude axial force influence on concrete shear capacity.

Axial Load and Moment Convention

For concrete design, compressive and tensile axial loads have positive and negative signs respectively. The major moment is designated as Mx in design as opposed to Mz used in analysis output. The minor moment is designated as My in both analysis and design.

Solution Assumptions

- The strain in reinforcement and concrete is directly proportional to the distance from the neutral axis (ACI 318-02/05 10.2.2).
- The maximum usable strain at the extreme concrete compression fiber is equal to 0.003 (ACI 318-02/05 10.2.3).
- The stress of steel is $f_s = E_s * \epsilon_s$ but $f_s \leq f_y$ where $E_s = 29000$ ksi, ϵ_s is steel strain and f_y is the yield strength of steel (ACI 318-02/05 10.2.4).
- The tensile strength of the concrete is neglected in flexural calculation (ACI 318-02/05 10.2.5).
- A uniformly distributed stress of $0.85f_c$ is assumed over an equivalent compression zone bounded by the edge of the cross section and a line parallel to the neutral axis at a distance $a = \beta_1 * c$ where c is the distance from extreme compression fiber to neutral axis (ACI 318-02/05 10.2.7.1).

- $\beta_1 = 0.85 - 0.05 * (f'_c - 4)$ and $0.65 \leq \beta_1 \leq 0.85$ and f'_c unit is ksi
- Reinforcement ratio ρ should be $1\% \leq \rho \leq 8\%$ for column sections (ACI 318-02/05 10.2.7.3).


Solution Algorithms

1. All sections are **EXACTLY** solved biaxially based on the solution assumptions above. Each section is solved based on the following steps.

2. Nominal Strength Calculation (P_n, M_{nx}, M_{ny})

2a. The nominal capacity of a section is computed at successive choices of biaxial angles. The choices of angles are based on the user input for biaxial angle steps found in the command Concrete > Design Options. Biaxial angle steps affect the solution accuracy and speed. For biaxial problems, steps must be multiples of 4. A value of 16 ~ 32 is sufficiently accurate for most sections. The adequacy of biaxial angle steps can be determined by smoothness of the M_x - M_y interaction diagram. For uniaxial problems, biaxial angle steps should be set to 4. This will give P - M_x (+) at 0 degree angle, P - M_x (-) at 180 degrees angle, P - M_y (+) at 90 degree angle, P - M_y (-) at 270 degrees angle.

The number of biaxial angle steps is analogous to the number of sides of a polygon used to approximate a circle or ellipse. A uniaxial solution in the program is therefore analogous to using a square to approximate a circle or a rectangle to approximate an ellipse. A biaxial solution with 16 angle steps is analogous to using a 16-sided polygon to approximate a circle or an ellipse. Obviously, the 16-sided polygon is closer or more accurate to approximate a circle than a square. The moral of this comparison is that a low value of biaxial angle steps tends to give more conservative biaxial capacity for the section.



2b). For each biaxial angle, P_n , M_{nx} , M_{ny} and maximum tensile steel strain ϵ_t are computed at successive choices of neutral axis distance c using strain compatibility and stress-strain relations to establish bar forces and the concrete compressive results. The choices of c are based on the neutral axial steps found in the command Concrete > Design Options. Neutral axial steps affect the solution accuracy and speed. A value of 250 ~ 500 for neutral axis steps is sufficiently accurate for most sections. The adequacy of neutral axis steps can be determined by smoothness of the P - M_x and/or P - M_y interaction diagrams. In addition, the program always computes several control points. They are maximum P_n (compression), minimum P_n (tension), $f_s = 0$; $0.25f_y$; $0.5f_y$ and $1.0f_y$ (balanced condition). Concrete displaced by steel may be optionally included or excluded (by default).

2c). M_{nx} - M_{ny} contour curves are computed for successive choices of axial forces. This is achieved through interpolation on the P_n , M_{nx} and M_{ny} already calculated for each biaxial angle in the procedure above. The choices of axial forces are based on the neutral axial steps found in the command Concrete > Design Options.

3. Design Strength Calculation (ϕP_n , ϕM_{nx} , ϕM_{ny})

Design strength according to ACI 318-02,05/08/11/14 is obtained by multiplying P_n , M_{nx} and M_{ny} of each biaxial angle by applying strength reduction factor ϕ as determined in the following (ACI 318-02/05 9.3.2):

$\Phi_c = 0.65$, $\alpha = 0.80$ for tied confinement

$\Phi_c = 0.70$, $\alpha = 0.85$ for spiral confinement for ACI 318-02/05

$\Phi_c = 0.75$, $\alpha = 0.85$ for spiral confinement for ACI 318-08/11/14

For ($\epsilon_t \leq \epsilon_y$, compression-controlled sections)

$$\phi = \Phi_c$$

For ($\epsilon_t > 0.005$, tension-controlled sections)

$$\phi = 0.90$$

For ($\epsilon_y < \epsilon_t < 0.005$)

$$\phi = \Phi_c + (0.9 - \Phi_c) * (\epsilon_t - \epsilon_y) / (0.005 - \epsilon_y)$$

where ϵ_t is maximum tensile steel strain for the biaxial angle and ϵ_y is steel yield strain (at balanced condition)

In addition, ϕP_n must be always less than the following (ACI 318-02/05 10.3.6.1)

$\Phi_c * \alpha * [0.85 * f'_c * (A_g - A_s) + f_y * A_s]$ if concrete displaced by steel is excluded
or

$\Phi_c * \alpha * [0.85 * f'_c * A_g + f_y * A_s]$ if concrete displaced by steel is not excluded.

4. Capacity Ratio

Capacity ratio is computed for each section based on the loads and the capacity of the section. It is defined as the following:

For a given load set (P_u, M_{ux}, M_{uy}) , find the section capacity M_x - M_y contour at $\phi P_n = P_u$. The capacity ratio for the load set is the larger of:

$$\left(\frac{\sqrt{(M_{ux})^2 + (M_{uy})^2}}{\sqrt{(\phi M_{nx, \max})^2 + (\phi M_{ny, \max})^2}}; \frac{P_u}{(\phi P_{n, \max})} \right)$$


Where $(\phi M_{nx, \max}, \phi M_{ny, \max})$ is the interaction point between the line from point (M_{ux}, M_{uy}) to point $(0, 0)$ and the M_x - M_y contour line. $\phi M_{nx, \max}$ is the maximum compression or tension capacity of the section, depending on the positive or negative sign of P_u . If P_u is outside the maximum compression or tension capacity, a capacity ratio of 99.9 is assigned.

A capacity ratio equal or less than 1.0 means the design strength is greater than the required strength; and the section is adequate to resist all input loads. A capacity ratio greater than 1.0 means the design strength is less than the required strength and the section is inadequate to resist all input loads. *It is important to realize that capacity ratio defined in the program is just a measure of section adequacy against loads. It should not be equated to a factor of safety.*

Capacity Ratio Calculation Example

To illustrate the calculation of capacity ratio in the program, see the following example.

For a given load set $(P_u, M_{ux}, M_{uy}) = (333 \text{ kip}, 180 \text{ ft-kip}, 125 \text{ ft-kip})$, a M_x - M_y capacity contour at $\phi P_n = 333 \text{ kip}$ is obtained as shown below. In addition, the maximum compression capacity = 1050.2 kip.



The interaction point between the line from point (180 ft-kip, 125 ft-kip) to point (0, 0) and the contour line is obtained as (214.1 ft-kip, 148.7 ft-kip)

$$\frac{\sqrt{(M_{ux})^2 + (M_{uy})^2}}{\sqrt{(\phi M_{ux,max})^2 + (\phi M_{uy,max})^2}} = \frac{\sqrt{(180)^2 + (125)^2}}{\sqrt{(214.1)^2 + (148.7)^2}} = 0.841$$

$$\frac{P_u}{(\phi P_{u,max})} = \frac{333}{1050.2} = 0.317$$

Therefore, the capacity ratio corresponds to the load set is 0.841. The section is adequate to resist the load.

P-δ and P-Δ Effects ¹¹⁹

Two types of second-order moment effects may develop in a frame.

- 1). P-δ effect is associated with individual member curvature. Additional second-order moment may develop by member (usually a column) axial force (P) acting upon the lateral deflection (δ) of the column axis away from the chord connecting the column ends. It is possible to account for P-δ effects on columns independently.

2). P-Δ effect is associated with the lateral drifts of the frame members. Additional second-order moment may develop by axial force (P) acting upon the lateral translation (Δ) of the frame nodes relative to their original position. It is NOT possible to account for P-Δ effects on columns independently.

Slenderness Effects ^[195]

For a non-sway frame, P-Δ effect may be safely ignored and the first-order structural analysis is therefore sufficient. The program then accounts for P-δ effect by magnifying the first-order moments using ACI moment magnification method.

For a sway frame, the second-order structural analysis must be performed to account for P-Δ effect. In addition, the program accounts for P-δ effect by magnifying the second-order moments using ACI moment magnification method. In fact, all columns in sway frames must first be considered as braced columns under gravity loads acting alone.

Braced or Unbraced Column ^[195]

The column is considered braced if one of the following two criteria is met:

Criterion 1: Increase in column end moment due to second-order effects is less than 5% of the first-order moment

Criterion 2: Stability index Q for the column story under consideration from the first-order analysis

$$Q = \frac{(\sum P_u) \Delta_0}{V_u l_c} < 0.05 \quad (\text{ACI 318-02/05 Eq10-6})$$

Section Properties for Structural Analysis and Computing K ^[198]

It is important to point out that in both first- and second-order analyses; appropriate member stiffness must be used to account for the effects of axial loads, cracking, and creep.

$$E_c = 57000 \sqrt{f_c} \text{ for normal weight concrete}$$

$$E_c = w_c^{1.5} 33 \sqrt{f_c} \text{ for } w_c \text{ between 90 and 155 lb/ft}^3$$

Moment of inertia (ACI 318-02/05 10.11.1)

$$= 0.35 I_g \text{ for beams and cracked walls}$$

$$= 0.70 I_g \text{ for columns and uncracked walls}$$

$$= 0.25 I_g \text{ for flat plates and flat slabs}$$

Area

$$A = 1.0 A_g$$

Note:

a). I_g and A_g are based on the gross concrete cross section, neglecting reinforcement.

- a). I_g for Tee beams can be closely approximated as 2 times I_g for the web.
 b). $0.70 I_g$ should be used for walls first. If the factored moments and shears indicate that a portion of the wall will crack due to stresses reaching the concrete modulus of rupture, the analysis should be repeated with $0.35 I_g$ for the cracked portions of the wall.

[Ref. 16 pp577]

The program allows a user to modify the moments of inertia through Element Cracking Factor from Concrete > Cracking Factors. In order to use stiffness reduction, you also need to check “Use cracked section properties (I_{cr}) for members and finite elements” in Analysis Options. This allows you to consider or ignore cracking in the analysis without re-entering element cracking information.

Radius of Gyration

$$r = \sqrt{I_g / A_g}$$

Effective Length Factor K ^[195]

Find relative stiffness ratios (Ψ_1 and Ψ_2) of columns and beams at the top and bottom joints of the column

$$\Psi = \frac{\sum \frac{EI}{L} \text{ for column members}}{\sum \frac{EI}{L} \text{ for beam members}}$$

Section properties are the same as used in the first-order analysis (step 1)

For practical reasons, $\Psi = 0.2$ for fixed end and $\Psi = 20$ for hinged end.

The effective length factor K is solved from the from the following equations
 For braced frames:

$$\frac{\Psi_1 \Psi_2 \pi^2}{4K^2} + \frac{\Psi_1 + \Psi_2}{2} \left[1 - \frac{\pi/K}{\tan(\pi/K)} \right] + \frac{2}{\pi/K} \tan\left(\frac{\pi}{2K}\right) - 1 = 0$$

For unbraced frames:

$$\frac{\Psi_1 \Psi_2 (\pi/K)^2 - 36}{6(\Psi_1 + \Psi_2)} - \frac{\pi/K}{\tan(\pi/K)} = 0$$

The program provides a tool to calculate the effective length factor K based on the input Ψ_1 and Ψ_2 . The equations above provide a more accurate K calculation than what is given by (ACI 318-02/05 10.12.1)

Unsupported Length L_u 195

The unsupported lengths L_{uy} , L_{uz} of a column are the clear distances between lateral supports in column local y and z directions (ACI 318-02/05 10.11.3.1). A zero value of L_u means that it is equal to the member length between the end nodes.

For non-sway frames, an optional check is made $kL_u / r \leq 34 - 12(M_1/M_2)$ (ACI 318-02/05 Eq10-7). Braced frame k is used here. L_u is unbraced length in local x and y directions. M_1 and M_2 are the smaller and larger factored end moments on the compression member respectively. (M_1/M_2) is positive if the member is bent in single curvature and negative otherwise.

For sway frames, an optional check is made $kL_u / r \leq 22$ (ACI 318-02/05 10.13.2). Sway frame k is used here.

Minimum Moments

The program calculates minimum moments for both braced and unbraced frames, $M_{min} = P_u(0.6 + 0.03h)$, where h is in inches (ACI 318-02/05 10.12.3.2). The program conservatively applies the minimum eccentricity about both axes simultaneously.

Equivalent Moment Factor C_m (ACI 318-02/05 10.12.3.1)

$$C_m = 1.0 \quad \text{if } M_1 = 0 \text{ or } M_2 = 0$$

$$C_m = 1.0 \quad \text{if transverse load exists}$$

$$C_m = 0.6 + 0.4 \frac{M_1}{M_2} \geq 0.4 \quad \text{if end moments only. (ACI 318-02/05 Eq10-13).}$$

Although not required, the program also conservatively applies $C_m \geq 0.4$ for ACI 318-08/11/14.

The sign of $\frac{M_1}{M_2}$ is: positive if the column is bent in single curvature, negative otherwise.

Note, C_m is only applicable to non-sway frames. You have the conservative option to always use $C_m = 1.0$ from Model Design Criteria under Concrete > Design Criteria.

Section Properties for Critical Loads Computation

The EI used in the frame analysis above is an average value. In designing individual columns, the following reduced EI should be used to reflect the greater chance of cracking:

$$EI = \frac{0.4E_c I_g}{1 + \beta_d} \quad (\text{ACI 318-02/05 Eq10-12})$$

The Infamous β_d

The ratio of maximum factored axial sustained load to maximum factored axial total load. The factor β_d accounts for the effects of creep.

$$\beta_d = \frac{\text{Factored Dead Load}}{\text{Factored Dead Load} + \text{Factored Live Load}}$$

Generally:

Critical Load P_c

$$P_c = \frac{\pi^2 EI}{(kl_u)^2} \quad \text{where } k \leq 1.0 \quad (\text{ACI 318-02/05 Eq10-10})$$

Moment Magnification Factor

$$\delta_{ns} = \frac{C_m}{1 - \frac{P_u}{0.75P_c}} \geq 1.0 \quad (\text{ACI 318-02/05 Eq10-9})$$

P_u is the average of axial force at both ends. If $1 - \frac{P_u}{0.75P_c} < 0$, the design fails and a capacity ratio of 999.9 is assigned.

Other Requirements

Reinforcement ratio for columns:

Bar requirements: minimum 4 bars for tied columns, 6 bars for spiral columns.

Tie requirements: $\geq \#3$ for No. 10 longitudinal bars and smaller; $\geq \#4$ for No. 11 14, 18 longitudinal bars.

Column Trial Size

The ACI code requires that the reinforcement ratio for columns be within

$$0.01 \leq \rho_t \leq 0.08 \quad \text{It is usually economical to have } \rho_t = 0.01 \sim 0.02$$

For tied columns

$$A_s \geq \frac{P_u}{0.40(f'_c + f_y \rho_t)}$$

For spiral columns

$$A_s \geq \frac{P_u}{0.45(f'_c + f_y \rho_t)}$$

Based on rectangular or circular sections used for analysis, the program will generate column sections with different reinforcement configurations.

Column Shear Reinforcement

The column shear design is based on

$$\phi(V_c + V_s) \geq V_u \quad (\text{ACI 318-02/05 Eq11-1})$$

where $\phi = 0.75$.

Given b_w , d , f'_c , f_y , number of stirrup legs n , and stirrup (tie) area A_v , the required stirrup spacing is computed at every analysis station.

Concrete shear strength

1. For $P_u < 0$ (column subjected to tension)

$$\phi V_c = \phi 2 \left(1 + \frac{N_u}{500 A_g} \right) \sqrt{f'_c} b_w d \geq 0 \quad (\text{ACI 318-02/05 Eq11-8})$$

2. For $P_u \geq 0$ (column subjected to compression)

$$\phi V_c = \phi 2 \left(1 + \frac{N_u}{2000 A_g} \right) \sqrt{f'_c} b_w d \quad (\text{ACI 318-02/05 Eq11-4})$$

Note:

- For circular section, $b_w = 2R$ and $d = 0.8(2R)$ where R is the radius of the circular section. (ACI 318 11.3.3 and 11.5.7.3)
- $N_u = 0$ if the influence of compression on concrete shear strength is ignored.
- $\sqrt{f'_c} \leq 100 \text{ psi}$ (ACI 318 11.1.2)
- $f'_c \leq 60$ ksi in design of shear reinforcement. (ACI 318-02/05 11.5.2)
- Light-weight concrete is not considered.
- Torsional forces are not considered.

The following is the algorithm used to compute the stirrup (tie) spacing(s) in the program.

If $V_u - \phi V_c > \phi 8 \sqrt{f'_c} b_w d$, the design fails (ACI 318-02/05 11.5.7.9).

If $V_u < \frac{\phi V_c}{2}$, no stirrup required (ACI 318-02/05 11.5.6.1). *The program does not check member depths when applying minimum shear reinforcement for ACI 318-08/11/14.*

If $V_u - \phi V_c \leq \phi 4 \sqrt{f'_c} b_w d$, $s_{max} \leq \min(d/2, 24 \text{ in})$ (ACI 318-02/05 11.5.5.1)

If $V_u - \phi V_c > \phi 4 \sqrt{f'_c} b_w d$, $s_{max} \leq \min(d/4, 12 \text{ in})$ (ACI 318-02/05 11.5.5.3)

If $\phi V_c < V_u < \frac{\phi V_c}{2}$, $s = \min \left(\frac{A_v f_y}{0.75 \sqrt{f'_c} b_w}, \frac{A_v f_y}{50 b_w} \right) \leq s_{max}$ (ACI 318-02/05 11.5.6.3)

Otherwise, $s = \frac{\phi A_v f_y d}{V_u - \phi V_c} \leq s_{max}$ (ACI 318-02/05 Eq11-15)

According to ACI 318-02/05, column confinement spacing shall not exceed 16 longitudinal bar diameters, 48 tie bar or wire diameters, or the least dimension of the compression members.

The following additional requirements are needed for column spirals:

- The maximum center-to-center spacing:

$$s < \frac{\pi d_{sp}^2 f_y}{0.45 D_c f_c [A_g / A_c - 1]} \quad (\text{Derived from ACI 318-02/05 Eq10-5})$$

- The clear spacing between successive turns shall not exceed 3 inches, nor be less than 1 inch. (ACI 318-02/05 7.10.4.3)

11.2 Concrete Beam Design

General

The concrete beam module designs concrete rectangular or Tee beams against enveloped bending about strong axis (local z) and enveloped shear along local y. Axial force, bending about weak axis (local y), and torsion are not considered. Furthermore, no deep beam action is considered. If axial force or biaxial bending actions cannot be neglected, the use of column design module is recommended.

Beam Flexural Reinforcement

The beam top and bottom flexural reinforcement is computed at each analysis station along the beam length. Minimum reinforcement is computed for the bottom steel. The program designs each beam against positive or negative moment with single layer of tension steel with tension-controlled condition. For flexural design, the critical section at a support may be taken at the face of the support (but not greater than $0.175 \cdot$ span length from the support center). The program offers an option to account for these conditions by automatically computing beam support widths from Model Design Criteria under Concrete > Design Criteria.

The following algorithm assumes one layer of tension steel, that is, $d_t = d$, the depth of the tension steel centroid. This assumption is made due to its simplicity and conservative nature and is reasonable unless the tension steel strain is very close to 0.005 – the tension-controlled limit strain.

The design result is reflected in top and bottom reinforcement diagrams.

Rectangular Beam Flexural Design Algorithm

Given b , $d = d_t$, d' , f_c , f_y and M_u find required A_s (and A_s' if needed)

Step 1: Determine maximum moment without compression steel, using the tension-controlled limit $\epsilon_t = 0.005$ and $\phi = 0.9$.

$$c_0 = 0.375d$$

$$a_0 = \beta_1 c_0$$

$$C_{f0} = 0.85 f_c' b a_0$$

$$\phi M_{n0} = \phi C_{f0} \left(d - \frac{a_0}{2} \right)$$

$$A_{s0} = C_{f0} / f_y$$

Step 2: If $M_u \leq \phi M_{n0}$, design the section as singly-reinforced as follows:

$$R_n = \frac{M_u}{\phi(bd^2)}$$

$$\rho = \frac{0.85 f_c'}{f_y} \left(1 - \sqrt{1 - \frac{2R_n}{0.85 f_c'}} \right) \geq \rho_{\min} = \max\left(\frac{3\sqrt{f_c'}}{f_y}, \frac{200}{f_y} \right) \quad (\text{ACI 318-02/05 10.5.1})$$

$$a = \frac{\rho d f_y}{0.85 f_c'}$$

$$c = \frac{a}{\beta_1}$$

$$\varepsilon_s = \left(\frac{d_t - c}{c} \right) 0.003$$

$$A_s = \rho b d$$

Step 3: If $M_u > \phi M_{n0}$, design the section as doubly-reinforced as follows (still assuming the tension-controlled limit $\varepsilon_t = 0.005$ and $\phi = 0.9$):

$$f_s' = \left(1 - \frac{d'}{c_0} \right) 0.003 (E_s) \leq f_y$$

$$A_s' = \left(\frac{M_u - \phi M_{n0}}{f_s' (d - d') \phi} \right)$$

$$A_s = A_{s0} + A_s' \left(\frac{f_s'}{f_y} \right)$$

Note, the tensile steel required to balance the compressive steel is $A_s' \left(\frac{f_s'}{f_y} \right)$

The design fails if $f_s' < 0$. For practical reasons, the design also fails if $A_s' > \frac{1}{2} A_{s0}$.

Tee Beam Flexural Design Algorithm

Given b , b_w , h_f , $d = d_t$, f_c , f_y and M_u , find required A_s

Step a). Assuming $a \leq h_f$ and tension-controlled section with $\phi = 0.9$

$$R_n = \frac{M_u}{\phi(bd^2)}$$

$$\rho = \frac{0.85f'_c}{f_y} \left(1 - \sqrt{1 - \frac{2R_n}{0.85f'_c}} \right)$$

$$\rho_{\min} = \max\left(\frac{3\sqrt{f'_c}}{f_y}, \frac{200}{f_y}\right)$$

$$A_s = \max(\rho bd, \rho_{\min} b_w d)$$

$$a = \frac{A_s f_y}{0.85 f'_c b}$$

If $a > h_f$, go to Step b)

$$c = \frac{a}{\beta_1}$$

$$\varepsilon_s = \left(\frac{d_t - c}{c} \right) 0.003$$

If $\varepsilon_s < 0.005$, the design fails.

Step b). $a > h_f$ and tension-controlled section with $\phi = 0.9$

$$M_{\text{inv}} = M_u - \phi(0.85)f'_c(b - b_w)h_f \left(d - \frac{h_f}{2} \right)$$

$$R_n = \frac{M_{\text{inv}}}{\phi(b_w d^2)}$$

$$\rho_w = \frac{0.85f'_c}{f_y} \left(1 - \sqrt{1 - \frac{2R_n}{0.85f'_c}} \right)$$

$$a_w = \frac{\rho_w d f_y}{0.85 f_c'}$$

$$c = \frac{a_w}{\beta_1}$$

$$\varepsilon_s = \left(\frac{d_t - c}{c} \right) 0.003$$

If $\varepsilon_s < 0.005$, the design fails.

Beam Shear Reinforcement ¹⁹⁴

The member shear reinforcement (stirrup spacing) is computed at each analysis station along the member length. Stirrup size and number of legs are assumed uniform along the length of a member as part of input. For shear design, sections located less than a distance d from the face of the support may be permitted to be designed for V_u computed at a distance d from the support (ACI 318-02/05 11.1.3.1). The program offers an option to account for these conditions by automatically computing beam support widths from Model Design Criteria under Concrete > Design Criteria.

The design result is reflected in a stirrup spacing diagram.

Beam Shear Design Algorithm

The shear design for concrete beam is the same as that of concrete column except the axial force is always treated as zero.

11.3 Concrete Slab/Wall Design

General

The concrete slab/wall module designs concrete slabs or walls against enveloped positive and negative Wood-Armer bending moments in slab local x and y directions. Axial force action is ignored. The program produces contours of required areas of steel which can be averaged with some commonsense to finish the design.

Wood-Armer Moments

Wood-Armer Formula [Ref 18, pp198] is the most popular approach to convert M_x , M_y and M_{xy} to orthogonal plate design moments M_{ux} and M_{uy}

The procedure to obtain M_{ux} and M_{uy} for designing plate bottom reinforcement is as follows:

- $M_{ux} = M_{xx} + |M_{xy}|$
 $M_{uy} = M_{yy} + |M_{xy}|$
- If $M_{ux} < 0$ and $M_{uy} < 0$
 $M_{ux} = 0$
 $M_{uy} = 0$
- If $M_{ux} < 0$ and $M_{uy} > 0$
 $M_{ux} = 0$
 $M_{uy} = M_{yy} + |M_{xy} * M_{xy} / M_{xx}|$
- If $M_{ux} > 0$ and $M_{uy} < 0$
 $M_{uy} = 0$
 $M_{ux} = M_{xx} + |M_{xy} * M_{xy} / M_{yy}|$
- $M_{ux} \geq 0$
 $M_{uy} \geq 0$

The procedure to obtain M_{ux} and M_{uy} for designing plate top reinforcement is as follows:

- $M_{ux} = M_{xx} - |M_{xy}|$
 $M_{uy} = M_{yy} - |M_{xy}|$
- If $M_{ux} > 0$ and $M_{uy} > 0$
 $M_{ux} = 0$
 $M_{uy} = 0$
- If $M_{ux} > 0$ and $M_{uy} < 0$
 $M_{ux} = 0$
 $M_{uy} = M_{yy} - |M_{xy} * M_{xy} / M_{xx}|$
- If $M_{ux} < 0$ and $M_{uy} > 0$
 $M_{uy} = 0$
 $M_{ux} = M_{xx} - |M_{xy} * M_{xy} / M_{yy}|$
- $M_{ux} \leq 0$
 $M_{uy} \leq 0$

Wood-Armer Formula is a lower bound solution method which satisfies the following conditions for a given external load:

- The equilibrium conditions are satisfied at all points in the plate.
- The yield strength of the plate elements is not exceeded anywhere in the plate.
- The boundary conditions are complied with.

A lower bound solution is conservative in nature.

Stress Singularity

The stresses and bending moments at the point of a concentrated load on the slab are theoretically infinite. This *theoretically* means that if we used all the steel in the

world, we still did not have enough steel to resist the stress at that point. This is of course ridiculous. The reason is of course because we prescribe an impossible loading (“concentrated load”). If we distribute the load over a small area (circle), the stresses become finite.

In finite element analysis, the program will never give you a stress of infinite magnitude. Still, at a point of concentrated force such as a column acting on a flat plate, stresses may have rather significant spikes. According to Ugural [Ref 15, pp116], the actual stress caused by a load on a very small area of radius r_c can be obtained by replacing the actual r_c with an equivalent radius r_e .

$$r_e = \sqrt{1.6r_c^2 + t^2} - 0.675t \quad (r_c > 0.5t)$$

$$r_e = r_c \quad (r_c \leq 0.5t)$$

where t is the plate thickness.

By applying this method, we can use stresses at half of the slab thickness instead of those at the concentrated loading point. By excluding the finite elements (usually finely meshed) near the concentrated loading points, we can provide practical and reasonable design results.

[Flexural Reinforcement](#)¹⁹⁷

The plate top and bottom flexural reinforcement in local x and y direction is computed at each nodal point as well as the center. No minimum reinforcement is considered. The program only designs each plate with tension-controlled condition. The procedure is similar to that of concrete beams except no double reinforcement is considered.

Steel Design

12 Steel Design

The steel design module performs steel design for beams and columns according to AISC 14th edition LRFD [Ref. 21]. Static analysis must be performed successfully before steel design can be performed. Sound engineering judgment is especially important to interpret and apply the design results given by the program.

Due to the fact that the software provides step-by-step calculation procedures, the technical treatment of the design process is kept minimal here.

12.1 Section Orientation

The orientations of section local X and Y axes of various AISC shapes are shown below (Figure 20.1).




Figure 20.1

12.2 Member Internal Forces and Moments

1. Axial force P acts perpendicular to the section. Moments M_x and M_y act about section local X and Y axes respectively. They have the following sign conventions.

Axial Force P : positive for compression; negative for tension

Moment M_x : Positive when section top most fiber is under compression.

Moment M_y : Positive when section rightmost fiber is under compression.




Figure 20.2

2. All moments are referenced about the geometric centroid of the gross section.
3. Loads are the required strength computed by the code-specified factored load combinations using either hands or analysis program such as FastFrame-3D. It is assumed that an overall 2nd order P-Delta ($P-\Delta$) analysis has been performed on a sway structure. If desired, the program uses moment magnification procedure to calculate the P-delta ($P-\delta$) effect, which accounts for slenderness of columns in non-sway structure or for slenderness along the lengths of columns in sway structure.
4. Critical ratio (also called capacity ratio) is computed for each section based on the magnified factored loads and the capacity of the section. Critical ratio equal or less than 1.0 means the design strength is greater than the required strength and the section is adequate. Critical ratio greater than 1.0 means the design strength is less than the required strength and the section is inadequate.

12.3 Solution Algorithms

Because detailed step-by-step calculation procedure is available for each member on Steel > Design Result, we will not list the algorithm here.

This page is intentionally left blank.
Remove this text from the manual
template if you want it completely blank.

References

13 References

1. K.J. Bathe, "Finite Element Procedures" Prentice-Hall, Inc., 1996
2. O.C. Zienkiewicz, "The Finite Element Method", 3rd ed., McGraw-Hill Book Company (UK) Limited, 1983
3. R.C. Cook & D.S. Malkus & M.E. Plesha, "Concepts and Applications of Finite Element Analysis", 3rd ed., John Wiley & Sons, Inc., 1989
4. R.H. Macneal & R.L. Harder, "A proposed Standard Set of Problems to Test Finite Element Accuracy", pp3-20 of "Finite Elements in Analysis and Design", North-Holland, 1985
5. J.P. Hartog, "Advanced Strength of Materials", McGraw-Hill Book Company, 1952.
6. R.J. Roark & W.C. Young, "Formulas for Stress and Strain", 5th ed., McGraw-Hill Book Company, 1975.
7. W. McGuire & R.H. Gallagher & R.D. Ziemian, "Matrix Structural Analysis", 2nd ed., John Wiley & Sons, Inc., 2000
8. J.S. Przemieniecki, "Theory of Matrix Structural Analysis", McGraw-Hill, 1968
9. D. Breyer, "Design of Wood Structures", 3rd ed, McGraw-Hill, 1993
10. J. MacCormac, "Structural Steel Design LRFD Method", 2nd ed, HarperCollins College Publishers, 1995
11. A. Tamboli, "Steel Design Handbook LRFD Method", McGraw-Hill, 1997
12. ACI, "Building Code Requirements for Reinforced Concrete (ACI 318-89) (Revised 1992)", American Concrete Institute, Detroit, Michigan.
13. K. Leet & D. Bernal, "Reinforced Concrete Design", 3rd ed, McGraw-Hill Book Company, 1997.
14. A. K. Chopra, "Dynamic of Structures – Theory and Applications to Earthquake Engineering", 2nd ed, Prentice-Hall, 2001
15. Ansel Ugural, "Stresses in Plates and Shells" 2nd Edition, The McGraw-Hill Companies, Inc., 1999
16. James G. MacGregor & James K. Wight, "Reinforced Concrete – Mechanics and Design" 4th Edition, Pearson Prentice Hall, 2005
17. "Notes on ACI 318-02 Building Code Requirements for Structural Concrete", 8th Edition, Portland Cement Association, 2002
18. R. Park and W.L. Gamble "Reinforced Concrete Slabs", John Wiley & Sons, 1980
19. ACI, "Building Code Requirements for Structural Concrete (ACI 318-05) and Commentary (ACI 318R-05)", American Concrete Institute, Detroit, Michigan, 2004
20. Arthur H. Nilson, David Darwin, Charles W. Dolan, "Design of Concrete Structures", 13th Edition, McGraw-Hill Higher Education, 2004
21. AISC "Steel Construction Manual", 14th Edition

22. Charles Salmon, John Johnson and Faris Malhas, "Steel Structures" 5th Edition, Pearson Prentice Hall, 2009
-

The following works are not referenced directly in this documentation, but are the primary programming references in the development of this program. Like the great engineering works cited above, these great programming works deserve the respect of being listed here.

- a. B. Stroustrup, "The C++ Programming Language" 3rd ed., Addison-Wesley Publishing Company, 1997
- b. R. Wright & M. Sweet, "OpenGL SuperBible", 2nd ed., Waite Group Press, 2000
- c. D.J. Kruglinski, "Inside Visual C++", Microsoft Press, 1996
- d. M. Woo & J. Neider & T. Davis & D. Shreiner, "OpenGL Programming Guide", Addison-Wesley Publishing Company, 1999
- e. C. Petzold, "Programming Windows 95", Microsoft Press, 1996
- f. C. Musciano & B. Kennedy, "HTML The Definitive Guide" 3rd ed., O'Reilly & Associates, Inc., 1998

This page is intentionally left blank.
Remove this text from the manual
template if you want it completely blank.

Appendix

14 Appendix

14.1 Unit Conversions

From English to Metric			From Metric to English		
1 ft	=>	0.3048 m	1 m	=>	3.28084 ft
1 in	=>	25.4 mm	1 mm	=>	0.03937 in
1 kip	=>	4.44822 kN	1 kN	=>	0.22481 kip
1 lb	=>	4.44822 N	1 N	=>	0.22481 lb
1 kip-ft	=>	1.35582 kN-m	1 kN-m	=>	0.73756 kip-ft
1 kip-in	=>	0.112985 kN-m	1 kN-m	=>	8.85073 kip-in
1 lb-ft	=>	1.35582 N-m	1 N-m	=>	0.73756 lb-ft
1 lb-in	=>	0.112985 N-m	1 N-m	=>	8.85073 lb-in
1 kip/in ²	=>	0.00689476 kN/mm ²	1 kN/mm ²	=>	145.04 kip/in ²
1 lb/in ²	=>	0.00689476 N/mm ²	1 N/mm ²	=>	145.04 lb/in ²

14.2 Designations, diameters and areas of standard bars

ASTM 615 (English)			ASTM 615 96a (Metric)		
Bar No	Diameter (in)	Area (in ²)	Bar No	Diameter (mm)	Area (mm ²)
#3	0.375	0.11	#10	9.5	71
#4	0.500	0.20	#13	12.7	129
#5	0.625	0.31	#16	15.9	199
#6	0.750	0.44	#19	19.1	284
#7	0.875	0.60	#22	22.2	387
#8	1.000	0.79	#25	25.4	510

ASTM 615 (English)			ASTM 615 96a (Metric)		
#9	1.128	1.00	#29	28.7	645
#10	1.270	1.27	#32	32.3	819
#11	1.410	1.56	#36	35.8	1006
#14	1.693	2.25	#43	43.0	1452
#18	2.257	4.00	#57	57.3	2581