

Biamp Control FAQ

Specific information on Biamp Control products.

Generic for Impera controllers

- [Can I expand the Impera controller to control more devices with RS232, LAN or I/O's?](#)
- [Are all the keypad button functions predefined?](#)
- [What are the I/O ports usually for?](#)
- [How to connect an IR Emitter Single or Dual?](#)
- [What are the advantages of a bi-directional port over a uni-directional port?](#)
- [Why does the off button or all buttons on the keypad flash?](#)
- [What is the uSD memory card utilized for in the control system?](#)
- [What is the default IP address of a Impera LAN device?](#)
- [How do I access the control system GUI from a browser](#)
- [Can I control DMX with a Impera Control system?](#)
- [Why are wireless touch interfaces losing connection to the control system?](#)
- [What should I do when I want to use an Impera as a LAN extension?](#)
- [What is the maximum uSD memory card capacity supported?](#)
- [How do extension devices communicate with the control system?](#)
- [Which control systems are possible in the EasyConnect?](#)

Rack controllers

Impera Tango

- [How can I mount the Impera Tango?](#)
- [Can I connect 2x LAN units to the Impera Tango without the use of an extra LAN switch?](#)
- [What can I use the relays for and what are the ratings?](#)
- [Is there a PoE injector in the box?](#)
- [What is the Impera Tango PoE LED behavior?](#)
- [Can I learn IR commands with the Impera Tango?](#)
- [Which PoE standards are the Impera Tango working with?](#)
- [How should I connect the Tango and a Touch Device in a standard configuration?](#)

Impera Lima

- [How can I mount the Impera Lima?](#)
- [What can I use the relays for and what are the ratings?](#)
- [Can I learn IR commands with the Impera Lima?](#)
- [Which PoE standards are the Impera Lima working with?](#)

Impera Alfa II

[Which possibilities does the AlFa II have for adding physical buttons?](#)

Keypad controllers

Impera Sierra II

[The Sierra II won't start up after I tried uploading to it?](#)

[Can I power the SieRRa II with both PSU and PoE?](#)

[How do I use the built in infrared learner?](#)

[Does the Sierra II control system have different LED colors?](#)

[Is the Impera Sierra II expandable?](#)

[Is it possible to access a GUI \(Graphical User Interface\) with the Sierra II?](#)

Impera Uniform

[How-to get started with Impera Uniform?](#)

[How-to upload a project to the Uniform?](#)

[How do I power Impera Uniform?](#)

[Can the Impera Uniform be on-wall mounted?](#)

[Can I get additional symbols for the Impera Uniform?](#)

[Why is the selection of Fonts and Font sizes limited on Impera Uniform?](#)

[Can I change the display layout when a button is pressed?](#)

[What is the size of Impera Uniform?](#)

[Is the display readable in a dark room?](#)

Impera Echo Plus

[Is the Echo Plus expandable?](#)

Impera Echo

[Is the Echo expandable?](#)

Touch Panel controllers

Apprimo Touch 8i

[What are the connections and button functions on the Apprimo Touch 8i?](#)

[Which PoE standard is used by Apprimo Touch 8i?](#)

[Will the Apprimo 8i self assign APIPA Link-local address with DHCP enabled and no DHCP Server present?](#)

[How many Biamp Extensions can be controlled?](#)

[Which LAN extensions works with the Apprimo Touch 8i?](#)

[How many 3rd party LAN devices can be controlled?](#)
[Can I control RS232 devices and GPIO's on an Apprimo Touch 8i?](#)
[How can I upload a project to Apprimo Touch 8i?](#)
[How does the KNX License work on Apprimo Touch 8i?](#)
[How many Apprimo Touch 8i may be used in a project?](#)
[Are Apprimo Touch 4, 7 & 10 panels supported in a project with Apprimo Touch 8i as the control system?](#)
[Does the Apprimo Touch 8i support link local \(APIPA\) IP addressing?](#)

Automated controllers

Impera Quebec II & III

[Which versions of the Impera - Quebec are available?](#)
[The QueBec II does not detect a VGA signal. What could be the issue?](#)
[Can I use Displayport and other HDMI adaptors together with Biamp Quebec II/III ?](#)
[Can I use an HDMI extender/switch in combination with the Impera Quebec II and III?](#)
[The Impera Quebec II and III never turns off the monitor](#)
[Which input has the highest priority?](#)
[How does VGA detection work?](#)
[How does HDMI detection work?](#)

Biamp Control Extensions

Preamplifier PM4100

[How to update firmware on the PM4100?](#)
[How to use front panel operation?](#)
[Does the Preamplifier support PoE?](#)
[How can I control the Preamplifier?](#)
[Is it necessary to connect PoE to the PM4100 in order to configure it?](#)
[Are there any Volume up and down commands for the PM4100?](#)
[How do I access the settings in the Preamplifiers?](#)
[Why is the power LED of the preamplifier blinking red?](#)
[What can I use the second RS-232 port on the PM4100 for?](#)
[How to enable PUSH mode for Input State changes on Biamp Extension amplifiers?](#)

Amplifier AMP-D225H

[How to update firmware on the AMP-D225H?](#)
[How to use front panel operation?](#)
[Can the amplifier be powered by PoE?](#)
[How can I control the amplifier?](#)
[Is it necessary to connect 24 VDC to the amplifier in order to configure it?](#)
[Are there any Volume up and down commands for the AMP-D225H?](#)

[How do I access the settings in the amplifier?](#)
[Why is the power LED of the amplifier blinking red?](#)
[What can I use the second RS-232 port on the AMP-D225H for?](#)
[Can I drive speakers below 8 ohm?](#)
[How do I connect the amplifier if I wish to use bridge mode?](#)
[How to enable PUSH mode for Input State changes on Biamp Extension amplifiers?](#)

Switching Relay 4 / Switching Relay 8

[How do I control the Switching Relay - 4 or 8?](#)
[Can the Switching Relay - 4 or 8 be controlled via LAN?](#)
[How can I control the Switching Relay - 4 or 8 with the GPIO's?](#)
[How does RS-232 loop-through work on Switching Relay 4 or 8?](#)
[How do I manually setup and configure a Switching Relay 4 or 8?](#)
[What is the max load for one relay in Switching Relay 2/4/8?](#)
[What is the default LAN settings of an Switching Relay - 4 or 8?](#)
[How can I tell the UNIT ID of a given Switching Relay - 4 or 8?](#)
[Can I daisy chain the Switching Relay - 4 or 8 using RS-232 loop through?](#)
[How to enable PUSH mode for Input state changes on Switching Relay - 4 and 8?](#)
[How do I set the IP address for Switching Relay - 4 or 8?](#)
[What is the default Baudrate of a Switching Relay 4 or 8?](#)
[Controlling Switching Relay-4 and 8 from a third party controller](#)
[How do I secure heavy duty cables on the Switching Relay - 8?](#)
[How do I factory reset a Switching Relay - 8?](#)
[How do I factory reset a Switching Relay - 4?](#)
[How to connect relay 3 and 4 on SR-4 with mutual blockage?](#)
[Does the Switching Relay - 4 protect the screen from the possibility of getting mains on both directions of the engine at the same time?](#)

Switching Relay 2

[How do I control the Switching Relay - 2?](#)
[How to add a Switching Relay - 2 to your project?](#)
[What is the junction connector in the Switching Relay - 2 used for?](#)
[What is the internal power supply for?](#)
[Does the Switching Relay - 2 protect the screen from the possibility of getting mains on both directions of the motor at the same time?](#)
[Why are there cut-outs in the printed circuit board?](#)

Apprimo Touch Panels

Apprimo Touch 4, 7 & 10 inch

[Setup menu button damaged? Alternative option to access setup menu](#)
[Is it possible to get a table stand for the touch panel?](#)
[How do you define the LED Backlight Lifetime?](#)
[Is it possible to connect a touch panel to a control system through Wi-Fi?](#)
[Touch screen never turns off when enabling the proximity sensor?](#)
[What is the resolution of the touch panels?](#)

[On-wall mount of 4 inch Touch Panel](#)

[On-wall mount of 7 or 10 inch Biamp Touch Panel](#)

[Are Apprimo Touch 4, 7 & 10 panels supported in a project with Apprimo Touch 8i as the control system?](#)