



PATCH KIT INSTALLATION GUIDE

1. **It's FAST!** so have all your tools and PPE ready:
 - *Gloves & Safety Glasses*
 - *Plastic Mixing Stick (or Margin Trowel)*
 - *Water and Cloth Towel for cleanup*
2. **Prepare** your repair location by removing damaged concrete and oils. Use a chisel and/or a wire brush.
 - *Surface must be completely dry.*
 - *Blow off any dust.*
3. **Remove Contents from Patch Kit Tub:**
 - *Liquid Jar*
 - *Dry Mix Bag*
 - *Mixing Stick*
4. **FIRST: Empty Activator Jar into Tub. NEXT: Empty Dry Mix Bag into Tub.**
5. **Mix well** with enclosed stick until Dry Mix and Activator are fully blended (about 45 seconds)
6. **Scrub** a small amount of Fascrete to coat the surface of the repair site.
7. **Wait 30 Seconds** for the scrub coat to stick, then press more Fascrete to fill repair site.
8. **Finish** using the mixing stick or trowel.
Wipe tools clean with a damp towel when finishing.
9. **Use a Stucco Sponge** (lightly dampened) to achieve a smooth finish to your repair.
10. **Clean tools and gloves with water.**
Wash hands with soap and water when finished.

Fascrete will be completely hardened in less than one hour!

Please visit our website for support and to order more Fascrete.